

DNSR473EW0WW

GE Dryer Lint Screen Filter Replacement Part Instruction Manual

Model: DNSR473EW0WW

1. INTRODUCTION

This manual provides instructions for the installation and maintenance of the Generic Replacement Lint Screen Filter for GE Dryers, specifically compatible with model DNSR473EW0WW. Proper installation and regular maintenance are crucial for the efficient and safe operation of your dryer.

2. SAFETY INFORMATION

- Always disconnect power to the dryer before attempting any installation, removal, or maintenance.
- Wear appropriate personal protective equipment, such as gloves, if necessary.
- Ensure the replacement part is compatible with your specific dryer model before proceeding. Refer to the compatibility section.
- Keep small parts away from children.

3. COMPATIBILITY

This replacement lint screen filter is designed to be compatible with GE Dryer model DNSR473EW0WW. Please verify your dryer's model number before installation to ensure proper fit and function. The part number for this replacement is lint#p5301363.




Image 1: The Generic Replacement Lint Screen Filter. This image shows the full view of the lint screen filter, featuring its white plastic frame and fine mesh screen designed to capture lint from dryer exhaust.

4. SETUP AND INSTALLATION

Follow these steps to replace your dryer's lint screen filter:

1. **Disconnect Power:** Unplug the dryer from the electrical outlet or turn off the circuit breaker supplying power to the dryer.
2. **Locate Existing Filter:** Open the dryer door and locate the existing lint screen filter, typically found in a slot near the dryer opening.
3. **Remove Old Filter:** Grasp the handle of the old lint screen filter and pull it straight out of its housing.
4. **Inspect Housing:** While the old filter is out, inspect the filter housing for any accumulated lint or debris and clean it thoroughly.
5. **Insert New Filter:** Take the new Generic Replacement Lint Screen Filter. Align it with the slot and gently push it all the way in until it is seated firmly.
6. **Restore Power:** Plug the dryer back into the electrical outlet or turn the circuit breaker back on.

Ensure the new filter is fully inserted to prevent lint bypass and maintain dryer efficiency.

5. OPERATING INSTRUCTIONS

Once the replacement lint screen filter is installed, operate your dryer as usual. The primary function of the lint screen is to collect lint and debris from your clothes during the drying cycle. A clean lint screen ensures optimal airflow, reduces drying time, and prevents fire hazards.

Important: Always ensure the lint screen is in place before starting a drying cycle.

6. MAINTENANCE

Regular cleaning of the lint screen is essential for dryer performance and safety.

- **After Every Load:** Remove and clean the lint screen after every drying cycle. Simply pull out the screen and peel off the accumulated lint.
- **Periodic Deep Cleaning:** Over time, fabric softener residue can build up on the screen, reducing airflow. If you notice lint sticking to the screen or reduced airflow, deep clean the screen:
 - a. Remove the lint screen.

- b. Wet both sides of the screen with hot water.
- c. Scrub the screen with a nylon brush and liquid detergent to remove any residue.
- d. Rinse thoroughly with hot water.
- e. Allow the screen to air dry completely before reinserting it into the dryer.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer takes too long to dry clothes.	Clogged lint screen.	Clean the lint screen thoroughly. Perform a deep clean if necessary.
Lint screen does not fit properly.	Incorrect model compatibility.	Verify your dryer's model number against the compatible models listed in this manual. Ensure the filter is inserted correctly.
Dryer feels unusually hot.	Restricted airflow due to lint buildup.	Clean the lint screen. Check the dryer vent for obstructions. If the problem persists, consult a qualified technician.

8. SPECIFICATIONS

Product Type: Dryer Lint Screen Filter

Brand: Generic

Compatible Dryer Model: GE DNSR473EW0WW

Replacement Part Number: lint#p5301363

Material: Plastic frame with mesh screen

Package Contents: 1 x Lint Screen Filter

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the retailer or manufacturer from whom the product was purchased. Keep your purchase receipt for warranty claims.