

[Manuals.plus](#) /

> [VERMESS](#) /

> VERMESS L Shaped Gaming Desk with 4 Drawers, 47" Reversible Home Office Desks with Power Outlets, L Shaped Computer Desk with USB Charging Port and Host Stand, Corner Desk, Easy to Assemble, White 120cm

VERMESS 4CTJCB

VERMESS L Shaped Gaming Desk User Manual

Model: 4CTJCB

Brand: VERMESS

1. INTRODUCTION

Thank you for choosing the VERMESS L Shaped Gaming Desk. This manual provides essential information for the proper assembly, operation, and maintenance of your new desk. Designed for both gaming and home office use, this desk features ample storage, integrated power outlets, and a reversible design to fit various room layouts. Please read this manual thoroughly before beginning assembly or use to ensure safe and efficient operation.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully. Do not skip steps or use unauthorized parts.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the desk or drawers beyond their intended weight capacity.
- Keep liquids away from electrical components, including the built-in power outlets.
- Place the desk on a level surface to prevent wobbling and ensure stability. Use the adjustable feet to compensate for uneven floors.
- Keep small parts and packaging materials away from children to prevent choking hazards.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Desk Panels (Main desktop, L-shaped extension, monitor stand)
- Metal Frame Components (Legs, support bars)

- Fabric Storage Drawers (4 units)
- Built-in Power Outlet Unit (with AC, USB, Type-C ports)
- CPU Host Stand
- Fabric Storage Bag (for side mounting)
- Assembly Hardware (Screws, bolts, nuts, adjustable feet)
- Assembly Tools (Hex key, screwdriver, etc.)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly of the VERMESS L Shaped Gaming Desk is designed to be straightforward. All parts are clearly labeled, and a tool kit is included. It is recommended to assemble the desk with two people for easier handling of larger components.

4.1 Reversible Design

This desk features a reversible design, allowing you to configure the L-shaped extension to either the left or right side to best suit your room layout. Plan your desired orientation before beginning assembly.



Figure 4.1: The reversible design allows for left or right L-shaped configuration.

4.2 Step-by-Step Assembly (General Guidance)

1. **Unpack and Identify:** Lay out all components and hardware. Refer to the included parts list to ensure everything is present and identify each piece.
2. **Assemble Frame:** Begin by connecting the main desk frame components according to the diagrams in the separate assembly guide. Ensure all connections are finger-tight before final tightening.
3. **Attach Desktop Panels:** Secure the desktop panels to the assembled frame. Pay attention to the orientation for the reversible design.
4. **Install Drawers and Accessories:** Assemble and insert the fabric storage drawers into their designated slots. Attach the fabric storage bag and CPU host stand.
5. **Integrate Power Outlet:** Carefully install the built-in power outlet unit into its recessed slot on the desktop.
6. **Final Tightening:** Once all components are in place, systematically tighten all screws and fasteners using the provided tools. Do not overtighten.
7. **Adjust Leveling Feet:** Adjust the leveling feet at the bottom of the desk legs to ensure the desk is stable and level on your floor.

Product Size




Figure 4.2: Product dimensions for planning your space.

5. OPERATING INSTRUCTIONS

5.1 Power Outlets

The desk is equipped with a convenient built-in power outlet unit. This unit includes 3 AC outlets, 1 USB port, and 1 Type-C port, allowing you to power and charge multiple devices directly from your desk, reducing cable clutter.



Power Outlets for Charging



3 AC Outlets
120V/12A



1 USB Port
5V/2A



1 TypeC Port
5V/2A

Figure 5.1: Integrated power outlets for convenient device charging.

5.2 Storage Features

The desk offers various storage solutions to keep your workspace organized:

- **Fabric Storage Drawers:** Four generously sized fabric drawers provide ample space for files, stationery, and personal items.
- **Fabric Storage Bag:** A side-mounted fabric bag offers quick access storage for headphones, cables, or other frequently used items.
- **Open Storage Shelves:** Two open shelves are available for additional storage or display.



Fabric Storage Drawers

4 drawers meet your storage needs

Figure 5.2: Fabric storage drawers for organizing your essentials.



Figure 5.3: Fabric storage bag and open shelves for convenient access.

5.3 Monitor Stand and CPU Host Stand

- The integrated desktop monitor stand elevates your computer monitor to a more ergonomic viewing height, promoting better posture.

- The dedicated CPU host stand keeps your computer tower off the floor, protecting it from dust and moisture while freeing up space under the desk.

5.4 Lighting Modes (If Applicable)

Some models of the VERMESS L Shaped Gaming Desk may include integrated lighting. If your desk features this, it typically offers multiple color changes and lighting modes to enhance your gaming or work environment. Refer to the specific lighting control unit for operation details.



Figure 5.4: Desk with customizable lighting options.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood and electrical components.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent if necessary. Ensure they are completely dry before reinserting.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if any looseness is detected.

- **Avoid Extreme Conditions:** Do not expose the desk to extreme temperatures, direct sunlight for prolonged periods, or high humidity, as this may cause warping or damage.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Issue	Possible Cause	Solution
Desk is wobbly	Uneven floor; loose fasteners	Adjust leveling feet; tighten all assembly screws.
Drawers do not slide smoothly	Improper assembly; obstruction	Ensure drawers are assembled correctly; check for items blocking the slides.
Power outlets not working	Not plugged in; circuit breaker tripped; faulty unit	Ensure desk power cord is securely plugged into a wall outlet; check household circuit breaker; contact support if issue persists.
Missing parts during assembly	Packaging error	Double-check all packaging materials; contact customer support with the specific part number.

8. SPECIFICATIONS

Feature	Detail
Brand	VERMESS
Model Number	4CTJCB
Color	White
Product Dimensions	90D x 120W x 86.2H Centimetres (Approx. 35.4D x 47.2W x 33.9H inches)
Item Weight	18.3 kg (Approx. 40.3 lbs)
Base Material	Iron
Top Material Type	Wood
Number of Drawers	4
Power Outlets	3 AC Outlets, 1 USB Port, 1 Type-C Port
Design Feature	Reversible L-Shape, Built-in Monitor Stand, CPU Host Stand

9. WARRANTY AND SUPPORT

VERMESS is committed to providing high-quality products. Warranty information is typically included with your product packaging. For specific warranty details, claims, or technical support, please refer to the contact information provided on the product packaging or visit the official VERMESS website. A

professional after-sales team is available to assist you with any inquiries or issues.