

Manuals.plus /

› GHCFWKU /

› User Manual: H015R 2500mAh Lithium Battery Pack for Honiture S13 S15 Vacuum

GHCFWKU H015R

User Manual: H015R 2500mAh Lithium Battery Pack

Compatible with Honiture S13 S15 Cordless Vacuum Cleaners

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using your new battery pack. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Do not expose the device to high temperature.** Avoid direct sunlight, heat sources, or storing in vehicles during hot weather.
- **Do not disassemble, crush, or solder.** Tampering with the battery can cause short circuits, fire, or explosion.
- **Do not throw into fire or water.** Dispose of batteries properly according to local regulations.
- Keep out of reach of children.
- Use only with compatible Honiture S13 and S15 cordless vacuum cleaners.
- If the battery pack is damaged, leaking, or shows signs of overheating, discontinue use immediately and contact support.



Figure 1: Important safety symbols and warnings found on the battery label. These symbols indicate precautions against high temperatures, disassembly, and improper disposal.

2. PRODUCT OVERVIEW

The GHCFWKU H015R Lithium Battery Pack is designed as a direct replacement for Honiture S13 and S15 cordless vacuum cleaners, providing reliable power for extended cleaning sessions.

- **Model:** H015R
- **Type:** Lithium Battery
- **Capacity:** 2500mAh
- **Nominal Voltage:** 25.9V (as per label in image)
- **Compatibility:** Honiture S13, Honiture S15 Cordless Vacuum Cleaners





Figure 2: Front view of the H015R battery pack, showing the main body, release button, and ventilation area. This is the side that typically faces outwards when installed.



Figure 3: Rear view of the H015R battery pack, displaying the product label with model information, voltage rating, manufacturer details, and safety warnings. This side is usually hidden when installed.

3. INSTALLATION

Before installing the new battery pack, ensure your Honiture vacuum cleaner is turned off and unplugged from any charging source.

1. **Remove the old battery:** Locate the battery release mechanism on your Honiture S13 or S15 vacuum cleaner. Press the release button (if applicable) and slide the old battery pack out.
2. **Insert the new battery:** Align the new H015R battery pack with the battery slot on your vacuum cleaner. Gently slide the battery into place until it clicks securely. Ensure it is fully seated and does not wobble.
3. **Verify installation:** Once installed, try to gently pull the battery to confirm it is locked in position.



Figure 4: Bottom view of the H015R battery pack, highlighting the four rubber feet for stability and the electrical connection interface. This interface connects the battery to the vacuum cleaner.

4. CHARGING AND USAGE

The H015R battery pack is designed to be charged directly through your Honiture S13 or S15 vacuum cleaner's existing charging system.

4.1 Initial Charge

For optimal performance, it is recommended to fully charge the battery pack before its first use. Connect your vacuum cleaner to its charger and allow it to charge until the charging indicator shows a full charge.

4.2 Regular Charging

Charge the battery whenever the vacuum cleaner's power indicator shows low battery. Avoid completely draining the battery frequently, as this can reduce its lifespan.

4.3 Usage Tips

- Operate the vacuum cleaner according to its original user manual.
- The 2500mAh capacity provides ample runtime for typical household cleaning tasks.
- If the vacuum cleaner stops due to low battery, recharge it promptly.

5. BATTERY CARE AND STORAGE

Proper care and storage will extend the life of your H015R battery pack.

- **Temperature:** Store the battery in a cool, dry place, away from extreme temperatures (below 0°C or above 40°C).
- **Long-term Storage:** If storing the battery for an extended period (more than a month), charge it to approximately 50-60% capacity. Recharge it every 3-6 months to prevent deep discharge.
- **Cleaning:** Keep the battery contacts clean and free of dust or debris. Use a dry cloth to wipe them if necessary.

6. TROUBLESHOOTING

If you encounter issues with your H015R battery pack, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Battery not charging	Not properly seated in vacuum. Charger or vacuum issue. Battery contacts are dirty.	Ensure battery is fully clicked into place. Test vacuum with original battery (if available) or check charger. Clean battery contacts with a dry cloth.
Reduced runtime	Battery not fully charged. Vacuum cleaner filter or brush roll clogged. Battery nearing end of life.	Ensure full charge before use. Clean vacuum cleaner filters and brush roll. Consider replacing the battery if it's old and performance has significantly degraded.
Battery feels hot during charging/use	Normal during heavy use/charging. Overheating due to fault.	If excessively hot or smoking, immediately disconnect and contact support. Ensure proper ventilation around the vacuum during charging.

7. SPECIFICATIONS

Attribute	Detail
Model Number	H015R
Battery Type	Lithium Battery
Capacity	2500mAh
Nominal Voltage	25.9V
Compatibility	Honiture S13, Honiture S15 Cordless Vacuum Cleaners
Item Weight	50 Grams
Assembly Required	No (for battery installation)
Number of Pieces	1
Manufacturer	lizi22543lam
Brand	GHCFWKU

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support for your GHCFWKU H015R battery pack, please refer to the documentation provided with your purchase or contact the seller directly.

Typical warranty terms for replacement parts may vary. Keep your proof of purchase for any warranty claims.

If you have questions or require assistance, please reach out to the manufacturer or seller through the platform where the purchase was made.

