Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE KKG23A-C1

XINFUTE KKG23A-C1 Air Conditioner Remote Control User Manual

Model: KKG23A-C1 (Compatible with KKG23B-C3)

1. Introduction

This manual provides detailed instructions for the XINFUTE KKG23A-C1 replacement remote control, designed for use with Changhong Air Conditioners, specifically compatible with models such as KKG23B-C3. Please read this manual thoroughly before using the remote control to ensure proper operation and longevity.

2. Product Overview

The XINFUTE KKG23A-C1 is an ergonomic replacement remote control for your air conditioner. It is constructed from durable ABS material and comes in the color as shown in the product images. This package includes one remote control unit; batteries are not included.







Image 1: Front view of the XINFUTE KKG23A-C1 remote control, showing its white casing and button layout. The display shows '24°C' and various mode indicators.

Button Functions:

- **Power Button:** Located centrally, used to turn the air conditioner ON or OFF.
- **MODE:** Cycles through various operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **UVC:** Activates or deactivates the Ultraviolet-C sterilization function (if available on your AC unit).
- **SLEEP:** Engages the sleep mode for comfortable overnight operation.
- **TURBO:** Activates rapid cooling or heating for quick temperature adjustment.
- **SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **QUIET:** Reduces fan noise for quieter operation.
- **V-SWEEP:** Controls vertical louver swing for air direction.

- **TIMER:** Sets the ON/OFF timer for scheduled operation.
- **CLEAN:** Initiates the self-cleaning function of the air conditioner.
- **H-SWEEP:** Controls horizontal louver swing for air direction.
- **DISPLAY:** Toggles the display on the air conditioner unit or remote.
- **Temperature/Navigation Arrows:** Used to adjust temperature settings and navigate menu options.

3. Setup

Battery Installation:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Ensure batteries are inserted correctly. Incorrect installation may prevent the remote from functioning or cause damage. Do not mix old and new batteries, or different types of batteries.

4. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

Basic Operation:

- **Power ON/OFF:** Press the central **Power** button once to turn the unit on, and again to turn it off.
- **Adjusting Temperature:** Use the **Up** and **Down** arrow buttons to increase or decrease the desired temperature.
- **Changing Mode:** Press the **MODE** button repeatedly to cycle through available operating modes (e.g., Cool, Fan, Dry, Heat, Auto). The current mode will be displayed on the remote's screen.
- **Adjusting Fan Speed:** Press the **SPEED** button to select your preferred fan speed (e.g., Auto, Low, Medium, High).

Advanced Functions:

- **TURBO Function:** Press **TURBO** for rapid cooling or heating. Press again to deactivate.
- **SLEEP Mode:** Press **SLEEP** to activate a quiet, energy-saving mode that gradually adjusts temperature for comfort during sleep.
- **TIMER Setting:** Press **TIMER** to set the automatic ON or OFF time. Use the temperature arrows to adjust the time and press **TIMER** again to confirm.
- **SWEEP Functions (V-SWEEP / H-SWEEP):** Use **V-SWEEP** for vertical louver movement and **H-SWEEP** for horizontal louver movement to optimize air distribution.
- **QUIET Mode:** Press **QUIET** to reduce the operational noise of the air conditioner.
- **CLEAN Function:** Press **CLEAN** to activate the air conditioner's self-cleaning cycle.
- **UVC Function:** Press **UVC** to enable or disable the ultraviolet sterilization feature, if supported by your air conditioner.
- **DISPLAY Control:** Press **DISPLAY** to turn the air conditioner's display panel on or off.

5. Maintenance

Battery Replacement:

When the remote control's display becomes dim or its range decreases, it is time to replace the batteries. Follow the battery installation steps outlined in Section 3. Always replace both AAA batteries simultaneously.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Air conditioner not responding to specific functions:**
  - Verify that your specific Changhong air conditioner model supports the function (e.g., UVC, CLEAN). Not all features are universal across all AC units.
  - Refer to your air conditioner's original manual for supported features.
- **Display on remote is dim or blank:**
  - Replace the batteries.

7. Specifications

Model Number	KKG23A-C1
Compatible Models	Changhong KKG23B-C3 and similar models
Brand	XINFUTE
Material	ABS Material
Color	As Shown (White)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	Approximately 4 x 3 x 1 inches
Item Weight	Approximately 2.82 ounces
Special Feature	Ergonomic Design

8. Warranty and Support

Warranty Information:

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing

defects under normal use.

Customer Support:

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receiving your product. For further assistance, refer to the contact information provided by your retailer or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F37ZT6J4

More documents and user manuals: **https://manuals.plus/**