

110.86879300

# Instruction Manual: Generic Replacement Lint Filter Screen for Kenmore Dryer Model 110.86879300

## INTRODUCTION

This manual provides instructions for the installation, maintenance, and troubleshooting of the Generic replacement lint filter screen, designed for compatibility with Kenmore dryer model 110.86879300. Please read these instructions carefully before proceeding with installation or maintenance.

## SAFETY INFORMATION

Always prioritize safety when working with appliances. Disconnect power to the dryer before attempting any installation or maintenance. Wear appropriate personal protective equipment if necessary. If you are unsure about any step, consult a qualified technician.

- **Disconnect Power:** Ensure the dryer is unplugged or the circuit breaker is off before handling the lint filter.
- **Handle with Care:** The filter screen may have sharp edges; handle carefully to avoid injury.
- **Proper Fit:** Verify that the replacement part fits securely before operating the dryer.

## SETUP AND INSTALLATION

This section details the steps to replace the lint filter screen in your Kenmore dryer model 110.86879300.

1. **Locate the Existing Filter:** The lint filter is typically located inside the dryer door opening.
2. **Remove the Old Filter:** Grasp the handle of the existing lint filter and pull it straight out of its housing.
3. **Inspect the Area:** Before inserting the new filter, inspect the filter housing for any accumulated lint or debris and remove it.
4. **Insert the New Filter:** Take the new Generic replacement lint filter screen. Align it with the opening and slide it firmly into the housing until it is fully seated. Ensure there are no gaps.



*Image 1: The Generic replacement lint filter screen, showing the mesh basket and the base plate. This image illustrates the complete assembly of the lint filter.*

After installation, close the dryer door and restore power to the appliance.

## OPERATING INSTRUCTIONS

Once the replacement lint filter screen is correctly installed, the dryer can be operated as usual. The new filter will effectively capture lint and debris during the drying cycle, helping to maintain drying efficiency and prevent fire hazards.

## MAINTENANCE

Regular cleaning of the lint filter is crucial for optimal dryer performance and safety.

- **Clean After Every Load:** Always remove and clean the lint filter after each dryer load. This prevents lint buildup, which can restrict airflow, increase drying time, and pose a fire risk.
- **Deep Cleaning:** Periodically, or if you notice a film on the screen that reduces airflow, wash the lint filter with warm, soapy water and a soft brush. Rinse thoroughly and allow it to dry completely before reinserting it into the dryer.
- **Inspect for Damage:** Regularly inspect the filter screen for any tears, holes, or damage. A damaged

filter should be replaced immediately to prevent lint from entering the dryer's exhaust system.

## TROUBLESHOOTING

---

If you experience issues after replacing the lint filter, consider the following:

- **Dryer Not Drying Efficiently:**
  - Ensure the lint filter is clean and free of lint buildup.
  - Check if the filter is fully seated in its housing.
  - Inspect the dryer's exhaust vent for blockages.
- **Lint Escaping into Dryer Drum:**
  - Verify the lint filter is correctly installed and fully seated.
  - Inspect the filter screen for any tears or holes that might allow lint to pass through. Replace if damaged.

If problems persist, consult your dryer's main instruction manual or contact a qualified appliance technician.

## SPECIFICATIONS

---

<b>Product Type</b>	Replacement Dryer Lint Filter Screen
<b>Compatible Dryer Model</b>	Kenmore 110.86879300
<b>Part Number</b>	110.86879300
<b>Manufacturer</b>	Generic
<b>Material</b>	Plastic frame with mesh screen

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage or technical support for this Generic replacement part, please refer to the seller or retailer from whom the product was purchased. Keep your proof of purchase for any warranty claims.

If you have questions about the installation or compatibility, please contact the seller directly.