Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Keazile KZ-FL-004-WH

Keazile 62-inch Walnut Wood Floor Lamp with White Linen Shade Instruction Manual

Model: KZ-FL-004-WH

Introduction Safety Information Package Contents Setup & Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Keazile 62-inch Walnut Wood Floor Lamp. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new floor lamp. Its stylish design, solid wood construction, and soft diffused lighting make it a perfect addition to any living room, bedroom, or office.

Your browser does not support the video tag.

Video 1.1: Overview of the Keazile Solid Wood Floor Lamp, showcasing its design and features in various settings.

2. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure the lamp is unplugged before assembly, changing bulbs, or cleaning.
- Use only E26 base bulbs. Do not exceed the maximum wattage: 60W for incandescent or 13W for LED.
- The lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Place the lamp on a stable, level surface to prevent tipping. The weighted base enhances stability.
- Keep the power cord away from heat sources, sharp edges, and heavy traffic areas.
- Do not attempt to modify or repair the lamp. Contact customer support for assistance.
- This product is UL-certified, ensuring compliance with safety standards.

3. Package Contents

Verify all components are present before beginning assembly.

- Lamp Base (Walnut Wood)
- Lamp Pole (Walnut Wood, multiple sections)
- Lampshade (White Linen, rolled)
- Lampshade Metal Rings (2 pieces, one with 3 arms for bulb socket)
- Bulb Socket Ring
- Power Cord with Foot Switch
- Instruction Manual



Figure 3.1: Key components including the foot switch, E26 bulb base, and solid wood base.

4. Setup and Assembly

Follow these steps to assemble your Keazile Floor Lamp.

4.1 Lampshade Assembly

1. Unfold the rolled linen lampshade and fasten the ends together using the integrated Velcro strips to form a cylinder.
2. Take one of the metal rings (the one with the 3 arms) and face the raised side inward. Snap this ring into the clips on the top edge of the lampshade.
3. Turn the lampshade over and snap the other metal ring into the clips on the bottom edge of the lampshade.
4. Adjust the Velcro for an even, snug lampshade.



Figure 4.1: Lampshade assembly steps.

Your browser does not support the video tag.

Video 4.1: Official Keazile Floor Lampshade Installation Guide. This video demonstrates the step-by-step process of assembling the lampshade, including unfolding, attaching the metal rings, and securing the Velcro.

4.2 Lamp Body Assembly

1. Carefully unpackage the wooden lamp pole sections and the base.
2. Screw the lamp pole sections together clockwise until secure. Ensure the power cord passes through each section.
3. Attach the assembled lamp pole to the wooden base by screwing it clockwise until firmly connected.
4. Unscrew the socket ring from the bulb holder at the top of the lamp pole.
5. Place the assembled lampshade onto the bulb holder, ensuring the metal ring rests securely.
6. Screw the socket ring back onto the bulb holder to secure the lampshade in place.
7. Insert an E26 base bulb (not included) into the socket. Do not exceed 60W incandescent or 13W LED.



Figure 4.2: Lamp body and bulb installation steps.

5. Operation

Operating your Keazile Floor Lamp is simple and convenient.

1. Plug the power cord into a standard 120V AC electrical outlet.
2. Locate the foot switch on the power cord.
3. To turn the lamp ON, gently press the foot switch.
4. To turn the lamp OFF, press the foot switch again.



Figure 5.1: Lamp in OFF and ON states.



Figure 5.2: Detail of the foot switch for easy operation.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect the power before cleaning. Wipe the wooden base and pole with a soft, dry cloth. For the linen shade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely. Unscrew the socket ring, remove the old bulb, and screw in a new E26 bulb (max 60W incandescent / 13W LED). Reattach the socket ring and lampshade.
- **Cord Care:** Periodically inspect the power cord for any damage. If the cord is damaged, discontinue use and contact customer support.

7. Troubleshooting

If you encounter any issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp unplugged. Bulb is loose or burnt out. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check if the bulb is screwed in tightly. Replace the bulb if it is burnt out. Test the outlet with another appliance.
Lampshade is wobbly or uneven.	Socket ring is loose. Lampshade clips not fully engaged. Velcro not properly aligned.	Tighten the socket ring securely. Ensure both metal rings are fully snapped into the lampshade clips. Re-adjust the Velcro on the lampshade for a tight fit.
Lamp flickers.	Loose bulb connection. Incompatible bulb type or wattage.	Tighten the bulb. Ensure the bulb is an E26 base and within the recommended wattage (max 60W incandescent / 13W LED).

8. Specifications

Feature	Detail
Model Number	KZ-FL-004-WH
Product Dimensions	15.7"D x 19.7"W x 61.4"H
Item Weight	10.7 Pounds
Base Material	Walnut Wood
Shade Material	Linen
Shade Color	White
Bulb Base	E26
Max Wattage (Incandescent)	60W
Max Wattage (LED)	13W
Voltage	120 Volts

Feature	Detail
Switch Type	Foot Switch
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Certifications	UL Listed



Figure 8.1: Product dimensions and key specifications.

9. Warranty and Support

9.1 Warranty Information

The Keazile Floor Lamp (Model KZ-FL-004-WH) is covered by a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, concerns, or technical assistance, please contact Keazile Customer Service:

- **Online Service:** Available 24/7 for inquiries.
- **Email Support:** Expect a response within 24 hours.
- **Replacements:** Free replacements are offered for eligible issues.

Visit the official Keazile store for more information:Keazile Store

Keazile

Figure 9.1: Keazile Brand Logo.

© 2026 Keazile. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F389DKYK

More documents and user manuals: **https://manuals.plus/**