

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Aveek](#) /

> [Aveek Wireless Microphone System V8 User Manual](#)

Aveek V8

Aveek Wireless Microphone System V8 User Manual

Model: V8

INTRODUCTION

Thank you for choosing the Aveek Wireless Microphone System. This system is designed to deliver crystal-clear, professional sound for various applications, including karaoke, streaming, weddings, and events. Featuring a professional dynamic mic core and advanced DSP noise cancellation, it ensures high-fidelity vocals free from distortion or static. The advanced 2.4GHz transmission provides a stable, ultra-low latency connection with a range of up to 100 feet, offering freedom of movement. This plug-and-play system requires no complex Bluetooth pairing, apps, or drivers, making it easy to set up with most speakers, karaoke machines, or amplifiers. Both the microphones and receiver are rechargeable via USB-C, providing over 10 hours of continuous use on a single charge.

WHAT'S IN THE BOX

Your Aveek Wireless Microphone System package includes:

- 2 x Handheld Microphones
- 1 x 6.35 mm Wireless Receiver
- 1 x 6.35mm (1/4") to 3.5mm (1/8") Adapter
- 1 x USB Charging Cable
- 2 x Anti-slip Rings
- 1 x User Manual



Image: Package contents of the Aveek Wireless Microphone System.

SETUP INSTRUCTIONS

1. Charging the Devices

Before first use, ensure both microphones and the wireless receiver are fully charged. Use the provided USB charging cable to connect the devices to a suitable USB power source (e.g., wall adapter, computer USB port). The microphones and receiver feature built-in rechargeable batteries.

RECHARGEABLE MICS & RECEIVER

10H Mic battery life

5H Receiver life



Image: Aveek wireless microphone and receiver connected for USB-C charging.

Your browser does not support the video tag.

Video: Demonstrates charging the Aveek wireless microphone and receiver.

2. Automatic Pairing

The Aveek Wireless Microphone System features automatic pairing. Simply turn on the receiver and then turn on each microphone. The devices will automatically connect to each other without manual configuration.



Image: Visual guide to automatic pairing of microphone and receiver.

3. Connecting to an Audio System

Plug the 6.35mm wireless receiver directly into the MIC input of your speaker, karaoke machine, or amplifier. If your audio system has a 3.5mm MIC input, use the included 6.35mm to 3.5mm adapter.



Image: Steps for connecting the receiver to an audio system.

PLUG & PLAY



Note:

not compatible with Bluetooth speakers, laptops, phones, PC, smart TVs, or tablets

Image: Examples of compatible audio systems for the Aveek wireless microphone.

Your browser does not support the video tag.

Video: Demonstrates connecting the wireless receiver to an amplifier and mixer, including a sound test.

OPERATING INSTRUCTIONS

1. Power On/Off

To power on the microphone, slide the power switch to the 'ON' position. To power off, slide the switch to 'OFF'. The receiver also has a power button; press and hold to turn it on or off.

2. Sound Quality and Performance

The microphones feature a cardioid pickup pattern, which focuses on your voice and helps block ambient noise, ensuring clear vocal delivery. The 2.4GHz wireless transmission provides a stable signal with low latency, preventing delays, cut-offs, or howling during use.



PROFESSIONAL SOUND QUALITY

Dynamic mic core + 2.4GHz wireless for crystal-clear sound



Cardioid Pickup

Focuses on your voice
blocks ambient noise



Stable Dynamic Performance

Stable signal, low latency
strong anti-interference

Image: Aveek wireless microphones in use, showcasing professional sound quality.




Long Battery Life

10+ Hours of usage time
3-4 Hours of charging time

Image: Explanation of the microphone's cardioid pickup pattern.

3. Wireless Range

Enjoy reliable transmission up to 100 feet in open environments. This allows for freedom of movement and interaction during performances or presentations.

LONG-DISTANCE STABLE RECEPTION

Reliable transmission range up to **100 ft** in open environments. No dropouts, no interruptions — just pure performance.



Image: Demonstrating the 100ft long-distance stable reception.



Image: Visualizing the 100-foot wireless reception range without interference.

COMPATIBILITY

The Aveek Wireless Microphone System is compatible with most audio systems featuring a 6.35mm (1/4") or 3.5mm (1/8") MIC input, including:

- Amplifiers
- Audio Interfaces
- Karaoke Machines
- PA Systems
- Speakers

Important Note: This system does **not** support Bluetooth connectivity and is not compatible with Bluetooth speakers, laptops, phones, PCs, smart TVs, or direct TV connections.



Image: Devices not compatible with the Aveek wireless microphone system.

MAINTENANCE

To ensure the longevity and optimal performance of your Aveek Wireless Microphone System, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the microphones and receiver. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the system in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For best battery life, avoid fully discharging the batteries frequently. Recharge them regularly, especially if the system will not be used for an extended period.
- **Anti-slip Rings:** Place the included anti-slip rings on the microphones to prevent them from rolling on flat surfaces and to provide a more secure grip.

TROUBLESHOOTING

If you encounter issues with your Aveek Wireless Microphone System, please refer to the following common troubleshooting steps:

- **No Sound:**
 - Ensure both microphones and the receiver are powered on.
 - Check that the receiver is securely plugged into the correct MIC input of your audio system.
 - Verify that the volume on your audio system is turned up.
 - Confirm that the microphones and receiver are charged.
- **Interference/Poor Sound Quality:**
 - Ensure there are no major obstructions between the microphones and the receiver.
 - Move away from other 2.4GHz wireless devices that might cause interference.

- Check if the microphones or receiver are low on battery.

- **Microphone Not Pairing:**

- Turn off both the microphone and receiver, then turn them back on in sequence (receiver first, then microphone) to re-initiate automatic pairing.
- Ensure both devices are sufficiently charged.

SPECIFICATIONS

Feature	Specification
Item Weight	0.67 Kilograms (1.48 pounds)
Microphone Form Factor	Handheld
Item Dimensions (L x W x H)	6.3 x 2.17 x 1.77 inches
Power Source	Battery Powered (1 Lithium Ion battery included)
Material	Plastic
Signal-to-Noise Ratio	92 dB
Hardware Platform	Karaoke Machine
Number of Channels	2
Frequency Response	15 KHz
Connectivity Technology	RF (2.4GHz)
Connector Type	3.5 mm Jack, 6.35 mm Jack
Special Feature	Battery Indicator Light
Polar Pattern	Unidirectional (Cardioid)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in the packaging or visit the official Aveek website. Keep your purchase receipt for warranty claims.