

DS13C5

Generic Dancing Stand 5-Tier Display Shelf (Model DS13C5) Instruction Manual

Your guide to setting up, operating, and maintaining your 360-degree automatic rotation display shelf.

PRODUCT OVERVIEW

The Generic Dancing Stand 5-Tier Display Shelf, Model DS13C5, is designed to showcase your items with a unique 360-degree automatic rotation feature. Inspired by 1970s space-age aesthetics, this shelf offers adjustable tiers and a durable construction, making it a distinctive addition to any room.

Key Features:

- Dynamic 360° Rotation:** Features automatic 360-degree rotation, allowing for a stunning display that rotates continuously, showcasing your favorite items in motion.
- 5-Tier Adjustable Shelves:** Customizable tiers to accommodate various sizes of display items, from small trinkets to larger collectibles, offering a unique display solution.
- Space-Age Inspired Design:** Evokes the futuristic and artistic vibe of 1970s space-age aesthetics, making it a perfect addition to modern and retro-inspired interiors.
- Unique Installation Art Piece:** More than just a shelf, this display piece is an eye-catching work of art, ideal for adding a statement to your living room, office, or gallery space.
- High-Quality Construction:** Built with durable materials to ensure stability and longevity, with a sleek, minimalistic design that complements any décor style.



Image: The fully assembled 5-tier display shelf in a living room setting, showcasing its wavy chrome design and items on its shelves.

SETUP AND ASSEMBLY

The Dancing Stand is designed for straightforward assembly. Please follow these steps carefully to ensure proper setup and functionality.

Unboxing and Component Check:

1. Carefully open the packaging and remove all components.
2. Verify that all parts listed in the included hardware and parts list are present. Refer to the diagram below for component identification.




Image: A diagram illustrating the dimensions of the shelf (13.8 inches wide, 60.6 inches high) and the individual tier heights (12.2 inches), along with a small diagram of the power unit.

Assembly Steps:

1. Place the base unit on a flat, stable surface. Ensure the power button is accessible.
2. Attach the first set of wavy support rods to the base unit, ensuring they are securely fastened.
3. Carefully place the first glass shelf onto the support rods. Ensure it sits flush and is stable.
4. Continue adding the remaining support rods and glass shelves in sequence, working your way upwards.
5. Once all five tiers are assembled, gently press down on each shelf to confirm secure connections.
6. Connect the power adapter to the designated port on the base unit and plug it into a standard electrical outlet.

Your browser does not support the video tag.

Video: An unboxing and assembly demonstration of the Chrome Wavy Dancing Shelf, showing how to connect the components and set up the unit.

OPERATING INSTRUCTIONS

The Dancing Stand features a simple one-button operation for its automatic rotation function.

Powering On/Off:

- Ensure the shelf is properly assembled and plugged into a power source.
- Locate the red power button on the base of the unit.
- Press the power button once to initiate the automatic 360-degree rotation. The shelves will begin to move in a dynamic, wavy pattern.
- Press the power button again to stop the rotation and power off the unit.

Placing Items on Shelves:

- Place items evenly on each shelf to maintain balance during rotation.
- Avoid placing excessively heavy items on a single shelf. Refer to the specifications for weight limits per shelf.
- Ensure items are stable and will not fall off during movement.

Your browser does not support the video tag.

Video: A demonstration of the Chrome Wavy Dancing Shelf in operation, showing its 360-degree automatic rotation with various items displayed on its tiers.

MAINTENANCE AND CARE

Proper maintenance will ensure the longevity and optimal performance of your Dancing Stand.

Cleaning:

- Disconnect the power before cleaning.
- Wipe the chrome frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- Clean glass shelves with a glass cleaner and a soft cloth.
- Ensure all parts are dry before reconnecting power.

Storage:

- If disassembling for storage, follow the assembly steps in reverse.
- Store components in their original packaging or a protective container to prevent damage.
- Store in a dry environment, away from extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your Dancing Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shelf does not rotate.	Not plugged in. Power button not pressed. Power adapter issue.	Ensure the power adapter is securely plugged into both the unit and a working electrical outlet. Press the red power button on the base. Try a different power outlet. If the issue persists, contact customer support.
Rotation is uneven or jerky.	Uneven weight distribution. Obstruction in the rotation mechanism.	Rearrange items on the shelves to distribute weight evenly. Inspect the base and rotating parts for any obstructions and remove them.
Noise during operation.	Loose components. Motor issue.	Check all connections and ensure they are tightened. If the noise persists and is unusual, discontinue use and contact customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	DS13C5
Brand	Generic
Material	Aluminum, Cast Iron
Color	Chrome
Product Dimensions	13"D x 13"W x 60"H
Number of Shelves	5
Shelf Type	Floating Shelf
Item Weight	23 Pounds
Special Features	Adjustable, Detachable, Durable, Space Saving, 360-degree Automatic Rotation
Assembly Required	Yes
Mounting Type	Floor Mount
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Specific warranty information for the Generic Dancing Stand 5-Tier Display Shelf (Model DS13C5) is not provided in the product details. Please refer to your purchase documentation or contact the seller directly for warranty details.

For further assistance or inquiries, please contact the seller, Dancing Stand Official, through the platform where the product was purchased.



Image: Contact information for Dancing Stand Official, including Instagram handle, WhatsApp number, and email address.