

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JISULIFE](#) /

› [JISULIFE Portable Handheld Fan Ultra2 Instruction Manual](#)

JISULIFE Handheld Fan Ultra2

JISULIFE Portable Handheld Fan Ultra2 Instruction Manual

Model: Handheld Fan Ultra2 | Brand: JISULIFE

1. INTRODUCTION

Thank you for choosing the JISULIFE Portable Handheld Fan Ultra2. This versatile device combines a powerful fan, a robust power bank, and a multi-functional flashlight, making it an essential companion for various activities. Designed for convenience and durability, the Ultra2 offers customizable airflow and reliable power on the go.

Key features include:

- 100 adjustable wind speeds with a powerful 43000 RPM motor and Storm Mode.
- 9000mAh rechargeable battery providing up to 25 hours of runtime.
- 18W reverse quick charging function to serve as a power bank.
- Digital display for real-time wind speed and battery life.
- Integrated flashlight with 3 brightness levels and an SOS flashing mode.
- Magnetic accessories for dust removal and inflation.
- Durable metal shell and safety lock design.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- JISULIFE Portable Handheld Fan Ultra2
- Small screwdriver
- Cleaning brush
- Storage bag
- Magnetic circular air nozzle
- Magnetic rectangular air nozzle
- Instruction manual
- Hanging rope
- USB-A to USB-C charging cable



Image: JISULIFE Portable Handheld Fan Ultra2 with included accessories.

Your browser does not support the video tag.

Video: An overview of the JISULIFE Handheld Fan Ultra2 and its features.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the device. Connect the provided USB-A to USB-C charging cable to the fan's

USB-C port and a compatible power adapter (not included). The digital display will show the charging progress. A full charge takes approximately 2.5 hours with 18W fast charging.



Image: The fan connected via USB-C, demonstrating its charging capability.

4. OPERATING INSTRUCTIONS


4.1 Power On/Off and Safety Lock

The fan features a safety lock to prevent accidental activation. To power on the device, slide the safety lock switch to the '-' position. To power off, slide it to the 'o' position.

Performance Monster in Your Control




Speed 1-100 adjustable
Instant cooling!



Handheld Fan Ultra2

Ultra high-speed motor reaching up to 43,000 RPM



General Fan

Maximum speed does not exceed 7000RPM

Image: Close-up of the fan's controls, including the safety lock and power button.

4.2 Fan Operation and Speed Adjustment

Once powered on, the digital display will activate. Use the scroll wheel to adjust the wind speed from 1 to 100. Press and hold the scroll wheel for 3 seconds to activate "Storm Mode" (100 speed). Release to return to the previous speed setting.

5 IN 1 Handheld Fan



Image: The fan's digital display indicating 100% wind speed.

4.3 Flashlight Operation

The flashlight is located on the front of the fan. Press the flashlight switch button to cycle through 3 brightness levels. Long press the button to turn off the flashlight. An SOS flashing light mode is also available for emergencies.

18W Reverse Fast Charging

Your Backup Power Bank



Image: The fan's integrated flashlight in operation.

4.4 Power Bank Function

The fan is equipped with a 9000mAh battery and supports 18W reverse quick charging. Connect your device to the fan's USB-C port using a compatible cable to charge it. The digital display will show the remaining battery life.

A Good Helper for Outdoor Lighting

Lighting Number of levels Brightness (at 100cm)

Level 1

8502K color temperature, 35LUX

Level 2

8634K color temperature, 67LUX

Level 3

10195K color temperature, 82LUX



Image: The fan being used to charge a smartphone, highlighting its power bank capability.

Your browser does not support the video tag.

Video: Demonstrating the fan's power bank feature, charging a phone in an outdoor setting.

4.5 Magnetic Accessories

The fan comes with two magnetic air nozzles that can be easily attached to the front. These nozzles enhance its versatility:

- **Dust Removal Tool:** Attach the appropriate nozzle to use the fan as a powerful dust blower for cleaning keyboards, camera lenses, or other delicate items.
- **Inflation Pump:** Use the nozzles to inflate small items like air mattresses or swimming rings.

9000mAh Large Battery

Up to 25 Hours of Runtime



Image: The fan with its magnetic air nozzles, ready for various applications.

Your browser does not support the video tag.

Video: Showcasing the multi-functional capabilities of the fan, including its use as an air pump and dust blower.

5. MAINTENANCE

5.1 Cleaning

The fan features a removable rear net for easy cleaning. Before cleaning, ensure the device is powered off and the safety lock is engaged. Use the provided small screwdriver to remove the screws on the rear net, then detach it. Use the cleaning brush to remove dust and debris from the air inlet and fan blades. Wipe the exterior with a soft, dry cloth. Do not use water or harsh chemicals directly on the device.

LED Display

Wind speed and battery percentage can clear at a glance



Removable Air Inlet Net

A removable and washable air inlet net ensures clean air output. Honeycomb air inlet structure prevents hair from being sucked in

Safety Lock

Prevent accidental touch for greater safety

Lightswitch Button

Flashlight switch, tap to change gears, long press to turn off

Image: The fan with its rear net removed, illustrating the cleaning process.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is low or depleted; Safety lock is engaged.	Charge the fan fully. Ensure the safety lock is slid to the '-' position.
Weak airflow.	Low speed setting; Air inlet/outlet blocked by dust.	Increase wind speed using the scroll wheel. Clean the rear net and fan blades.
Device not charging.	Charging cable or adapter issue; Port is dirty.	Try a different USB-C cable and power adapter. Ensure the USB-C port is clean.
Flashlight not working.	Battery is low; Flashlight switch not pressed correctly.	Charge the fan. Press the flashlight switch button firmly.

7. SPECIFICATIONS

Feature	Detail
Brand	JISULIFE
Model Name	Handheld Fan Ultra2
Battery Capacity	9000mAh
Max Runtime	25 hours
Charging Power	18W (Reverse Quick Charging)
Wind Speed Levels	1-100 (Adjustable)
Motor Speed	43000 RPM
Max Wind Speed	17m/s
Flashlight Brightness	3 levels + 1 flashing mode
Material	Metal Shell
Dimensions	5.31"D x 2.95"W x 1.57"H
Item Weight	10.5 Ounces

8. WARRANTY AND SUPPORT

JISULIFE offers a 1-Year (12 months) warranty period for the Portable Handheld Fan Ultra2. During this time, our dedicated support team is available to assist you with any issues arising during product usage. For warranty claims or technical support, please contact JISULIFE-NA customer service through the Amazon platform or visit the official JISULIFE website for contact information.

For more information, visit the [JISULIFE Store on Amazon](#).