

AEG 7000, AEG ASKW5, Electrolux Cordless 700 (EP71UB14DB, EP71AB14UG, EP71HB14SH, EP71B14WET, EP71UB14AM, EP71AB14N4)

## Generic Replacement Filter Kit for AEG 7000, AEG ASKW5, and Electrolux Cordless 700 Handheld Vacuum Cleaners

Models: EP71UB14DB, EP71AB14UG, EP71HB14SH, EP71B14WET, EP71UB14AM, EP71AB14N4

### INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Generic Replacement Filter Kit. Designed for compatibility with specific AEG and Electrolux cordless handheld vacuum cleaner models, this kit ensures optimal filtration performance and a healthier home environment. Please read these instructions carefully before use.

### PRODUCT OVERVIEW

The filter kit includes a complete set of filters necessary for comprehensive air purification within your vacuum cleaner system. It consists of:

- **Two (2) Pre-Motor Filters:** These filters capture larger dust particles before they reach the motor, protecting the vacuum's internal components and extending its lifespan.
- **One (1) Hygiene Filter (Fine Dust Filter):** This advanced filter is part of a 5-level filtration system, designed to remove up to 99.9% of micro-dust particles, ranging from 0.3 to 10 µm, ensuring cleaner exhaust air.

Together, these filters work to maintain optimal dust removal efficiency and contribute to a healthier living space.



*Figure 1: The complete filter kit, including two pre-motor filters (mesh design) and one hygiene filter (pleated design).*



*Figure 2: A close-up of a pre-motor filter, featuring its mesh filtration surface.*

## COMPATIBILITY

---

This filter kit is specifically designed for the following cordless handheld vacuum cleaner models:

- AEG 7000
- AEG ASKW5
- Electrolux Cordless 700 (Models: EP71UB14DB, EP71AB14UG, EP71HB14SH, EP71B14WET, EP71UB14AM, EP71AB14N4)

Ensure your vacuum cleaner model matches one of the listed compatible models for proper fit and function.

## INSTALLATION

---

Follow these general steps to replace the filters in your compatible vacuum cleaner. Refer to your vacuum cleaner's original manual for specific instructions on accessing the filter compartment.

1. **Power Off:** Ensure the vacuum cleaner is turned off and unplugged from any power source before beginning installation.
2. **Locate Filter Compartment:** Identify the filter compartment on your vacuum cleaner. This is typically

located near the dustbin.

3. **Remove Old Filters:** Carefully remove the existing pre-motor and hygiene filters. Dispose of old filters responsibly.
4. **Insert New Filters:**
  - Place the new pre-motor filters into their designated slots. Ensure they are seated correctly.
  - Insert the new hygiene filter, making sure it fits snugly.
5. **Close Compartment:** Securely close the filter compartment cover.
6. **Test:** Power on the vacuum cleaner to ensure proper operation.



*Figure 3: Filters shown from multiple perspectives, illustrating their design for proper fit.*

## OPERATING PRINCIPLES

The filters are integral to the vacuum cleaner's operation, ensuring efficient dust and allergen capture. When the vacuum is in use, air is drawn through the pre-motor filters first, which trap larger debris. Subsequently, the air passes through the hygiene filter, which captures fine dust particles and allergens before the air is expelled back into the room. Regular replacement and cleaning of these filters are crucial for maintaining the vacuum's suction power and air purification capabilities.

## MAINTENANCE



Proper maintenance of your filters ensures continued optimal performance and extends the life of your vacuum cleaner.

### Cleaning Instructions:

- Both the pre-motor filters and the hygiene filter are washable and reusable.
- Gently tap the filters to remove loose dust.
- Rinse the filters under cool, running water until the water runs clear. Do not use detergents or hot water.
- Allow the filters to air dry completely for at least 24 hours before reinserting them into the vacuum cleaner. Ensure they are absolutely dry to prevent mold growth and damage to the vacuum.

### Replacement Schedule:

- It is recommended to replace the **pre-motor filter** every **6 months**.
- It is recommended to replace the **hygiene filter** every **12 months**.

Regular replacement according to this schedule will help maintain the vacuum's suction power and filtration efficiency.



*Figure 4: A detailed view of the hygiene filter, showing its pleated structure designed for fine dust capture.*

## TROUBLESHOOTING

---

If you experience issues with your vacuum cleaner after filter installation or during use, consider the following:

- **Reduced Suction Power:**
  - Check if filters are clogged. Clean or replace them as per the maintenance schedule.
  - Ensure filters are completely dry before reinstallation.
  - Verify that filters are correctly seated in their compartments.
- **Unusual Odors:**
  - Filters may be dirty or not completely dry. Clean and thoroughly dry them.
  - Consider replacing filters if odors persist after cleaning.
- **Visible Dust Exhaust:**
  - Ensure the hygiene filter is correctly installed and not damaged.
  - The filter may be past its effective lifespan; replace it.

If problems persist, consult your vacuum cleaner's original instruction manual or contact the vacuum cleaner manufacturer's support.

**SPECIFICATIONS**

Product Name	Filter Kit
Number of Pieces	3 (2 Pre-Motor Filters, 1 Hygiene Filter)
Fitment	AEG 7000, AEG ASKW5, Electrolux Cordless 700 (EP71UB14DB, EP71AB14UG, EP71HB14SH, EP71B14WET, EP71UB14AM, EP71AB14N4)
Material	Not specified (typically synthetic filtration media)
Dimensions	Refer to Figure 5 for detailed measurements.
Filtration Efficiency	Up to 99.9% of micro-dust particles (0.3 to 10 µm)




Figure 5: Dimensional specifications for the pre-motor filter (top) and hygiene filter (bottom).

## WARRANTY AND SUPPORT

As a generic replacement part, specific warranty information may vary. Please refer to the retailer or seller for details regarding returns or defects. For operational issues related to your vacuum cleaner, consult the original manufacturer's support channels.

**Related Documents - AEG 7000, AEG ASKW5, Electrolux Cordless 700 (EP71UB14DB, EP71AB14UG, EP71HB14SH, EP71B14WET, EP71UB14AM, EP71AB14N4)**

 <p><b>AEG</b> Instruction Book</p> <p>ULTIMATE 7000 ANIMAL 7000 HYGIENIC 7000</p>	<p><a href="#">AEG 7000 Series Cordless Stick Vacuum Cleaner: Ultimate, Animal, Hygienic - Instruction Manual</a></p> <p>Comprehensive instruction manual for the AEG 7000 Series cordless stick vacuum cleaners, including Ultimate, Animal, and Hygienic models. Learn about assembly, charging, operation, maintenance, and accessories.</p>
 <p><b>BELiFE</b> Live life as it is</p> <p>Contact us if you have any questions: ✉ <a href="mailto:Belifehome@outlook.com">Belifehome@outlook.com</a> ☎ 401-300-0032</p>	<p><a href="#">Belife Cordless Vacuum Cleaner User Manual and Troubleshooting Guide</a></p> <p>Comprehensive guide for the Belife cordless vacuum cleaner, covering assembly, operation, troubleshooting, and maintenance of filters and brush. Learn how to use and care for your device.</p>
	<p><a href="#">Fanttik Fold V10 Ultra Deluxe Cordless Handheld Vacuum Cleaner User Manual</a></p> <p>User manual for the Fanttik Fold V10 Ultra Deluxe Cordless Handheld Vacuum Cleaner, covering safety instructions, product overview, package contents, usage, cleaning, maintenance, wall mounting, LED indicators, troubleshooting, specifications, and warranty information.</p>
 <p><b>Electrolux</b> Instruction Book</p> <p>ULTIMATE 700 ANIMAL 700 HYGIENIC 700</p>	<p><a href="#">Electrolux Ultimate 700, Animal 700, Hygienic 700 Cordless Vacuum Cleaner Instruction Manual</a></p> <p>Comprehensive instruction manual for Electrolux Ultimate 700, Animal 700, and Hygienic 700 series cordless stick vacuum cleaners. Covers assembly, operation, charging, maintenance, and accessory usage.</p>
	<p><a href="#">Electrolux Rapido ZB6210EB, ZB6214IGM, ZB6218STM Handheld Vacuum Cleaner User Manual and Safety Guide</a></p> <p>Comprehensive user manual and safety guide for the Electrolux Rapido handheld vacuum cleaner models ZB6210EB, ZB6214IGM, and ZB6218STM. Learn about features, charging, usage, maintenance, safety precautions, and proper disposal.</p>
 <p><b>Electrolux</b></p>	<p><a href="#">Electrolux UltimateHome 900 Cleaning Station User Guide and Spring Replacement</a></p> <p>Detailed instructions for using the Electrolux UltimateHome 900 cleaning station, including pad washing, drying, and spring replacement for optimal performance. Learn how to maintain your Electrolux cordless vacuum.</p>



