JELLYPIG X100

JELLYPIG X100 Flat Suction Handheld Vacuum Instruction Manual

Model: X100 | Brand: JELLYPIG

1. Important Safety Instructions

Please read all instructions carefully before using the JELLYPIG X100 Flat Suction handheld vacuum. Retain this manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filter in place.
- Turn off the appliance before connecting or disconnecting the battery charger.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Exercise extra care when cleaning on stairs.
- If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.

2. Package Contents

Verify that all items are present in your package:

- JELLYPIG X100 Main Unit (Handheld Vacuum)
- Crevice Tool
- USB Charging Cable
- Instruction Manual

3. Product Overview

Familiarize yourself with the components of your JELLYPIG X100 handheld vacuum.





Image 1: JELLYPIG X100 Main Unit. This image displays the main body of the JELLYPIG X100 handheld vacuum. It features a sleek, dark gray cylindrical design. Towards the top, there is a transparent purple-tinted section, which likely serves as the dust collection bin or filter housing, allowing visibility of collected debris. The overall form suggests a compact and ergonomic design for handheld use.

1. **Suction Nozzle:** The opening through which debris is collected.
2. **Dust Cup/Bin:** Transparent section for collecting dust and debris (visible as purple-tinted area in image).
3. **HEPA Filter:** Located inside the dust cup, filters fine particles.
4. **Power Button:** Activates and deactivates the vacuum.
5. **Charging Port:** For connecting the USB charging cable.
6. **Crevice Tool Attachment Point:** Where the crevice tool connects.

4. Setup

4.1 Initial Charging

Before first use, fully charge the JELLYPIG X100.

1. Locate the charging port on the main unit.
2. Connect the provided USB charging cable to the charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a powered USB port.
4. The charging indicator light (if present, refer to product for exact location) will illuminate during charging and turn off or change color when fully charged.
5. Allow approximately 3-4 hours for a full charge.

4.2 Attaching the Crevice Tool

For reaching tight spaces, attach the crevice tool:

- Align the crevice tool with the suction nozzle or attachment point on the main unit.
- Push firmly until it clicks into place.
- To remove, pull the tool away from the main unit.

5. Operating Instructions

5.1 Powering On/Off

- To turn on: Press the Power Button once.
- To turn off: Press the Power Button again.

5.2 Vacuuming

- Ensure the dust cup is empty and the filter is clean before use.

- Turn on the vacuum.
- Direct the suction nozzle or attached crevice tool towards the area to be cleaned.
- Move the vacuum slowly over the surface to allow for effective debris collection.
- After use, turn off the vacuum.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your JELLYPIG X100.

6.1 Emptying the Dust Cup

Empty the dust cup after each use or when debris reaches the MAX fill line.

1. Ensure the vacuum is turned off.
2. Locate the dust cup release button or twist mechanism (refer to product for exact location).
3. Remove the dust cup from the main unit.
4. Hold the dust cup over a trash receptacle and empty its contents.
5. Reattach the dust cup to the main unit, ensuring it clicks securely into place.

6.2 Cleaning the HEPA Filter

Clean the HEPA filter regularly to maintain suction power. It is recommended to clean it every 3-5 uses, depending on usage.

1. With the dust cup removed, carefully pull out the HEPA filter.
2. Tap the filter gently over a trash can to remove loose dust.
3. If heavily soiled, rinse the filter under cool running water.**Do not use detergent.**
4. Allow the filter to air dry completely for at least 24 hours before reinserting**Do not use the vacuum with a wet filter.**
5. Once dry, place the HEPA filter back into the dust cup and reattach the dust cup to the main unit.

6.3 General Cleaning

- Wipe the exterior of the vacuum with a soft, damp cloth.
- Do not use harsh chemicals or abrasive cleaners.
- Ensure no liquid enters the motor housing.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum fully.
Weak suction.	Dust cup is full. Filter is clogged. Suction nozzle is blocked.	Empty the dust cup. Clean or replace the HEPA filter. Remove any obstructions from the nozzle.

Problem	Possible Cause	Solution
Unusual noise during operation.	Obstruction in the suction path.	Turn off the vacuum and check for blockages in the nozzle or dust cup area.
Charging indicator not working.	Cable or adapter issue. Charging port damage.	Ensure the USB cable and adapter are working correctly. Try a different cable/adapter. Contact support if issue persists.

8. Specifications

Brand: JELLYPIG

Model Name: X100

Special Feature: Cordless

Filter Type: HEPA Filter

Included Components: Crevice Tool

Capacity: 1.6 Liters

Form Factor: Handheld

Color: Black

Product Dimensions: 5"L x 2"W x 3"H

Item Weight: 8 ounces

Portable: Yes

Batteries required: No

9. Warranty and Support

The JELLYPIG X100 Flat Suction handheld vacuum comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact JELLYPIG customer service through the retailer's platform or visit the official JELLYPIG store page on Amazon:

Visit the JELLYPIG Store on Amazon

© 2025 JELLYPIG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question