**iJoy IJ1038**

# iJoy Magnetic Selfie Stick Tripod with Remote User Manual

Model: IJ1038

## Introduction

Thank you for choosing the iJoy Magnetic Selfie Stick Tripod with Remote. This versatile accessory is designed to enhance your mobile photography and videography experience, offering both a stable tripod and an extendable selfie stick. Its strong magnetic mount ensures secure attachment for compatible iPhone models, and the included Bluetooth remote provides convenient hands-free control.
Please read this manual carefully before using the product to ensure proper operation and to maximize its features.

## Package Contents

- Magnetic Selfie Stick with Tripod
- Bluetooth Remote Shutter

## Product Overview



Figure 1: iJoy Magnetic Selfie Stick Tripod in both tripod and extended selfie stick modes. The image shows the device holding a smartphone, demonstrating its dual functionality.




Figure 2: Key features of the MagSnap Selfie Stick & Tripod. This diagram highlights its adjustable length, multi-functional design, strong magnetic attachment, and integrated Bluetooth shutter.

The iJoy Magnetic Selfie Stick Tripod is designed for ease of use and portability. It features an extendable shaft, foldable tripod legs, a strong magnetic phone mount, and a detachable Bluetooth remote shutter.

## Compatibility

This device is compatible with MagSafe-enabled iPhones, specifically iPhone series 12, 13, 14, 15, 16, and newer models that support MagSafe technology.

## Setup

### 1. Unfolding the Tripod/Selfie Stick

1. Gently pull the bottom part of the handle downwards to extend the tripod legs. Ensure the legs are fully spread for maximum stability when used as a tripod.

2. To use as a selfie stick, hold the handle firmly and extend the telescopic pole upwards to your desired length. The stick can extend up to 26 inches.




Figure 3: The selfie stick extended to its maximum length of 26 inches. This image demonstrates the full extension capability of the device.




Figure 4: The foldable design of the selfie stick tripod. This image illustrates how the device can be compactly folded for easy storage and portability.

## 2. Attaching Your Phone

- Ensure your iPhone is MagSafe compatible.
- Align the back of your iPhone with the magnetic ring on the selfie stick mount. The strong magnet will securely attach your phone.
- Adjust the angle of your phone by tilting the magnetic mount.

## 3. Pairing the Bluetooth Remote Shutter

1. Locate the Bluetooth remote shutter, which is typically integrated into the handle of the selfie stick. Gently slide it out if it's docked.
2. Press and hold the button on the remote until the indicator light starts blinking, indicating it's in pairing mode.
3. On your iPhone, go to **Settings** > **Bluetooth**.

4. Select "iJoy Remote" or a similar name from the list of available devices. The indicator light on the remote will stop blinking and remain solid once paired.
5. The remote is now ready to use for taking photos or starting/stopping video recording.




Figure 5: Close-up view of the Bluetooth shutter button. This image highlights the remote's location and design, indicating its readiness for use.

## Operating Instructions

### Using as a Selfie Stick

- Extend the pole to your desired length.
- Position your phone for the perfect shot.
- Press the button on the Bluetooth remote to capture photos or start/stop video recording.




Figure 6: A person using the iJoy selfie stick to capture a photo. This image demonstrates the product in action, highlighting its ease of use for self-portraits.

## Using as a Tripod

- Extend the tripod legs fully and place the tripod on a flat, stable surface.
- Adjust the height of the pole if necessary.
- Use the Bluetooth remote for hands-free photo or video capture, ideal for group shots, time-lapses, or stable video recording.




Figure 7: A person using the iJoy selfie stick tripod as a stable stand. This image illustrates its utility for video recording, live streaming, or hands-free viewing.

## Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, collapse the selfie stick and fold the tripod legs for compact storage. Store in a cool, dry place away from direct sunlight.
- **Battery:** The Bluetooth remote uses a small button cell battery. If the remote stops responding, replace the battery. Refer to the remote's casing for battery type (typically CR2032).

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Bluetooth remote not pairing. | Remote battery is low or dead.<br>Remote is not in pairing mode.<br>Bluetooth on phone is off. | Replace the remote battery.<br>Press and hold the remote button until the light blinks.<br>Enable Bluetooth on your phone. |
| Phone not securely attaching. | Phone is not MagSafe compatible.<br>Obstruction between phone and magnet. | Ensure your phone is MagSafe compatible (iPhone 12 series or newer).<br>Remove any thick cases or foreign objects. |
| Selfie stick feels unstable. | Tripod legs not fully extended.<br>Uneven surface.<br>Excessive weight on the stick. | Ensure tripod legs are fully spread.<br>Place on a flat, stable surface.<br>Do not attach accessories that exceed the stick's weight capacity. |

## Specifications

| Feature | Detail |
|---|---|
| Model Number | IJ1038 |
| Brand | iJoy |
| Compatibility | MagSafe-compatible iPhones (iPhone 12, 13, 14, 15, 16, and newer) |
| Max Extension Length | 26 inches |
| Connectivity | Bluetooth (for remote shutter) |
| Special Features | Lightweight, Remote Control, Foldable, Strong Magnetic Mount |
| Item Weight | 5 ounces |
| Dimensions (Folded) | Approx. 7.8 x 2.48 x 1.93 inches |
| Battery (Remote) | 1 Product Specific battery (included) |

## Warranty Information

iJoy products are manufactured with high-quality materials and craftsmanship. This product comes with a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.
For detailed warranty terms and conditions, please visit the official iJoy website or contact customer support.

## Customer Support

If you have any questions, issues, or require assistance with your iJoy Magnetic Selfie Stick Tripod, please contact our customer support team:

- **Website:** Visit the iJoy Store on Amazon
- **Manufacturer:** Quest USA Corp

When contacting support, please have your product model number (IJ1038) and purchase details ready.

© 2025 iJoy. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question