
[Manuals.plus](#) /

› [XGIMI](#) /

› XGIMI MoGo 4 Portable Projector User Manual

XGIMI WK08K

XGIMI MoGo 4 Portable Projector User Manual

Model: WK08K | Brand: XGIMI

INTRODUCTION

This manual provides essential information for the safe and effective operation of your XGIMI MoGo 4 Portable Projector. Please read it thoroughly before use and retain it for future reference.



The XGIMI MoGo 4 Portable Projector, designed for versatile entertainment.

SETUP

Unpacking and Initial Power On

Carefully remove all components from the packaging. The MoGo 4 features a built-in battery for immediate use. To power on, simply slide the projector up from its base. It will automatically start within a few seconds.

Cinematic Streaming, Anytime.




NETFLIX



The MoGo 4 is designed for quick setup and portability.

Positioning and Automatic Adjustments

The 360° adjustable stand allows for flexible projection angles, from wall to ceiling. The integrated ISA Technology automatically aligns and adjusts the image for optimal viewing, including auto-focus and auto-keystone correction.



Crystal Clear, Stunningly Real.

 **450** ISO
Lumens

1080P



90% DCI-P3
Color Gamut

Projecting onto a ceiling with the 360° adjustable stand.

OPERATING

Google TV and Streaming

The MoGo 4 comes with Google TV and licensed Netflix built-in, providing access to a vast library of apps and content. Navigate using the included remote controls.




Access your favorite streaming services directly from the projector.

Remote Controls

Your projector includes two remote controls: a standard Bluetooth remote with shortcut buttons and a mini keyring remote for basic functions. The standard remote is backlit for ease of use in low light.

Ambient Light Mode and Creative Filters

Enhance your environment with the ambient light mode, offering various colors that can react to music. The MoGo 4 also supports magnetic creative filters (Sunset Filter included) that snap onto the lens to project different themes and moods. Additional filters are available separately.



Magnetic Creative Filter

Click, Click, BOOM

Transforming your space has never been simpler. Just snap the Magnetic Creative Filter onto the lens, and vibe out.

The Magnetic Sunset Filter creates a warm, golden-hour ambiance.

1. HDR 10 is not supported when HDMI is connected.
2. Brightness (light output) will vary depending on usage conditions. White light output is measured according to ISO 21118. The nominal value represents the average value of mass-produced units and is tested under ideal laboratory conditions in Performance Mode/High Power Mode. In Performance Mode, the highest brightness is achieved, which may result in some color differences compared to the default viewing mode. Additionally, the fan speed may increase, potentially causing noise. This is normal. For regular viewing, it is recommended to use other brightness modes.
3. DCI-P3 90% is the color gamut area ratio of DCI-P3 under the CIE 1931 color space. This data is from the XGIMI laboratories. Actual color gamut coverage varies depending on the individual product.
4. The Eye Protection function is disabled in default settings and can be enabled in the system settings.
5. To ensure accurate calibration, the side throw angle should not exceed 25° (degrees). The display quality may vary based on product usage habits and environmental conditions. Due to the complexity of the environment, Uninterrupted Auto Keystone Correction may fail, and manual correction may be required.
6. For the best viewing experience, we recommend using a projection size of 60-120 inches. Exceeding this range may affect the quality of your projected content. The display quality may vary based on product usage habits and environmental conditions.
7. The actual storage capacity is subject to change based on various factors, such as system usage, software version, and settings used.
8. Wi-Fi 5 indicates the version of the wireless network protocol supported by the device, and it can be used with wireless routers and other equipment that support the corresponding protocol version. Network speed is influenced by various factors; please refer to actual conditions for precise performance.
9. The projector's Bluetooth supports connection with mobile phones in Creative Filter and Ambient Light Mode.
10. When using a third-party power bank or adapter, it needs to ensure an output power between 65W and 150W and meet the following power, current, and voltage requirements: 65W at 20V/3.25A, 100W at 20V/5A.

Explore different moods with magnetic creative filters.

FEATURES AND HIGHLIGHTS

- **Built-in Battery:** Enjoy up to 2.5 hours of video playtime (Eco Mode) or up to 6 hours of music playtime. Extend viewing with the optional PowerBase Stand (sold separately).
- **360° Adjustable Stand:** Project from any angle, including wall to ceiling, with ease.
- **ISA Technology:** Features Uninterrupted Auto Keystone Correction, Uninterrupted Auto Focus, and Intelligent Eye Protection for a seamless viewing experience.
- **Powerful Sound:** Equipped with 12W Harman Kardon speakers for deep, cinematic audio.
- **Google TV with Licensed Netflix:** Access 10,000+ apps and 800+ free live channels.
- **Vibrant Visuals:** Delivers sharp 1080P clarity with 450 ISO Lumens of brightness.
- **Portability:** Compact and lightweight (2.9 pounds), designed for easy transport.
- **Connectivity:** Includes HDMI, USB, Wifi 5, and Bluetooth 5.1 for versatile connections.

Your browser does not support the video tag.

Official XGIMI MoGo 4 Portable Projector Video, showcasing its features and portability.

MAINTENANCE

Lens Care

To maintain optimal image quality, regularly clean the projector lens using a soft, lint-free cloth specifically designed for optical surfaces. Avoid abrasive materials or harsh chemicals.

Ventilation

Ensure the projector's ventilation openings are clear and unobstructed to prevent overheating. Do not place the projector on soft surfaces that may block airflow.

Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the lens cap to protect the lens from dust and scratches.

TROUBLESHOOTING

No Image / Dim Image

- Check power connection and ensure the projector is turned on.
- Verify the input source is correctly selected (HDMI, streaming app).
- Ensure the lens is clean and free of obstructions.
- For optimal brightness, use in a dark environment.

No Sound

- Check the volume level on the projector and the connected device.
- Ensure no external audio devices (like Bluetooth speakers) are connected if you intend to use the internal speakers.
- If using HDMI, verify the audio output settings on the source device.

Connectivity Issues (Wi-Fi/Bluetooth)

- Restart the projector and your Wi-Fi router/Bluetooth device.
- Ensure the projector is within range of the Wi-Fi network or Bluetooth device.
- Check Wi-Fi password and network settings.

SPECIFICATIONS

Feature	Detail
Brand	XGIMI
Model Number	WK08K
Item Weight	2.9 pounds
Product Dimensions	3.8 x 3.8 x 8.2 inches
Color	Grey
Display Resolution	1920 x 1080 (1080P)
Brightness	450 ISO Lumens
Connectivity Technology	Bluetooth, Wi-Fi 5, HDMI, USB
Special Features	Auto Focus, 360° Adjustable Stand, Google TV, Licensed Netflix, Harman Kardon Speakers
Recommended Uses	Education, Home Cinema, Gaming, Business

WHAT'S IN THE BOX

- XGIMI MoGo 4 Portable Projector
- Remote Control (Standard Bluetooth)
- Mini Keyring Remote

- Magnetic Sunset Filter
- Power Adapter
- User Manual (this document)

WARRANTY AND SUPPORT

XGIMI offers a 30-day price match guarantee. For any product inquiries, technical support, or warranty claims, please contact XGIMI customer service.

Email: service-usa@xgimi.com

Please refer to the official XGIMI website for the most up-to-date electronic manual and support information.