WolfLawS X1

WolfLawS X1 Wireless Gaming Headset

USER MANUAL

Introduction

Thank you for choosing the WolfLawS X1 Wireless Gaming Headset. This manual provides detailed instructions on how to set up, operate, and troubleshoot your new headset, ensuring an optimal gaming experience across multiple platforms including Xbox, PlayStation 5, PC, Mac, and Nintendo Switch.

What's in the Box

- WolfLawS X1 Wireless Gaming Headset
- USB Transmitter
- Charge Cable
- User Manual



Image: Contents of the WolfLawS X1 Wireless Gaming Headset package, including the headset, USB transmitter, charging cable, and user manual.

Product Overview

Key Features

- **Multi-Platform Compatibility:** Supports 2.4GHz wireless for Xbox controllers (official controllers only), PC, PS5, laptops, Mac, and Nintendo Switch.
- **Superior Sound Quality:** Features 50mm speakers and 3D surround sound for immersive audio.
- **Extended Battery Life:** Up to 40 hours of playtime on a single 2-hour charge.
- **Low Latency:** Less than 20ms latency for instant audio feedback.
- **Noise-Canceling Microphone:** Ensures clear communication with teammates.
- **Comfortable and Durable Design:** Adjustable headband and memory foam ear cushions for long gaming sessions.
- **Convenient Controls:** Easy-to-reach buttons for volume, mic mute, and mode switching.



Image: Detailed view of the headset's easy-to-use function buttons, including the light/wireless/BT mode switch, volume wheel, Type-C charging port, mic mute switch, detachable mic port, and power button.



Image: Illustration highlighting the headset's 1000mAh battery, providing over 40 hours of playtime.




Image: Visual representation of the 50mm precision drivers and 3D surround sound technology for powerful bass.



Image: Close-up of the detachable microphone with noise reduction features, designed to pick up sound clearly.

Setup and Connectivity

Connecting to Xbox Controller (2.4GHz Wireless)

The X1 headset connects directly to official Xbox One/Series X|S controllers via the included USB transmitter. Ensure the transmitter is fully and tightly inserted into the controller's port to avoid noise or connection issues.




Image: Visual guide showing the correct way to plug the dongle into the Xbox controller (fully inserted, no gap) versus an incorrect, loose connection that can cause audio issues.

1. Plug the X1 Transmitter directly into your Xbox Controller. (Note: Only supports official controllers, not 3rd party).
2. While the LEDs of the receiver are flashing, turn the headset power on and keep the headset in 2.4GHz mode.
3. Click the 'Xbox Accessories' option on your Xbox device to connect the headset.
4. Choose the 'Volume' option and enter into the 'Audio and Music' interface to turn the headset volume and mic on. (For first-time use, default system volume might be low; adjust in Settings).

Video: Demonstrates how to correctly connect the X1 dongle to an Xbox controller, ensuring a secure fit for optimal audio performance.

Pairing with PC/PS5 (2.4GHz USB Dongle)

1. Insert the 2.4GHz USB Dongle into a USB port on your PC or PS5.
2. Turn the headset power button on.
3. The indicator light will be white when successfully connected.



Image: Step-by-step visual guide for pairing the headset with PC or PS5 using the 2.4GHz USB dongle, showing the white indicator light upon successful connection.

Pairing with Mac, Tablet, Mobile, and Switch (Bluetooth Mode)

The headset also supports Bluetooth connectivity for devices like Mac, tablets, mobile phones, and Nintendo Switch.

(Note: Bluetooth mode does not support PS4 and PS5).

1. Turn the headset power button on.
2. Hold the mode button for 2 seconds to switch to Bluetooth (BT) mode. The indicator will be blue while pairing.
3. Go to your device's Bluetooth settings and pair with "X1".



Image: Visual instructions for pairing the headset via Bluetooth, showing the blue indicator light during the pairing process and the final connection step on a device.

Troubleshooting

This section addresses common issues you might encounter with your WolfLawS X1 headset.

Video: A comprehensive Q&A video addressing common issues and solutions for the X1 Wireless Gaming Headset.

Q: Why can't I connect the headset with the controller?

A: First, confirm if your headset is in Bluetooth mode. The dongle cannot be connected in Bluetooth mode. Hold down the mode switch button for 2 seconds to switch to 2.4GHz mode (white indicator light).

Q: No sound from the microphone or microphone sound is too low?

A: Confirm the settings on your Xbox console. Ensure the microphone sound is turned up to the maximum in the 'Headset chat mixer' settings. If it's at maximum, adjust the game sound and chat sound to the center to balance them. Also, ensure the detachable microphone is properly plugged into the headset.

Q: Is there an echo from the microphone?

A: Turn off 'Mic monitoring' mode in the Xbox console settings. This feature can sometimes cause an echo.

Q: Why is there a lot of noise?

A: Make sure the transmitter is fully inserted into the controller. If the transmitter is not fully inserted, there will be significant electrical noise in the headset. Ensure there is no gap between the dongle and the controller.

Q: Is the headset volume too low?

A: Make sure the 'Headset Volume' on the Xbox console is set to maximum. When using the headset for the first time, the default volume on the console is 80%, so you may need to manually increase it.

Q: Why can't my teammates hear me?

Q: Why can't my teammates hear me?

A: Confirm whether the microphone is activated on the headset and in your console settings. If activated, please adjust the game sound and chat sound to the center in the 'Headset chat mixer' to ensure proper balance and audibility.

Specifications

Feature	Detail
Model Number	X1
Package Dimensions	8.23 x 8.11 x 3.66 inches
Item Weight	14 ounces
Connectivity	2.4GHz Wireless, Bluetooth
Battery Life	Up to 40 hours
Charging Time	Approx. 2 hours
Latency	<20ms
Speaker Size	50mm
Microphone	Noise-Canceling, Detachable

Warranty and Support

WolfLawS products come with a standard manufacturer's warranty. For detailed warranty information, technical support, or any inquiries not covered in this manual, please refer to the warranty card included in your package or visit the official WolfLawS support website. You can also contact our customer service team through the retailer where you purchased the product.

© 2025 WolfLawS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question