

[Manuals.plus](#) /

> [AMACOOOL](#) /

> AMACOOOL Portable Neck Fan (Model NF001) Instruction Manual

AMACOOOL NF001

AMACOOOL Portable Neck Fan (Model NF001) Instruction Manual

Your guide to operating and maintaining your AMACOOOL Portable Neck Fan.

INTRODUCTION

Thank you for choosing the AMACOOOL Portable Neck Fan. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.



Image: The AMACOOOL Bladeless Neck Fan, highlighting its dual cooling capabilities.

PRODUCT OVERVIEW

The AMACOOOL Portable Neck Fan (Model NF001) is designed to provide personal cooling with both fan and AC modes. It features a bladeless design for safety and comfort, a 5000mAh rechargeable battery for extended use, and an LED display for battery status.

2-IN-1 COOLING REVOLUTION



Image: Illustrates the two cooling modes: AC mode for instant cool down and fan mode for powerful airflow.



Image: Shows the flexible silicone neckband adjusting to fit various neck sizes.

The device incorporates advanced ceramic semiconductor technology for efficient cooling in AC mode and multiple air outlets for comprehensive airflow in fan mode.



SEMICONDUCTOR COOLING PLATES

with **UPGRADED** MOTOR DRIVE

18°C in Just One Second

Image: Close-up of the semiconductor cooling plates, indicating rapid cooling to 18°C.

SIX AIR OUTLETS

with **ALL-AROUND** WIND



Image: Diagram showing the six air outlets providing comprehensive airflow around the neck.

SETUP

1. Charging the Device

Before first use, fully charge the AMACOOOL Portable Neck Fan. Use the provided Type-C cable to connect the device to a compatible USB power source. A full charge typically takes approximately 2 hours.

- The LED display will indicate charging status and battery level.
- Ensure the device is turned off during charging.



Image: Illustrates the 5000mAh battery capacity and Type-C charging port.

2. Wearing the Device

Place the neck fan around your neck. The flexible and non-slip silicone sleeve band is designed to adjust to various neck sizes, ensuring a secure and comfortable fit. The bladeless design prevents hair or beard from getting caught.



Image: Demonstrates the flexibility of the silicone neckband for a stable fit during movement.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Long press the power button. You will hear a "beep" sound, and the fan will start in the first gear speed (fan-only mode).
- **To Power Off:** Long press the power button again.

Modes of Operation

- **Fan Mode:** Activated by a long press of the power button. This mode provides airflow without active cooling.
- **AC Mode (Cooling Mode):** Double press the power button to activate the AC mode. This mode uses ceramic semiconductor technology to provide active cooling to the neck area in addition to the fan.

Adjusting Fan Speed

The device offers 3 adjustable fan speeds: Low, Medium, and High.

- **To Increase Speed:** Short press the + button.
- **To Decrease Speed:** Short press the - button.



Image: Close-up of the control buttons (+ and -) for adjusting fan speed.

LED Display

The integrated LED display shows the remaining battery life, allowing you to monitor power levels at a glance.

A CLEAR LED DISPLAY

See More Intuitively



Image: A clear LED display showing the battery percentage and cooling indicator.

Battery Life Overview

The 5000mAh battery provides varying hours of operation depending on the selected speed and mode:

Mode/Speed	Approximate Battery Life
1st Speed (Fan Only)	17 hours
1st Speed with AC	5 hours
2nd Speed (Fan Only)	8.5 hours
2nd Speed with AC	2.5 hours
3rd Speed (Fan Only)	3 hours
3rd Speed with AC	2 hours



Image: Visual representation of battery life across different fan speeds and cooling modes.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AMACOOOL Portable Neck Fan.

- **Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** When not in use, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to use the provided carrying case for protection.
- **Charging:** To maintain battery health, charge the device regularly, even if not used frequently.



Image: The AMACOOOL Portable Neck Fan, its carrying case, and charging cable, illustrating proper storage.

TROUBLESHOOTING

If you encounter issues with your AMACOOOL Portable Neck Fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully using the provided Type-C cable. Ensure the charging indicator on the LED display is active.
Fan makes a grinding or unusual noise.	Internal fan blade obstruction or damage.	Turn off the device immediately. Do not attempt to open or repair the unit. Contact customer support for assistance.

Problem	Possible Cause	Solution
Cooling plates are not cold in AC mode.	AC mode not activated or device malfunction.	Double press the power button to ensure AC mode is active. Check the LED display for the cooling indicator. If the issue persists, contact customer support.
Short battery life.	High fan speed or continuous AC mode usage.	Battery life varies significantly with speed and mode. Refer to the "Battery Life Overview" table. Reduce fan speed or use fan-only mode for longer duration. Ensure the device is fully charged before use.

If the problem persists after attempting these solutions, please contact AMACOOOL customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	AMACOOOL
Model Number	NF001
Color	Black
Style	AC (Air Conditioner)
Material	Silicone
Number of Speeds	3
Wattage	5 watts
Item Weight	0.83 kg
Indoor/Outdoor Usage	Indoor
Control Method	Touch
Motor Type	Brushless
Installation Type	Wearable



Image: Diagram showing the dimensions of the AMACOOOL Portable Neck Fan.

WARRANTY AND SUPPORT

Specific warranty information and detailed customer support contacts are not provided within this manual. For warranty claims, technical support, or further inquiries, please refer to the official AMACOOOL website or contact the retailer where the product was purchased.

You may also visit the [AMACOOOL Store on Amazon](#) for additional product information and support resources.

IMPORTANT SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep out of reach of children and pets.
- Do not attempt to disassemble, modify, or repair the device yourself. This may void the warranty and pose safety risks.
- Use only the provided charging cable or a certified Type-C cable.
- Avoid blocking the air inlets or outlets during operation to ensure proper airflow and prevent overheating.
- If the device shows signs of damage, overheating, or abnormal operation, discontinue use immediately and contact customer support.

VIDEO DEMONSTRATION

Watch this official video for a visual guide on the AMACOOOL Portable Bladeless AC Neck Fan's features and operation.

Your browser does not support the video tag.

Video: An official demonstration of the AMACOOOL Portable Bladeless AC Neck Fan, showcasing its design and functionality.

© 2026 AMACOOOL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question