



Manuals.plus /

› BLOKEES /

› BLOKEES Transformers Classic Class 18 Shockwave Model Kit Instruction Manual

BLOKEES CC18

BLOKEES Transformers Classic Class 18 Shockwave Model Kit

Model: CC18

1. INTRODUCTION

Thank you for choosing the BLOKEES Transformers Classic Class 18 Shockwave Model Kit. This kit allows you to assemble a highly detailed and articulated figure of Shockwave from Transformers One. Designed for ease of assembly, this model features a luminescent design and dynamic posing capabilities. Please read this manual carefully before beginning assembly and operation to ensure a smooth and enjoyable experience.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years. This product is recommended for ages 12 years and older. Adult supervision is advised during assembly for younger users. Keep all packaging materials away from children.

3. PACKAGE CONTENTS

Your BLOKEES Transformers Classic Class 18 Shockwave Model Kit includes all necessary parts to complete your figure. The kit consists of 86 pieces, along with character-specific weapons and accessories. A detailed assembly instruction booklet is also included in the box.



Image: The product packaging for the BLOKEES Transformers Classic Class Shockwave model kit, showing the assembled figure and key features.

4. ASSEMBLY INSTRUCTIONS

The Shockwave model kit is designed for simple assembly. All 86 pieces easily snap together without the need for

tools, glue, or paint. Please refer to the detailed assembly instructions provided in the box for step-by-step guidance. Ensure all parts are securely connected to prevent detachment.




Image: An assembled BLOKES Shockwave figure highlighting its articulated joints, light-up features, and detailed body sculpt.

The kit includes runners with clearly labeled pieces. Carefully detach each piece from its runner. Some pieces may require gentle twisting or wiggling to remove. Ensure you have all components, including the main body parts, head, limbs, weapons, and any small accessories, before starting assembly.

5. OPERATING INSTRUCTIONS

5.1. Luminescent Feature

The Shockwave figure features light-up eyes and chest. A built-in light module powers this luminescent design. To activate the light-up feature, gently shake the figure. The light module contains one nonstandard battery, which is included and pre-installed.



Image: A close-up of the Shockwave figure, showcasing its illuminated eye and chest, which glow with a menacing purple light.

5.2. Dynamic Posing

The figure boasts 20 points of articulation, including enhanced joints, allowing for a wide range of dynamic combat stances and film-accurate poses. Carefully manipulate the joints to achieve desired positions. Avoid excessive force to prevent damage.

- **Knee Joint:** Bends up to 140 degrees.
- **Hip Joint:** Allows for forward kicks over 90 degrees.
- **Elbow Dual-stage Joint:** Bends over 150 degrees.
- **Shoulder Butterfly Joint:** Provides a 45-degree forward swing.

Your browser does not support the video tag.

Video: An official BLOKEES video showcasing the dynamic posing capabilities and light-up features of the Transformers Classic Class Shockwave figure, along with other figures in the series.

6. MAINTENANCE

To maintain the quality and appearance of your Shockwave figure, follow these guidelines:

- **Cleaning:** Wipe the figure gently with a dry, soft cloth to remove dust. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation or discoloration.
- **Handling:** Handle the figure with care, especially when posing, to avoid stressing joints or detaching parts.
- **Battery Replacement:** The pre-installed battery for the light-up feature is not easily replaceable once the figure is fully assembled. Disassembly for battery replacement may stress chest pieces and details. If battery replacement is necessary, use a part separator and exercise extreme caution.

7. TROUBLESHOOTING

If you encounter any issues with your Shockwave model kit, refer to the following common solutions:

- **Light-up feature not working:** Ensure the figure has been gently shaken to activate the light module. If the light remains off, the pre-installed battery may be depleted. As noted in the maintenance section, battery replacement is challenging due to the assembly design.
- **Parts not fitting securely:** Double-check the assembly instructions to ensure all pieces are oriented correctly and fully snapped into place. Apply gentle, even pressure.
- **Difficulty posing:** Ensure joints are clean and free of debris. If a joint feels stiff, gently work it back and forth. Avoid forcing movements beyond the intended range of articulation.
- **Head detaching easily:** Due to the head shape, it may be prone to detaching during extreme posing. Reattach the head firmly.

8. SPECIFICATIONS

Brand	BLOKEES
Model Name	TF-CC- Shockwave
Model Number	CC18
Toy Figure Type	Action Figure Build Kit
Character	Shockwave
Number of Pieces	86
Item Dimensions (L x W x H)	4.5" x 3.5" x 4.9" (11.43 cm x 8.89 cm x 12.45 cm)
Figure Size	5.5 inches (13.97 cm)
Item Weight	150 Grams
Material Type	Acrylonitrile Butadiene Styrene (ABS) Plastic
Age Range Description	12 Years+
Batteries Required	Yes (1 Nonstandard Battery, included)

9. WARRANTY AND SUPPORT

BLOKEES provides a 30-day warranty against manufacturer defects for this product. If you encounter any issues or require assistance, please contact BLOKEES customer support through the retailer where the product was purchased or visit the official BLOKEES store online for further support options.