

INZOY CP005

INZOY Wingback Pushback Recliner Chair Instruction Manual

Model: CP005 | Brand: INZOY

INTRODUCTION

Thank you for choosing the INZOY Wingback Pushback Recliner Chair. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new recliner. Please read this manual carefully before use to ensure proper function and longevity of your product.



Image: The INZOY Wingback Pushback Recliner Chair, featuring a classic wingback design and white fabric upholstery.

SETUP AND ASSEMBLY

Your INZOY recliner is designed for quick and easy assembly, typically taking less than 10 minutes without the need for additional tools. Follow these steps to set up your chair:

1. Unpack all components from the packaging. Verify that all parts are present according to the enclosed parts list.
2. Carefully attach the backrest to the seat base. Ensure the connection points align and click securely into place.
3. Attach the four legs to the base of the chair. Twist or push them into the designated slots until they are firm.
4. Once assembled, gently rock the chair to ensure stability before use.

Adjust to Fit Your Need

Fully relax your body and better to enjoy your favorite entertainment or rest



Reading



Watching TV



Napping

Image: The recliner mechanism allows for multiple positions, from upright to fully reclined.

OPERATING INSTRUCTIONS

The INZOY Wingback Pushback Recliner Chair features an easy-to-use push-back reclining mechanism. There are two main reclining positions:

- **Upright Position:** The chair is in its standard seating position with the footrest retracted.
- **Reclined Position (up to 160 degrees):** To recline, gently push back on the armrests and lean your body backward. The footrest will extend automatically. To return to the upright position, push down on the footrest with your heels until it locks into place, and lean forward.

This adjustable backrest and footrest system allows for various activities such as reading, watching TV, or napping.



Reading



Watching TV



Napping



Image: Demonstrating the versatility of the recliner for reading, watching TV, and napping.

Comfortable Push Back Chair

Wide soft backrest = perfect for relax your back

Overstuffed cushion = better to support for long time sitting



Image: Key comfort features include a wide soft backrest, overstuffed cushion, and foam-padded footrest.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your INZOY recliner, follow these maintenance guidelines:

- **Regular Cleaning:** Vacuum the fabric regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner specifically designed for upholstery, testing on an inconspicuous area first. Avoid harsh chemicals.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position your chair away from direct sun exposure or use curtains/blinds.
- **Mechanism Check:** Periodically check the reclining mechanism for any loose screws or components. Tighten as necessary. The footrest mechanism is tested for over 10,000 uses, ensuring durability.



Image: The robust footrest mechanism is designed for long-term durability.

TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common solutions:

- **Reclining Mechanism Sticking:** Ensure no objects are obstructing the mechanism under the chair.

Apply a silicone-based lubricant to moving parts if necessary, avoiding contact with fabric.

- **Chair Wobbles:** Check that all legs are securely attached and tightened. Ensure the chair is on a flat, even surface.
- **Fabric Damage/Stains:** Refer to the "Maintenance and Care" section for cleaning instructions. For significant damage, contact customer support.

If the problem persists, please contact INZOY customer service for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	INZOY
Model Name	Push Back Recliner
Model Number	CP005
Color	White
Product Dimensions (Overall)	30"W x 34"D x 41"H
Seat Dimensions	21"W x 21"D x 19"H (Seat Height)
Weight Capacity	350 lbs
Material	High-quality linen fabric, FCS Standard Wood Frame, High Density Sponge
Reclining Angle	Up to 160 degrees

Product Size

Weight Capacity
350LBS



Image: Detailed product dimensions and weight capacity.

Hight Quality Raw Material



Soft Cloth Fabric



FCS Standard Wood Frame



High Density Sponge

Image: Components of the recliner, including fabric, wood frame, and sponge.

WARRANTY AND SUPPORT

INZOY provides a **one-year warranty** for quality issues with your recliner. Additionally, free exchange for damaged or missing accessories is available for items purchased within 1 year.

For any problems, questions, or to claim warranty service, please contact INZOY customer service. We are committed to providing helpful, prompt, and friendly support.

You can visit the official INZOY store for more information and support:

[Visit the INZOY Store on Amazon](#)