

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VASAGLE](#) /

› [VASAGLE UBBC768W01 Storage Cabinet Instruction Manual](#)

## VASAGLE UBBC768W01

# VASAGLE UBBC768W01 Storage Cabinet Instruction Manual

Model: UBBC768W01

[Instructions](#)   [Safety Information](#)   [Maintenance](#)   [Parts List](#)   [Troubleshooting](#)   [Setup & Assembly](#)   [Specifications](#)   [Operating](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

**WARNING:** Always secure the cabinet to the wall using the included anti-tip kit to prevent tipping and potential injury. Failure to do so can result in serious injury or death.

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.
- Assemble on a soft, clean surface to prevent scratches.
- Ensure all connections are tight before use. Periodically check and re-tighten as necessary.
- Do not overload shelves. Refer to specifications for weight limits.
- Use only as intended for storage in appropriate environments (bathroom, living room, kitchen, hallway).

## 2. PARTS LIST

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

# 40+

## Design Awards



Image: Exploded view of the VASAGLE UBBC768W01 storage cabinet components.

### Hardware Components (Illustrative Quantities):

Item	Description	Quantity
A	Cam Lock	16
B	Cam Bolt	16
C	Wood Dowel	20
D	Screw (for hinges)	16
E	Anti-tip kit	1 set
F	Door Handle	4
G	Shelf Pins	8
H	Magnetic Catch	2
I	Drawer Pull	1
J	Hinges	8

Note: Exact quantities for generic items (A, B, C, D, F, G, H, I, J) are illustrative. Refer to your specific packaging for precise counts.

## 3. SETUP & ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

### 3.1 Assembly Video (Generic Example)

Your browser does not support the video tag.

Video: *Generic Bathroom Cabinet Installation Guide*. This video demonstrates general assembly principles for similar furniture. Specific steps may vary.

## 3.2 Step-by-Step Assembly Instructions

### Step 1: Attach Hinges and Handles to Doors

Using screws (D) and hinges (J), attach the hinges to the cabinet doors (parts 18 and 19). Then, attach the door handles (F) to the front of the doors.



Image: Detail of cabinet doors with attached handles.

### Step 2: Assemble Base Frame

Connect the base panels (e.g., parts 1, 2, 3, 4) using cam locks (A) and cam bolts (B) and wood dowels (C). Ensure grooves are aligned for the back panel.

### Step 3: Install Drawer Components

Assemble the drawer box (parts 12, 13, 14, 15) and attach the drawer pull (I) to the front panel (12).



Image: The cabinet's drawer, shown open with various items.

### Step 4: Attach Back Panels

Slide the back panels into the designated grooves on the assembled sections. Secure with small nails if provided.

## Step 5: Combine Upper and Lower Sections

Carefully align and connect the upper and lower cabinet sections. Secure them using the provided fasteners.

## Step 6: Install Adjustable Shelves

Insert shelf pins (G) into the desired holes within the cabinet. Place the adjustable shelves onto the pins. The shelves can be repositioned to accommodate items of various sizes.



Image: Interior view of the cabinet highlighting adjustable shelves and different height configurations.

## Step 7: Install Anti-Tip Kit

Attach the anti-tip kit (E) to the top rear of the cabinet and secure it to a wall stud using appropriate hardware. This is a critical safety step.



Image: Diagram illustrating the correct installation of the anti-tip kit to secure the cabinet to a wall.

## 4. OPERATING INSTRUCTIONS

---

The VASAGLE UBBC768W01 storage cabinet is designed for versatile storage in various rooms.

- **Doors:** Open and close the cabinet doors using the provided handles. The fluted acrylic doors offer a semi-transparent view of contents while maintaining a neat appearance.
- **Drawer:** Pull the drawer open to access its contents. Push it closed until it is flush with the cabinet front.
- **Adjustable Shelves:** To adjust shelf height, remove items from the shelf, lift the shelf, remove the shelf pins, reinsert pins into desired holes, and then replace the shelf. Ensure pins are fully inserted and the shelf is stable before placing items.
- **Weight Distribution:** Distribute weight evenly across shelves and within compartments. Avoid placing heavy items on the top shelves to maintain stability.



Image: Detail of the fluted acrylic doors, providing a stylish and semi-transparent view.

## 5. MAINTENANCE

---

Regular maintenance will help prolong the life and appearance of your storage cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the MDF material.
- **Hardware:** Periodically check all screws, bolts, and connections to ensure they remain tight. Re-tighten as needed.
- **Environment:** Avoid exposing the cabinet to excessive moisture or direct sunlight, which can cause warping or

fading.

## 6. TROUBLESHOOTING

If you encounter any issues with your VASAGLE storage cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly/unstable	Loose connections; uneven floor; anti-tip kit not installed.	Ensure all cam locks and bolts are tightened. Place shims under the base if the floor is uneven. Install the anti-tip kit as per instructions.
Doors do not close properly	Misaligned hinges; loose hinge screws.	Adjust hinge screws to align doors. Ensure magnetic catches are properly installed and aligned.
Drawer sticks or does not slide smoothly	Improper assembly of drawer slides (if applicable); debris in tracks.	Recheck drawer assembly steps. Clear any debris from drawer tracks.
Shelves are not level	Shelf pins not fully inserted or unevenly placed.	Ensure all shelf pins are fully inserted into corresponding holes at the same height.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	UBBC768W01
Brand	VASAGLE
Material	MDF (Medium Density Fiberboard), Acrylic
Color	Cloud White
Product Dimensions	30D x 170W x 60H Centimetres (11.8"D x 23.6"W x 66.9"H)
Item Weight	26 kg (57 lbs)
Weight Limit (Top Shelf)	15 kg (33 lbs)
Weight Limit (Adjustable Shelf)	10 kg (22 lbs)
Weight Limit (Bottom Cabinet)	20 kg (44 lbs)
Special Features	Adjustable Shelves, Easy to Clean, Anti-tip Kit Included
Recommended Uses	Storage and Organization in Bathroom, Kitchen, Laundry Room, Hallway




Image: Detailed dimensions and weight capacity information for the storage cabinet.

## 8. WARRANTY & SUPPORT

This product is eligible for return, refund, or replacement within 30 days of receipt. For any questions, missing parts, or assistance, please contact VASAGLE customer support.

- **Customer Support:** Refer to your purchase documentation or the seller's website for contact information.
- **Returns/Refunds:** Please retain all packaging and proof of purchase for any return or refund requests.