

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [DID A R](#) /
- › [DID A R 2025 Blu-ray Player Model RM Instruction Manual](#)

## DID A R RM

# DID A R 2025 Blu-ray Player Model RM Instruction Manual

Comprehensive Guide for Setup, Operation, and Maintenance

## INTRODUCTION

---

This manual provides essential information for the setup, operation, and maintenance of your DID A R 2025 Blu-ray Player Model RM. Please read it thoroughly before use to ensure optimal performance and longevity of your device. This player supports Blu-ray discs (Region A1) and all DVD regions (PAL), offering versatile media compatibility for your home entertainment needs.

## WHAT'S IN THE BOX

---

- DID A R 2025 Blu-ray Player Model RM
- Remote Control
- HDMI Cable
- AV Cable



Figure 1: Contents of the DID A R 2025 Blu-ray Player package. The image displays the player unit, remote control, HDMI cable, and AV cable.


## PRODUCT OVERVIEW

The DID A R 2025 Blu-ray Player Model RM is engineered for a superior viewing and listening experience. It outputs video in crisp 1080p resolution and supports Dolby Audio/DTS for rich, immersive sound. The player's retro design, featuring a wood-grain aesthetic, allows it to blend seamlessly with various home decor styles. It also includes a USB port for playing media from external storage devices.



Figure 2: The Blu-ray player showcasing its top-loading disc mechanism and retro design on a wooden surface.

# 1080p HD Display & Dolby sound effects



DVD Region Free

## Supports Blu ray discs

DVD Video/DVD+R/DVD+RW/VCD  
Xvid /CD/CD-R/CD-RW/MP3/WMA

Figure 3: Visual comparison of 1080p versus 720p resolution, highlighting the player's superior picture quality. Supported media types such as Blu-ray, DVD, CD, MP3, and WMA are also listed.

Your browser does not support the video tag.

Video 1: An overview of the 2025 New Model Blu-ray Player, demonstrating its features and design.

## SETUP

### Connecting to a Television

1. Connect one end of the provided HDMI cable to the **HDMI OUT** port on the back of the Blu-ray player.
2. Connect the other end of the HDMI cable to an available HDMI input on your television.
3. For older televisions, use the provided AV cable. Connect the colored plugs (yellow for video, red for right audio, white for left audio) to the corresponding input jacks on your television.
4. Connect the power adapter to the **DC IN 12V** port on the back of the player and then plug it into a power outlet.
5. Turn on your television and select the correct HDMI or AV input source using your TV's remote control.



Figure 4: Detailed view of the rear panel connections, including HDMI OUT, LAN (100), DC IN 12V, and Digital Out (Coaxial)

ports.

## Network Connection

For internet-enabled features, connect an Ethernet cable to the **LAN (100)** port on the back of the player. Alternatively, the player may support wireless LAN connectivity; refer to the on-screen network settings for configuration.

Your browser does not support the video tag.

*Video 2: A short demonstration highlighting the compact size and easy setup process of the Blu-ray player.*

Your browser does not support the video tag.

*Video 3: This video illustrates the effortless setup and overall quality of the Blu-ray player.*

## OPERATING INSTRUCTIONS

---

### Loading a Disc

1. Gently lift the disc cover on the top of the player.
2. Place the Blu-ray or DVD disc onto the spindle with the label side facing up.
3. Close the disc cover. The player will automatically begin reading the disc.



Figure 5: Demonstrating the top-loading disc mechanism. The disc cover is open, and a disc is being inserted.

## Using the Remote Control

The included remote control allows full functionality of the Blu-ray player. Insert two AAA batteries (not included) into the remote. Use the directional buttons to navigate menus, the **OK** button to confirm selections, and the **Play/Pause**, **Stop**, **Fast Forward**, and **Rewind** buttons for media control. Dedicated buttons for **Home**, **Netflix**, and other functions are also available.



*Figure 6: The remote control, detailing its layout with playback, navigation, and dedicated function buttons.*

## USB Playback

Insert a USB flash drive into the **USB** port on the front of the player. The player will detect the device and allow you to browse and play compatible media files (e.g., MP3, WMA, Xvid). Ensure your USB device is formatted to a compatible file system (e.g., FAT32).

## MAINTENANCE

---

- Keep the player clean by wiping it with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- Ensure proper ventilation around the player to prevent overheating. Do not block any ventilation openings.
- Handle discs by their edges to prevent scratches and smudges. Store discs in their cases when not in use.

## TROUBLESHOOTING

Problem	Solution
No picture or sound	Check HDMI/AV cable connections. Ensure the correct input source is selected on your TV. Verify power connection to the player and outlet.
Disc not playing	Ensure the disc is clean and free of scratches. Verify the disc is placed correctly in the tray. Try a different disc to rule out disc-specific issues.
Remote control not working	Check and replace batteries in the remote. Ensure there are no obstructions between the remote and the player's sensor.
Player freezes or becomes unresponsive	Unplug the player from the power outlet, wait 30 seconds, then plug it back in and restart the device.
Cannot connect to network	Check LAN cable connection if using wired. Verify network settings in the player's menu. Restart your router and modem.
Poor picture quality	Ensure you are using an HDMI cable for optimal 1080p resolution. Check your TV's display settings for picture mode and resolution.

## SPECIFICATIONS

- **Brand:** DID A R
- **Model Name:** RM
- **Media Type:** Blu-Ray Disc, DVD Video
- **Special Feature:** Surround Sound
- **Resolution:** 1920 x 1080 pixels (1080p)
- **Connector Type:** HDMI, AV
- **Connectivity Technology:** HDMI, LAN (100)
- **Audio Output Mode:** Surround
- **Item Weight:** 0.98 Kilograms (2.16 pounds)
- **Package Dimensions:** 12.56 x 8.86 x 2.91 inches
- **Included Components:** Blu Ray Player, Remote Control, HDMI Cable, AV Cable

## WARRANTY AND SUPPORT

The DID A R Blu-ray Player Model RM includes a 3-year warranty, providing assurance for your purchase. For technical support, troubleshooting assistance, or to initiate a warranty claim, please refer to the contact information detailed in your product packaging or visit the official DID A R support website. Additional

extended protection plans are available for purchase to further safeguard your investment:

- **2-Year Protection Plan:** \$9.99
- **3-Year Protection Plan:** \$13.49
- **Complete Protect:** \$16.99/month (covers all eligible past and future purchases)

© 2025 DID A R. All rights reserved.