

[manuals.plus](#) /› [Mixcous](#) /› [Mixcous 9-Drawer Dresser \(Model CD-5741438\) Instruction Manual](#)

Mixcous CD-5741438

Mixcous 9-Drawer Dresser Instruction Manual

Model: CD-5741438

Brand: Mixcous

1. INTRODUCTION

Thank you for choosing the Mixcous 9-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

This dresser is designed to provide ample storage and complement various interior styles. Ensure all safety guidelines are followed to prevent injury or damage.

2. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Drawer dresser components
- Installation instructions
- Hardware (screws, dowels, cam locks, etc.)

3. SETUP & ASSEMBLY

Assembly is required for this dresser. It is recommended to have two adults for assembly. Please follow the included step-by-step instructions carefully. Lay out all parts on a soft, clean surface to prevent scratches.



Figure 3.1: Overview of the assembly process.

Ensure all connections are secure but do not overtighten screws, which could damage the wood. The assembly process typically involves:

1. Attaching the side panels to the base.
2. Installing drawer slides on the main frame.
3. Assembling each drawer box.
4. Attaching drawer fronts and handles.
5. Inserting assembled drawers into the frame.
6. Securing the top panel.

Refer to the detailed diagram in your included instruction booklet for specific part identification and step-by-step guidance.

4. OPERATING INSTRUCTIONS

The Mixcos 9-Drawer Dresser features nine spacious drawers designed for smooth operation. Each drawer is equipped with a handle for easy opening and closing.



Figure 4.1: Mixcous 9-Drawer Dresser in a room setting.

- **Drawer Usage:** Gently pull the handles to open drawers and push them firmly to close. Avoid forcing drawers if they feel stiff; check for obstructions.
- **Storage Capacity:** The deep drawers provide ample space for clothing, linens, and other household essentials.
- **Top Surface:** The sturdy top surface can be used to display decorative items, lamps, or other personal belongings. Ensure items placed on top do not exceed the weight capacity of the dresser.



Figure 4.2: Illustration of drawer depth and storage potential.

5. MAINTENANCE & CARE

To ensure the longevity and appearance of your dresser, follow these care instructions:

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately blot any spills with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If they become stiff, a small amount of silicone lubricant can be applied.

6. SAFETY INFORMATION

Your safety is important. Please adhere to the following safety guidelines:

- **Anti-Tipping Device:** This dresser includes an anti-tipping device. It is crucial to install this device and secure the dresser to a wall to prevent accidental tipping, especially in households with children or pets. Failure to do so can result in serious injury or death.

Spacious Storage for Every Room



High Quality



Enduring



Multifunctional



Figure 6.1: Anti-tipping device installation for enhanced safety.

- **Weight Distribution:** Distribute weight evenly across drawers and on the top surface. Avoid placing heavy items in only one drawer, which can affect stability.
- **Children:** Do not allow children to climb on or play with the dresser. Keep heavy items in lower drawers.
- **Moving:** When moving the dresser, empty all drawers first. Lift the unit rather than dragging it to prevent damage to the legs or frame.

7. TROUBLESHOOTING

If you encounter any issues during or after assembly, consider the following common solutions:

- **Missing Parts:** Double-check the packaging and the parts list. If parts are genuinely missing, contact customer support.
- **Misaligned Holes:** Ensure all pieces are oriented correctly according to the diagrams. Sometimes, a slight adjustment or loosening of adjacent screws can help align holes.
- **Drawers Not Sliding Smoothly:** Verify that drawer slides are installed correctly and are not bent. Ensure the drawer box is assembled squarely.
- **Wobbling:** Check that all screws and fasteners are tightened. Ensure the dresser is placed on a level surface. If necessary, use furniture levelers.

For persistent issues, please refer to the support section of this manual.


8. SPECIFICATIONS

Feature	Detail
Brand	Mixcous
Model Name	drawer dresser
Item Model Number	CD-5741438
Product Dimensions	15.55"D x 63"W x 30.31"H
Color	Black
Material Type	Engineered Wood
Number Of Items	1
Item Weight	134 pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Additional Product Features	Rust Resistant, Scratch Resistant, Soft Close, Space Saving

9. WARRANTY & SUPPORT

Mixcous stands behind the quality of its products. For any questions, concerns, or assistance with your 9-Drawer Dresser, please contact our customer support team. Our representatives are available to help you before or after your purchase.

Please retain your proof of purchase for any warranty claims. Specific warranty details may be provided with your product packaging.

	<p>Reibii Bed Frame Assembly Instructions - Model CD-SBF-2BE-Q-DL</p> <p>Comprehensive assembly guide for the Reibii bed frame, model CD-SBF-2BE-Q-DL, featuring two storage drawers. This document provides detailed step-by-step instructions, a complete parts list, and essential assembly tips for a smooth setup.</p>
 User Manual	<p>MangoKit CD-X Portable CD Player User Manual - Features, Operation & Troubleshooting</p> <p>Comprehensive user manual for the MangoKit CD-X Portable CD Player. Learn about its features, basic operations, connectivity options (Bluetooth, AUX), FM radio, programming, troubleshooting, safety instructions, and technical specifications.</p>
	<p>Panduit CD-920 Series Crimp Die Measurement Instructions</p> <p>Detailed instructions for measuring Panduit CD-920 series raised and recessed style crimp dies, including step-by-step guidance and a comprehensive table of part numbers, color codes, index numbers, and diameter ranges.</p>
	<p>MONODEAL Portable CD Player User Manual</p> <p>User manual for the MONODEAL portable CD player, detailing functions, operation, FAQs, and specifications. Supports CD, CD-R, CD-RW, MP3, and WMA formats.</p>
	<p>DVD Player Operation and Features</p> <p>A comprehensive guide to operating the DVD player, including disc insertion, playback controls, menu navigation, special features like subtitles and angles, and screen format settings.</p>
	<p>Arafuna Portable CD Player User Manual - Bluetooth, FM Radio, AUX</p> <p>Comprehensive user manual for the Arafuna Portable CD Player. Learn about setup, playback, Bluetooth connectivity, FM transmission, troubleshooting, and specifications.</p>