

## LVYUAN F-1600P

# LVYUAN 1600W Pure Sine Wave Power Inverter (Model F-1600P) User Manual

Model: F-1600P | Brand: LVYUAN

## 1. INTRODUCTION AND OVERVIEW

---

The LVYUAN 1600W Pure Sine Wave Power Inverter is designed to efficiently convert 12V DC power from a battery source into 120V AC power, suitable for a wide range of applications including vehicles, RVs, and off-grid solar systems. It provides 1600W of continuous power and can handle surge power up to 3000W, making it capable of powering various electronic devices and small appliances. This inverter features four US-standard 120V AC outlets and four USB ports for versatile connectivity. Its pure sine wave output ensures compatibility with sensitive electronics, minimizing interference and promoting stable operation. An integrated LCD display provides real-time information on battery voltage, output voltage, and load status, while a remote control offers convenient power management.

## 2. WHAT'S IN THE BOX

---

- 1 x LVYUAN 1600W 12V Pure Sine Wave Power Inverter
- 2 x Car Inverter Cables (Red for positive, Black for negative)
- 6 x Extra Charger Adapter Fuses (Fuses are pre-installed)
- 1 x Car Outlet Adapter Remote Controller
- 1 x Car Power Inverter User Manual

## 3. PRODUCT FEATURES AND COMPONENTS

---

# High-efficiency Cooling **Ultra-quiet**

**smart automatic  
start and stop**

**Surge mode  
Under 60dB**

40dB 50dB 60dB 70dB



**Front Panel:** Features four AC output sockets, four USB 5V output ports, an ON/OFF switch, and a remote control port.

# Utilize The Inverter to The Fullest!

## Lean, Safe, Reliable



\*Devices with surge power over 3000W might fail to initiate operation.

**Rear Panel:** Equipped with positive (+) and negative (-) DC 12V input terminals and dual cooling fans for heat dissipation.



**Easy Installation, Intuitive Operation,  
Adaptable Convenience.**



**20W Type-C +  
5V 3.1A USB**



**Intelligent LCD Display:** Shows input voltage, output voltage, battery level, and load status for easy monitoring.



**Wireless Control for Convenience**

**Wireless Remote Control:** Allows convenient power on/off operation from a distance.



**Built to thrive where  
the extremes begin.**

**-5°F**

**104°F**

**Durable Construction:** Designed to withstand various environmental conditions, ensuring reliable performance.

## 4. SETUP INSTRUCTIONS

1. **Prepare the Inverter:** Ensure the inverter's main power switch is in the 'OFF' position before making any connections.
2. **Connect Battery Cables to Inverter:**

- Attach the red (positive) cable to the positive (+) terminal on the inverter. Secure the connection by rotating the knob until it is fully tightened.
- Attach the black (negative) cable to the negative (-) terminal on the inverter. Secure the connection by rotating the knob until it is fully tightened.

### 3. Connect Battery Cables to Power Source:

- Connect the other end of the red (positive) cable to the positive (+) terminal of your 12V DC battery.
- Connect the other end of the black (negative) cable to the negative (-) terminal of your 12V DC battery.

**Important:** Always connect the positive terminal first, then the negative terminal, to prevent sparks. Ensure all connections are tight and secure.

4. **Grounding:** Connect the inverter's grounding terminal to a proper earth ground. This is crucial for safety.
5. **Initial Power On:** Once all connections are secure, switch the inverter's main power switch to the 'ON' position. The LCD display should illuminate, showing battery voltage and output voltage.

Your browser does not support the video tag.

**Video:** Demonstrates the connection process of the inverter to a battery and initial power-on. This video also shows various devices being powered by the inverter.

## 5. OPERATING INSTRUCTIONS

---

1. **Powering On/Off:** The inverter can be turned on or off using the main switch on the front panel or via the included wireless remote control. Ensure the remote switch is set to 'REMOTE' if using the remote.
2. **Connecting Devices:** Plug your AC-powered devices into the 120V AC outlets. For USB-powered devices, use the 5V USB ports.
3. **Monitoring Performance:** The LCD display provides continuous feedback:
  - **Battery Voltage:** Indicates the current voltage of your 12V DC power source.
  - **Output Voltage:** Shows the stable 120V AC output.
  - **Load Indicator:** Displays the percentage of the inverter's capacity being used.
  - **Frequency:** Default 60Hz, not adjustable.
4. **Pure Sine Wave Output:** This inverter produces a pure sine wave output, which is identical to grid power. This makes it safe for powering sensitive electronics such as laptops, medical equipment, and audio systems without risk of damage or malfunction.
5. **Cooling System:** The inverter features an intelligent cooling fan system that activates automatically based on internal temperature and load, ensuring optimal performance and preventing overheating.

## 6. MAINTENANCE

---

- **Regular Cleaning:** Keep the inverter clean and free from dust and debris, especially around the cooling vents, to ensure proper airflow.
- **Check Connections:** Periodically inspect all cable connections to the inverter and battery to ensure they remain tight and free from corrosion. Loose connections can lead to power loss or overheating.
- **Storage:** When not in use for extended periods, store the inverter in a cool, dry place away from direct sunlight and moisture.
- **Fuse Replacement:** If a fuse blows, replace it with an identical type and amperage rating. Refer to the specifications for correct fuse types.

## 7. TROUBLESHOOTING

---

The inverter's LCD display can assist in diagnosing issues by indicating specific protection modes. Below are common questions and general troubleshooting steps:

- **Does the power inverter drain the vehicle's battery?**

Yes, power inverters draw power from the battery. Many inverters will emit a low-power alert or shut down automatically to prevent complete battery discharge. If planning to use a larger battery-powered inverter, confirm your vehicle's electrical system can support it. Consulting a professional is recommended.

- **How long will it take a power inverter to drain a car battery?**

With a small inverter powering a low load like a laptop, you typically get 30–60 minutes before the battery drains, depending on battery condition and draw. Leaving the vehicle running is the safest option for extended use.

- **What to do if the vehicle's fuse blows?**

If the 12-volt accessory fuse blows, check the owner's manual to locate the correct fuse box. Remove the fuse, inspect it for a broken or burnt element, and replace it with one of the same amperage rating.

- **Inverter not turning on:** Check all battery connections for tightness. Ensure the battery has sufficient charge (above 12V). Verify the main power switch is in the 'ON' position.

- **No AC output:** Check if the connected device is within the inverter's wattage limits. Disconnect and reconnect the device. If the inverter indicates an overload, reduce the connected load.

- **Overheating:** Ensure the inverter is in a well-ventilated area. Clear any obstructions from the cooling fans. Reduce the load if the inverter consistently runs hot.

## 8. SPECIFICATIONS

Feature	Specification
Brand	LVYUAN
Model Name	LVYUAN 3000W Peak Power (F-1600P)
Wattage (Continuous)	1600 Watts
Peak Output Power	3000 Watts
Input Voltage	12 Volts (DC)
Output Voltage	120 Volts (AC)
Electrical Output Waveform	Pure Sine Wave
Frequency	60 Hz
Display Type	LCD
Recommended Uses	Office, RV, Vehicle, Off-Grid Solar
Item Dimensions (L x W x H)	11.4"L x 6.3"W x 3.9"H
Power Source	Solar and Battery Powered
Standby Power Shutoff	90%
Color	Green

## 9. SAFETY INFORMATION

- **Ventilation:** Ensure adequate ventilation around the inverter to prevent overheating. Do not block cooling vents.
- **Moisture:** Keep the inverter away from water, rain, and excessive moisture.
- **Flammable Materials:** Do not operate the inverter near flammable liquids, gases, or other combustible materials.
- **Proper Grounding:** Always ensure the inverter is properly grounded as per the setup instructions.
- **Overload Protection:** Avoid exceeding the inverter's continuous or peak wattage ratings to prevent damage to the unit and connected devices.
- **Children and Pets:** Keep the inverter out of reach of children and pets.

## 10. WARRANTY AND SUPPORT

---

The LVYUAN 1600W Pure Sine Wave Power Inverter comes with a **2-Year Manufacturer Warranty**. For technical support, warranty claims, or any inquiries, please contact Guangzhou LVYUAN Technology Co., Ltd., the manufacturer.