

[Manuals.plus](#) /

› [Veemoon](#) /

› Veemoon Paper Dispenser Lock Key Replacement User Manual

Veemoon LEQ36Z0P23Y059LX7A42

Veemoon Paper Dispenser Lock Key Replacement Manual

Model: LEQ36Z0P23Y059LX7A42

1. INTRODUCTION

This manual provides comprehensive instructions for the Veemoon Paper Dispenser Lock Key Replacement. This key is designed to provide convenient and efficient access to various commercial toilet paper and paper towel dispensers, ensuring easy replacement of empty rolls and streamlined restroom maintenance.



Figure 1.1: Veemoon Paper Dispenser Lock Key

This image displays the Veemoon Paper Dispenser Lock Key, a compact black accessory with a rounded top and a square-shaped base designed for dispenser locks.

2. PRODUCT OVERVIEW

The Veemoon replacement key is a compact and durable accessory essential for managing restroom supplies. It is specifically engineered to unlock compatible paper and tissue dispensers, facilitating quick and easy access for refilling and maintenance.

Key Features:

- **Effortless Access:** Designed for easy insertion and turning to unlock various dispenser types.
- **Compact and Handy:** Its small size allows for easy storage, whether hung on a wall or attached to a keychain, ensuring it is always within reach.
- **Durable Material:** Constructed from high-quality Acrylonitrile Butadiene Styrene (ABS) for long-lasting performance and resistance to wear.
- **Versatile Compatibility:** Compatible with a wide range of commercial roll paper dispensers that utilize a square-shaped lock mechanism.

Package Contents:

- 1 x Veemoon Paper Dispenser Lock Key



Figure 2.1: Key Features Detail

This image provides a close-up view of the key, highlighting its smooth finish, the small circular hole for attachment, and the square-shaped opening at its base, which is the functional part for unlocking dispensers.

3. SPECIFICATIONS

Attribute	Value
Brand	Veemoon
Model Number	LEQ36Z0P23Y059LX7A42
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Dimensions (L x W x H)	1.26 x 1.02 x 0.99 inches (3.20 x 2.60 x 2.51 cm)
Item Weight	0.16 ounces (4.54 g)

Attribute	Value
Country of Origin	China



Figure 3.1: Key Dimensions

This image illustrates the precise dimensions of the Veemoon key, showing its length as 3.2 cm (1.26 inches) and width as 2.6 cm (1.0 inch).

4. SETUP

The Veemoon Paper Dispenser Lock Key is a standalone tool and does not require any assembly or installation. It is ready for use directly out of the package.

5. OPERATING INSTRUCTIONS

To open a compatible paper dispenser, follow these steps:

1. Locate the lock mechanism on your paper dispenser. This is typically a small, square-shaped opening.
2. Insert the square end of the Veemoon key into the lock mechanism. Ensure it is fully inserted.
3. Gently turn the key clockwise or counter-clockwise (depending on the dispenser's lock) to unlock the

dispenser. You may hear a click as the lock disengages.

4. Once unlocked, open the dispenser door to replace or refill paper rolls.
5. After refilling, close the dispenser door and turn the key in the opposite direction to securely lock it. Remove the key.



Figure 5.1: Key in Use with a White Dispenser

This image shows a hand inserting the Veemoon key into the lock of a white wall-mounted paper towel dispenser.



Figure 5.2: Key in Use with a Silver Dispenser

This image depicts the Veemoon key inserted into the lock mechanism of a silver, wall-mounted paper towel dispenser.



Figure 5.3: Key in Use with a Round Toilet Paper Dispenser

This image shows the Veemoon key inserted into the lock of a round, wall-mounted toilet paper dispenser.

6. MAINTENANCE

The Veemoon key requires minimal maintenance to ensure its longevity and proper function.

- **Cleaning:** Keep the key clean and free from dust, dirt, or any debris that might accumulate in the square opening. A soft, dry cloth can be used for cleaning.
- **Storage:** Store the key in a dry place, away from extreme temperatures or direct sunlight, to prevent any potential material degradation over time.

7. TROUBLESHOOTING

If you encounter any issues while using your Veemoon Paper Dispenser Lock Key, please refer to the following common problems and solutions:

- **Key does not turn in lock:**
 - Ensure the key is fully inserted into the lock mechanism.
 - Check for any visible obstructions or foreign objects inside the dispenser's lock.

- Verify that the dispenser lock is compatible with this specific key type. This key is designed for square-shaped lock mechanisms.
- **Lost or misplaced key:**
 - This product is specifically designed as a replacement for lost or misplaced original keys. If this replacement key is lost, another replacement will be required. Consider attaching it to a keychain for easier tracking.

8. WARRANTY AND SUPPORT

For information regarding product warranty, return policies, or technical support, please refer to the purchase documentation provided by your retailer. You may also contact Veemoon customer service through the platform or store where the product was originally purchased for assistance.