



---

[Manuals.plus](#) /

› [Disney Store](#) /

› Disney Store Official Princess Micro Toy Set – Frozen: Instruction Manual

## Disney Store Frozen

# Disney Store Official Princess Micro Toy Set – Frozen: Instruction Manual

Model: Frozen Castle Playset

## 1. PRODUCT OVERVIEW

---

This instruction manual provides essential information for the Disney Store Official Princess Micro Toy Set – Frozen. This portable playset allows for imaginative play with micro figures of Elsa, Anna, and Olaf within a miniature Arendelle Castle.



Image 1.1: The Arendelle Castle Micro Playset in its closed, portable form, featuring a glittery blue handle for easy transport.

The set is part of the Disney Once Upon a Story Collection, celebrating the 2013 film, Frozen. It includes the Arendelle Castle playset, micro figures, and various miniature accessories for an immersive play experience.

## 2. SETUP

### 2.1 Unboxing the Playset

Carefully remove all components from the packaging. Ensure all figures and accessories are accounted for. Retain packaging for future reference or disposal.



Image 2.1: The playset as it appears in its original packaging, displaying the castle and included accessories.

## 2.2 Opening the Castle

To open the Arendelle Castle playset, locate the latch mechanism on the side or back of the castle. Gently unlatch and unfold the castle to reveal the interior play areas. The castle is designed to open into a two-story play space.



Image 2.2: The playset opened, showcasing the interior rooms and some of the micro figures and accessories in place.

### 2.3 Arranging Figures and Accessories

The set includes micro figures of Elsa, Anna, and Olaf, along with various accessories such as beds, an oven, and a mixing bowl. Place these items within the castle's interior to create different scenes and scenarios. The figures and accessories are designed to fit within the designated spaces.



Image 2.3: A complete view of all included figures and accessories, ready for arrangement within the playset.

### 3. OPERATING THE PLAYSET

#### 3.1 Interactive Play

Engage in imaginative play by moving the Elsa, Anna, and Olaf micro figures throughout the castle. Utilize the miniature furniture and accessories to create various scenes from the Frozen story or invent new adventures.



Image 3.1: An example of interactive play with the open castle, figures, and accessories.

### 3.2 Portable Design

The playset features a translucent, glitter-infused carry handle, making it easy to transport. When play is complete, ensure all micro figures and accessories are stored securely inside the closed castle to prevent loss. The castle's design allows for compact storage and travel.



Image 3.2: The back of the closed playset, demonstrating its compact and travel-friendly form.

### 3.3 Opening and Closing the Castle Door

The front door of the Arendelle Castle can be opened and closed to allow figures to enter and exit the playset. Gently push or pull the door to operate it.



Image 3.3: A detailed view of the castle's front door.

## 4. MAINTENANCE

---

### 4.1 Cleaning Instructions

To clean the playset and figures, wipe them gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the product's finish or paint. Ensure all parts are dry before storing.

### 4.2 Storage

When not in use, store the playset in its closed position with all figures and accessories securely inside. Keep the set in a cool, dry place away from direct sunlight to prevent material degradation.

## 5. TROUBLESHOOTING

---

### 5.1 Missing Pieces

Due to the micro size of the figures and accessories, it is important to keep track of all components during and after play. If a piece is misplaced, carefully check the play area and storage compartments. Replacement parts are generally not available for micro playsets.

## 5.2 Difficulty Opening/Closing

If the castle is difficult to open or close, ensure no figures or accessories are obstructing the hinges or latch mechanism. Apply gentle, even pressure when opening and closing the playset.

## 6. SPECIFICATIONS

---

- **Brand:** Disney Store
- **Model:** Frozen Castle Playset
- **ASIN:** B0F3F8WF49
- **Manufacturer:** Disney
- **Package Dimensions:** 11.02 x 7.6 x 3.66 inches
- **Item Weight:** 12.6 ounces
- **Recommended Age:** 3 years and up

## 7. WARRANTY AND SUPPORT

---

Specific warranty information for the Disney Store Official Princess Micro Toy Set – Frozen is not provided in this manual. For any warranty claims or product support, please refer to the original purchase documentation or contact Disney Store customer service directly.