

Best Choice Products SKY9687

Best Choice Products 8-Person Outdoor Picnic Table Instruction Manual

Model: SKY9687

1. INTRODUCTION

Thank you for choosing the Best Choice Products 8-Person Outdoor Picnic Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new picnic table. Please read these instructions thoroughly before assembly and retain them for future reference.

This outdoor picnic table is designed for comfortable seating of up to 8 individuals, featuring a circular tabletop with built-in benches and an umbrella hole for shade. Its durable construction is suitable for various outdoor environments.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always assemble the product on a flat, stable surface.
- Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity: 500 lbs per seat, 300 lbs for the tabletop.
- When using an umbrella, ensure it is properly secured in the umbrella hole and an appropriate base weight is used to prevent tipping in windy conditions.
- Keep children away from the assembly area. Small parts may pose a choking hazard.
- This product is intended for outdoor use only.
- Do not stand on the table or benches.
- Inspect the table regularly for any signs of wear, damage, or loose components. Discontinue use if damage is found.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Circular Tabletop Sections
- Bench Sections (4)
- Steel Frame Components
- Hardware Pack (bolts, washers, nuts, adjustable anchor screw)
- Assembly Guide

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two adults for assembly. A screwdriver is the recommended tool for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Tabletop:** Connect the circular tabletop sections according to the provided assembly guide. Ensure they are aligned correctly.
3. **Attach Frame to Tabletop:** Secure the main steel frame to the underside of the tabletop using the provided bolts and fasteners. Do not fully tighten all bolts until the entire frame is assembled.
4. **Attach Benches:** Connect the four bench sections to the steel frame. Ensure each bench is oriented correctly for seating.
5. **Install Rubber Feet:** Attach the sixteen slip-resistant rubber feet to the bottom of the frame legs for stability and floor protection.
6. **Final Tightening:** Once all components are in place, systematically tighten all bolts and fasteners. Do not overtighten.
7. **Check Stability:** Gently rock the table to ensure it is stable and all connections are secure.

Tabletop max weight:
300lbs

Bench max weight:
500lbs




Image 4.1: Product dimensions and weight capacities.

Maximum Stability



Adjustable
Anchor Screw



16 Slip
Resistant Feet

Image 4.2: Details of the adjustable anchor screw and slip-resistant feet for maximum stability.

5. OPERATING INSTRUCTIONS

5.1 General Use

This picnic table is designed for dining and social gatherings in outdoor settings such as yards, patios, and poolside areas. The circular design and built-in benches accommodate up to 8 people comfortably.



Image 5.1: The 8-person seating capacity of the picnic table.



Image 5.2: The picnic table is suitable for various outdoor entertainment settings.

5.2 Umbrella Usage

The tabletop features a 1.9-inch diameter umbrella hole in the center. To use an outdoor umbrella:

1. Insert the umbrella pole through the hole in the tabletop.
2. Ensure the umbrella pole extends through the frame's umbrella support.
3. Tighten the adjustable anchor screw on the frame to secure the umbrella pole in place.
4. Always use a suitable umbrella base weight (sold separately) to provide additional stability, especially in windy conditions.

Pair with a BCP Umbrella and Base



Image 5.3: Proper setup with an umbrella and base.

6. MAINTENANCE

6.1 Cleaning

The high-density plastic tabletop and benches are designed for easy cleaning. Use a soft cloth with mild soap and water to wipe down surfaces. Rinse thoroughly and dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the material.



Image 6.1: The table's easy-to-clean surface and umbrella cutout.

6.2 Storage and Protection

While designed for all-weather use, extending the lifespan of your picnic table can be achieved by covering it during prolonged periods of non-use or extreme weather conditions. Store in a dry, sheltered area during winter months if possible.

7. TROUBLESHOOTING

- **Table is wobbly:** Ensure all bolts and fasteners are securely tightened. Check that the table is on a flat, even surface. Adjust the position if necessary.
- **Missing parts:** If any parts are missing upon delivery, do not proceed with assembly. Contact Best Choice Products customer support immediately for replacement parts.
- **Difficulty with assembly:** Refer to the detailed assembly guide included with your product. Ensure you are using the correct hardware for each step. If issues persist, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	SKY9687
Brand	Best Choice Products
Product Dimensions	75"D x 75"W x 30"H
Item Weight	55 Pounds
Maximum Weight Recommendation (Tabletop)	300 lbs
Maximum Weight Recommendation (Per Seat)	500 lbs
Seating Capacity	8 Persons
Frame Material	Alloy Steel
Top Material Type	High Density Polyethylene
Color	Light Gray
Umbrella Hole Diameter	1.9 inches
Indoor/Outdoor Usage	Outdoor
Tools Recommended for Assembly	Screwdriver

9. VIDEO GUIDE

8-Person Picnic Table - The Best Seat for the Outdoors

Your browser does not support the video tag.

Video 9.1: An official video from Best Choice Products Inc demonstrating the features and benefits of the 8-Person Picnic Table. This video is 36 seconds long and provides a visual overview of the product in use.

10. WARRANTY AND SUPPORT

10.1 Manufacturer's Warranty

This product comes with a 60-day warranty. All returns must be shipped back to a Best Choice Products return center at the customer's expense within 60 days of delivery. A pre-paid return shipping label will be provided via email if the return is a result of our error. The company reserves the discretion to decide if an item may be returned to a Best Choice Products return center. Unauthorized returns may not be accepted. Once your claim is processed and approved, please allow 5-7 business days for completion. If a replacement unit or parts are requested, fulfillment time depends on product availability.

10.2 Customer Support

For any questions, missing parts, or warranty claims, please contact Best Choice Products customer support. Refer to the contact information provided with your purchase or visit the official Best Choice Products website for assistance.

