

[Manuals.plus](#) /

› [7AM2M](#) /

› 7AM2M AM100 Rechargeable Sonic Electric Toothbrush User Manual

7AM2M AM100

7AM2M AM100 Rechargeable Sonic Electric Toothbrush User Manual

1. INTRODUCTION

Thank you for choosing the 7AM2M AM100 Rechargeable Sonic Electric Toothbrush. This manual provides essential information for the safe and effective use, maintenance, and care of your new toothbrush. Please read it thoroughly before first use and retain it for future reference.



The 7AM2M AM100 Sonic Electric Toothbrush, shown with its charging base and a comprehensive set of replacement brush heads, highlighting the product's complete package.

2. SAFETY INFORMATION

Please observe the following safety precautions:

- Replace the brush head when the bristles show signs of fading or wear.
- Keep this product out of reach of children to prevent choking hazards from small parts.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Ensure the charging base is kept dry and away from water to prevent electrical hazards.

3. PACKAGE CONTENTS

Your 7AM2M AM100 Sonic Electric Toothbrush package includes:

- 1 x Electric Toothbrush Handle

- 14 x Brush Heads
- 1 x USB Wireless Charging Base
- 1 x Instruction Manual (this document)



The product packaging for the 7AM2M AM100 Sonic Electric Toothbrush, displaying key features like 5 modes, IPX7 waterproof rating, and smart timer, alongside the toothbrush handle and several brush heads.

4. PRODUCT FEATURES

- **Sonic Technology:** Produces 40,000 brush strokes per minute for dynamic cleaning.
- **5 Brushing Modes:** Clean, White, Polish, Milder, and Sensitive for personalized oral care.
- **Smart Chip:** Compensates for power in case of obstacles and increases strength for consistent performance.
- **High Capacity Lithium-Ion Battery:** Provides extended usage time.
- **IPX7 Waterproof:** Allows for safe use in the shower and easy cleaning under running water.
- **Ergonomic Anti-Slip Design:** Ensures comfortable and secure handling.

- **Bristle Fade Reminder:** Blue bristles gradually fade to white, indicating when to replace the brush head.

Internal Technology

Maglev Motor



Smart Chip

compensate for power in case of obstacles and increase strength



Powerful Lithium-Ion Battery



An illustration detailing the internal components of the 7AM2M AM100 Sonic Electric Toothbrush, including the powerful Maglev Motor for high vibrations, a Smart Chip for consistent performance, and a High Capacity Lithium-Ion Battery for extended use.

Brushing Modes

New exterior design

IPX7

Waterproof



• Ergonomic Anti Slip Design

A visual representation of the five distinct brushing modes available on the 7AM2M AM100 Sonic Electric Toothbrush: Clean, White, Polish, Sensitive, and Milder, each designed for specific oral care needs.

Design and Bristles



W-Shaped

No damage
to gums




Bristles Fade

Cleans
5 times
better than
others



Polished >93.5%

Remind you
to use the
brush head
replacment



The 7AM2M AM100 Sonic Electric Toothbrush highlighting its IPX7 waterproof rating, ensuring safe use in wet environments, and its ergonomic anti-slip design for comfortable and secure handling.



**45% more
usage time than others**

1 charge **120** **days use** 

*Under A Sensitive Gear

A close-up of the W-shaped bristles on the 7AM2M AM100 brush head, designed for effective cleaning, and illustrating the blue bristle fade reminder feature which indicates when it's time to replace the brush head.

5. SETUP AND CHARGING

Initial Charging

1. Place the toothbrush handle onto the USB wireless charging base.
2. Connect the USB cable to a compatible power adapter (not included) and plug it into a power outlet.
3. The indicator light on the toothbrush will illuminate to show it is charging.

4. Allow the toothbrush to charge fully before first use. A full charge can provide up to 120 days of use (under Sensitive mode).

Attaching the Brush Head

1. Align the brush head with the metal shaft on the toothbrush handle.
2. Push the brush head down firmly until it clicks into place.
3. To remove, pull the brush head straight up from the handle.

20,000,000
Sold

120+
Global Patent

100+ Countries
For Sale

1000+ Dentists
Recommendations



1 Year Assurance



After-Sales,
Number:
(+1)209-734-3760

6. OPERATING INSTRUCTIONS

Power On/Off and Mode Selection

1. Press the power button once to turn on the toothbrush. It will start in the last used mode.
2. Press the power button repeatedly within 5 seconds to cycle through the 5 modes: Clean, White, Polish, Milder, Sensitive.
3. To turn off the toothbrush, press and hold the power button for 2 seconds, or press the power button after the desired mode has been active for more than 5 seconds.

Brushing Technique

- Wet the bristles and apply a small amount of toothpaste.
- Place the brush head against your teeth at a slight angle towards the gum line.
- Gently move the brush head slowly across each tooth, allowing the sonic vibrations to do the cleaning. Avoid scrubbing vigorously.
- The toothbrush features a 2-minute smart timer and a 30-second interval pause to guide you to brush each quadrant of your mouth evenly.
- After brushing, rinse your mouth and the brush head thoroughly.

7. MAINTENANCE

Cleaning the Toothbrush

- After each use, rinse the brush head and bristles thoroughly under running water.
- Wipe the toothbrush handle with a damp cloth. Do not immerse the handle in water for extended periods, despite its waterproof rating.
- Ensure the charging base is clean and dry before placing the toothbrush on it.

Replacing Brush Heads

The blue indicator bristles on the brush head will gradually fade to white over approximately three months of use. This indicates that it is time to replace the brush head for optimal cleaning performance. Replacement brush heads are available from 7AM2M.

8. TROUBLESHOOTING

- **Toothbrush not turning on:** Ensure the toothbrush is fully charged. If the issue persists, contact customer support.
- **Toothbrush not charging:** Check if the charging base is properly connected to a power source. Ensure the toothbrush is correctly seated on the charging base. Clean any debris from the charging contacts.
- **Reduced vibration:** The battery might be low. Recharge the toothbrush. If the issue persists after charging, contact customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	7AM2M
Model	AM100
Special Feature	Sonic Technology
Power Source	Battery Powered
Number of Items	9 (referring to the product bundle, including brush heads)
Toothbrush Head Shape	Round (W-shaped bristles)
Waterproof Rating	IPX7

10. WARRANTY AND SUPPORT

7AM2M provides a 1-year assurance for this product. If you encounter any issues or have questions, please contact us through your Amazon account:

1. Log in to your Amazon account.
2. Go to "Your Orders".
3. Find the order ID for your 7AM2M AM100 Toothbrush.
4. Click on "Contact seller".

11. LEGAL DISCLAIMER

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for personal oral hygiene use only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question