

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GRIFEMA](#) /

› [GRIFEMA GA2006 Digital Luggage Scale User Manual](#)

GRIFEMA GA2006

GRIFEMA GA2006 Digital Luggage Scale

User Manual

1. INTRODUCTION

Thank you for choosing the GRIFEMA GA2006 Digital Luggage Scale. This portable and accurate scale is designed to help you measure the weight of your luggage, preventing unexpected excess baggage fees. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your device.

2. SAFETY INFORMATION

- Do not immerse the scale in water or other liquids.
- Avoid dropping the scale or subjecting it to strong impacts.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the scale yourself. Contact customer support if issues arise.
- Ensure the battery compartment is securely closed after battery installation.

3. PACKAGE CONTENTS

The GRIFEMA GA2006 Digital Luggage Scale package includes:

- 1 x GRIFEMA GA2006 Digital Luggage Scale
- 1 x CR2032 Battery (pre-installed or included separately)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your digital luggage scale:



Image: Front view of the GRIFEMA GA2006 Digital Luggage Scale, highlighting the LCD screen, power/tare button, and unit selection button.

- **LCD Display:** Shows weight readings and unit indicators.
- **Power/Tare Button (/T/A):** Press to power on/off, or to activate the tare function.
- **Unit Button (U/SET/ ▼):** Press to switch between measurement units (kg/lb).
- **Strap and Hook:** For attaching luggage to be weighed.

5. SETUP

5.1 Battery Installation

The scale uses one CR2032 lithium battery. If the battery is not pre-installed or needs replacement, follow these steps:

1. Locate the battery compartment on the back of the scale.
2. Use a small screwdriver to open the battery cover.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Replace the battery cover and secure it with the screw.



Image: Detailed view of the battery compartment, showing the CR2032 battery and how to open the cover.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

- To power on, press the Power/Tare button (/T/A). The display will show "8888" then "0.00 kg" or "0.0 lb".
- To power off, press and hold the Power/Tare button (/T/A) for 3 seconds. The scale will also automatically shut off after 60 seconds of inactivity to conserve battery.

6.2 Unit Conversion (kg/lb)

While the scale is powered on and displaying "0.00", press the Unit button (U/SET/▼) to switch between kilograms (kg) and pounds (lb). The selected unit will be displayed on the LCD screen.

6.3 Weighing Luggage

1. Ensure the scale is powered on and displaying "0.00".
2. Attach the luggage strap to the handle of your luggage.
3. Lift the scale by its body, holding it steady, so the luggage hangs freely from the strap and hook.

4. Wait for the display to stabilize. The weight will flash three times and then lock, indicating the final measurement.
5. Lower the luggage. The display will show the locked weight for a few seconds before returning to "0.00" or powering off automatically.



Image: A person demonstrating how to weigh a suitcase using the digital luggage scale, showing the scale held above the luggage.

6.4 Tare Function

The tare function allows you to subtract the weight of a container or additional items to get the net weight of the contents.

1. With the scale powered on and displaying "0.00", attach the empty container or item you wish to tare.
2. Once the weight stabilizes, press the Power/Tare button (/T/A). The display will reset to "0.00" and show a "T" indicator, meaning the tare weight has been subtracted.
3. Now, add the items you want to weigh into the container. The display will show only the weight of the added items.

7. MAINTENANCE

7.1 Cleaning

Wipe the scale with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.

7.2 Storage

Store the scale in a cool, dry place. If not used for an extended period, it is recommended to remove the battery to prevent leakage.

7.3 Battery Replacement

When the display shows a "Lo" indicator, it's time to replace the battery. Refer to section 5.1 for battery installation instructions.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Scale does not turn on.	Dead or incorrectly installed battery.	Check battery installation or replace the CR2032 battery.
Display shows "Lo".	Low battery power.	Replace the CR2032 battery.
Display shows "Err" or "O-Ld".	Overload. The weight exceeds the maximum capacity.	Remove some weight. The maximum capacity is 50 kg (110 lb).
Inaccurate readings.	Scale not held steadily, or external interference.	Ensure the scale is held steady and the luggage hangs freely. Avoid strong air currents or vibrations during weighing.

9. SPECIFICATIONS

Detailed specifications for the GRIFEMA GA2006 Digital Luggage Scale:

Product Dimensions

Net weight: 85g



Image: Technical drawing illustrating the dimensions of the GRIFEMA GA2006 Digital Luggage Scale.

- **Model:** GA2006
- **Maximum Weight Capacity:** 50 kg / 110 lb
- **Measurement Precision:** 50 g / 0.1 lb (+/- 0.5%)
- **Units:** Kilograms (kg), Pounds (lb)
- **Display:** Backlit LCD
- **Material:** Stainless steel, plastic
- **Battery Type:** 1 x CR2032 Alkaline (included)
- **Auto-Off:** 60 seconds of inactivity
- **Dimensions:** 14.5 cm x 3.2 cm x 3.5 cm (approximate, main body)
- **Net Weight:** 85 g

10. WARRANTY INFORMATION

GRIFEMA products are manufactured to high-quality standards. This product is covered by a standard

warranty against manufacturing defects. Please retain your proof of purchase for any warranty claims. For specific warranty terms and conditions, refer to the documentation provided at the time of purchase or contact customer support.

Additionally, a 30-day free return policy may apply, as per retailer terms.

11. CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your GRIFEMA GA2006 Digital Luggage Scale, please contact your retailer or the manufacturer's customer service. Please have your product model number (GA2006) and purchase details ready when contacting support.