

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DREAME](#) /

› [DREAME L50 Ultra Robot Vacuum and Mop User Manual](#)

DREAME L50 Ultra

DREAME L50 Ultra Robot Vacuum and Mop User Manual

Model: RLL94CE

Introduction	Safety Information	Package Contents	Product Overview	Setup	Operation
Maintenance	Troubleshooting	Specifications		Warranty & Support	

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your DREAME L50 Ultra Robot Vacuum and Mop. Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

To reduce the risk of injury or damage, read and follow all safety precautions when setting up, using, and maintaining your robot. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- Ensure the robot is fully charged before first use.
- Do not use the robot in wet environments or near water.
- Remove loose cables, small objects, and fragile items from the floor before cleaning.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the robot in areas where there are open flames or explosive materials.
- Use only the manufacturer-specified power adapter and charging dock.
- Do not use the robot to pick up large debris, broken glass, or corrosive liquids.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon unboxing.



Robot Vacuum x1
Robot aspirateur x1



Base Station x1
Base x1



Main Brush (pre-installed x1)
Brosse principale (préinstallée x1)



Brush Guard (pre-installed x1)
Protection de brosse (préinstallée x1)



Side Brush (pre-installed x1)
Brosse latérale (préinstallée x1)



Scale Inhibitor (pre-installed x1)
Inhibiteur de tartre (préinstallé x1)



Dust Bags x2 (pre-installed x1)
Sacs à poussière x2 (préinstallé x1)



Mop Pad Holders x2
Supports de serpillière x2



Mop Pads x2
Serpillières x2



Dust Box (pre-installed x1, including filter)
Bac à poussière (préinstallé x1, avec filtre du bac à poussière)



200ml Cleaning Solution x1
Solution de nettoyage de 200 ml x1



Base Station Ramp Extension x1
Rallonge de la rampe de la base x1



Quick Start Guide x1
Guide de démarrage rapide x1



User Manual x1
Manuel d'utilisation x1

What's in the Box Contenu de la boîte

Image: All components included in the DREAME L50 Ultra package. This includes the robot vacuum, base station, various brushes, mop pads, cleaning solution, and documentation.

- Robot Vacuum x1
- Base Station x1
- Main Brush (pre-installed) x1
- Brush Guard (pre-installed) x1
- Side Brush (pre-installed) x1
- Scale Inhibitor (pre-installed) x1
- Dust Bags (pre-installed) x2
- Mop Pad Holders x2
- Mop Pads x2
- Dust Box (pre-installed, including filter) x1
- 200ml Cleaning Solution x1
- Base Station Ramp Extension x1
- Quick Start Guide x1
- User Manual x1

4. PRODUCT OVERVIEW

The DREAME L50 Ultra is an advanced robot vacuum and mop designed for comprehensive floor cleaning. It features powerful suction, intelligent navigation, and an all-in-one PowerDock for automated maintenance.



Image: The DREAME L50 Ultra robot vacuum docked with its white base station, alongside a smartphone displaying the companion app icon.

Key Features:

- **19,500Pa Vormax Suction:** Powerful suction for effective debris pickup.
- **HyperStream Detangling DuoBrush:** Bristled rubber brush and TPU rubber brush for efficient hair removal and tangle prevention.
- **ProLeap System:** Retractable legs for seamless crossing over door tracks and thresholds up to 6cm.
- **AI Action and 3D Structured Light:** Precise obstacle avoidance for over 180 types of objects.
- **Dual Flex Arm Technology:** Extendable side brush and mop for comprehensive edge-to-corner cleaning.
- **All-in-One PowerDock:** Features auto-empty (up to 100 days), hot water mop self-cleaning, hot air drying, auto

solution refilling, and auto water tank refilling.

- **Customizable Carpet Cleaning:** 5 modes via the Dreamehome App for tailored carpet care.
- **On-Demand Voice Control:** Compatible with Alexa, Siri, and Google Assistant.

5. SETUP

5.1 Unboxing and Initial Placement

Carefully remove all components from the packaging. Place the base station on a hard, level surface against a wall, ensuring there is adequate clearance around it (at least 0.5m on both sides and 1.5m in front). Connect the power cable to the base station and plug it into a power outlet.

Your browser does not support the video tag.

Video: A user unboxes the DREAME L50 Ultra, showing the components and initial setup of the robot and its base station. This video demonstrates the physical setup process.

5.2 App Installation and Connection

Download the "Dreamehome" app from your smartphone's app store. Follow the in-app instructions to connect your DREAME L50 Ultra to your home Wi-Fi network. This process typically involves scanning a QR code on the robot and following prompts for network selection.

5.3 Filling Water Tanks and Solution

Open the top cover of the base station to access the clean water tank and cleaning solution compartment. Fill the clean water tank with tap water and the solution compartment with the provided DREAME cleaning solution. Ensure both are securely closed before operation.

6. OPERATION

6.1 Starting and Stopping Cleaning

- **Start:** Press the power button on the robot or tap "Clean" in the Dreamehome app.
- **Pause:** Press the power button during cleaning or tap "Pause" in the app.
- **Resume:** Press the power button or tap "Resume" in the app.
- **Return to Dock:** Press the home button on the robot or tap "Dock" in the app.

6.2 Cleaning Modes

The Dreamehome app allows you to select various cleaning modes:

- **Vacuum Only:** For dry debris on all floor types.
- **Mop Only:** For wet cleaning on hard floors.
- **Vacuum & Mop:** Simultaneous vacuuming and mopping.
- **Custom Cleaning:** Define specific areas or rooms for cleaning with adjustable settings.

6.3 Scheduled Cleaning

Set up recurring cleaning tasks through the Dreamehome app. You can specify start times, frequency (daily, weekly, custom), and cleaning parameters for the entire area or specific rooms.

Your browser does not support the video tag.

Video: This video demonstrates how to set up scheduled cleaning tasks using the Dreamehome app, allowing the robot vacuum to clean automatically at predefined times.

6.4 Obstacle Avoidance and Dynamic Cleaning

The DREAME L50 Ultra utilizes AI Action and 3D structured light for precise obstacle avoidance. It can detect and navigate around over 180 types of objects, including shoes, furniture, and cables.



No Spot Left Behind with Smart Obstacle Detection La détection d'obstacles intelligente ne néglige aucune surface

Image: A DREAME L50 Ultra robot vacuum navigating around various obstacles like a teddy bear, slippers, and cables, illustrating its smart obstacle detection capabilities.

Enable "Dynamic Obstacle Area Cleaning" in the app settings to allow the robot to remember skipped areas due to dynamic obstacles (like pets or people) and clean them later.

Your browser does not support the video tag.

Video: This video highlights the Dynamic Replenishment Sweeping Technology, showing how the robot avoids dynamic obstacles and then returns to clean those areas.

6.5 Edge and Corner Cleaning

The Dual Flex Arm technology with an extendable side brush and mop ensures thorough cleaning of corners and tight spots. Activate "AI-driven SideReach" and "AI-driven MopExtend" in the app settings for enhanced coverage.

100%

Coverage Cleaning
of Edges and Corners

Nettoyage à

100%

des bords et coins



*100% Coverage: Certified by TÜV SÜD. Actual results depend on the environment.

*Nettoyage à 100 % : certifié par TÜV SÜD. Les performances réelles peuvent varier suivant l'environnement domestique.

Comprehensive Edge-to-Corner Coverage Nettoyage complet, y compris des bords et des coins

Image: A DREAME L50 Ultra robot vacuum cleaning along a wall and corner, demonstrating its ability to reach tight spaces with its extendable components.

Your browser does not support the video tag.

Video: This video illustrates the DREAME robot's corner and edge cleaning feature, showing how it extends its brush and mop to clean along walls and around furniture legs.

6.6 Carpet Cleaning Strategies

Customize carpet cleaning through the Dreamehome app with 5 available modes:

- **Removable Mops:** Detach mop pads to maintain dry carpets.
- **Liftable Mops:** Mops lift for low-pile carpets.
- **Complete Carpet Avoidance:** Robot avoids all carpets.
- **Intensive Carpet Cleaning:** Vacuums carpets twice for deeper cleaning.
- **Suction Boost:** Increases suction power on carpets.

6.7 Voice Control

Manage your cleaning routine using voice commands with Alexa, Siri, or Google Assistant. Link your DREAME L50 Ultra to

your preferred voice assistant through the Dreamehome app.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your DREAME L50 Ultra.

7.1 All-in-One PowerDock Maintenance

- Auto-Empty:** The dock automatically empties the robot's dustbin for up to 100 days. Replace the dust bag in the dock when full.
- Mop Self-Cleaning:** Mop pads are automatically rinsed with 167°F hot water.
- Hot Air Drying:** Mop pads are dried with hot air to prevent odors and mildew.
- Solution & Water Refilling:** The dock automatically refills the robot's water tank and cleaning solution.
- Base Station Cleaning:** The AceClean DryBoard system helps prevent dirt buildup in the washboard area. Periodically check and clean the washboard filter.




Image: An infographic detailing the various automated functions of the DREAME L50 Ultra's PowerDock, including auto-empty, mop self-cleaning, hot air drying, and water/solution refilling.

7.2 Robot Vacuum Component Cleaning

- **Dustbin:** Empty the robot's internal dustbin regularly, especially if not using the auto-empty feature.
- **Main Brush:** Remove the main brush and clean any tangled hair or debris. The HyperStream Detangling DuoBrush is designed to minimize tangles.
- **Side Brush:** Check for and remove any tangled hair or debris from the side brush.
- **Filters:** Clean the dustbin filter periodically by tapping out debris. Replace as needed.
- **Sensors:** Wipe all sensors (cliff sensors, wall sensors, charging contacts) with a clean, dry cloth to ensure proper function.



Image: A close-up view of the DREAME L50 Ultra's dual brush system, showing a bristled rubber brush for hard floors and a TPU rubber brush for carpets, designed for effective hair removal.

Your browser does not support the video tag.

Video: This video shows the dirty water collected after two mopping cycles, demonstrating the effectiveness of the DREAME L50 Ultra's mopping function.

Your browser does not support the video tag.

Video: This video measures the sound level of the DREAME L50 Ultra during its self-empty cycle, providing an indication of its

operational noise.

8. TROUBLESHOOTING

If your DREAME L50 Ultra encounters an issue, refer to the following common solutions. For persistent problems, contact customer support.

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; Power button not pressed correctly.	Place the robot on the charging dock; Press and hold the power button for 3 seconds.
Robot cannot charge.	Charging contacts are dirty; Power cable not connected.	Clean the charging contacts on both the robot and dock; Ensure the power cable is securely plugged in.
Robot gets stuck frequently.	Too many obstacles; Sensors are dirty.	Clear the cleaning area of clutter; Clean all sensors on the robot.
Poor cleaning performance.	Dustbin full; Brushes tangled; Filter clogged.	Empty the dustbin; Clean the main and side brushes; Clean or replace the filter.
Mop pads not cleaning effectively.	Mop pads dirty; Water tank empty; No cleaning solution.	Ensure mop pads are clean; Refill the clean water tank; Refill the cleaning solution.
Robot is too loud during self-empty.	Normal operation.	The self-empty function involves powerful suction and is inherently noisy. This is normal.

8.1 Restarting the Robot

If the robot is unresponsive or behaving erratically, a simple restart may resolve the issue. Press and hold the power button on the robot for a few seconds until it powers off, then press it again to turn it back on.

Your browser does not support the video tag.

Video: This video demonstrates how to perform a simple restart on the DREAME L50 Ultra robot vacuum by pressing and holding the power button.

8.2 Factory Reset

A factory reset will restore the robot to its original settings and delete all saved maps and Wi-Fi connections. This should be used as a last resort for persistent issues.

1. Ensure the robot is powered on.
2. Open the top cover of the robot.
3. Locate the small reset button (often a pinhole) near the Wi-Fi indicator.
4. Using a small tool (like a SIM ejector tool or paperclip), press and hold the reset button for approximately 5 seconds until you hear a voice prompt confirming the factory reset.
5. The robot will then restart with factory settings.

Your browser does not support the video tag.

Video: This video guides you through the process of performing a factory reset on the DREAME L50 Ultra robot vacuum, including locating the reset button and confirming the reset.

9. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	DREAME
Model Name	Dreame L50 Ultra White
Item Model Number	RLL94CE
UPC	810142561310
Color	White
Product Dimensions	17" L x 16" W x 27" H
Item Weight	42.1 pounds
Suction Power	19,500Pa Vormax Suction
Battery Life	180 minutes
Voltage	110 Volts
Control Method	App, Remote, Voice
Filter Type	Foam
Surface Recommendation	Wood, Marble, Tile

10. WARRANTY AND SUPPORT

DREAME products are covered by a limited warranty from the date of purchase. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official DREAME website.


Customer Support:


If you have any questions, require technical assistance, or need to report an issue, please contact DREAME customer support through the following channels:

- Official Website:** Visit the DREAME official website for FAQs, support resources, and contact information.
- Dreamehome App:** Access support directly through the app's help section.
- Email/Phone:** Refer to your product's quick start guide or the official website for specific contact details in your region.

Please have your product model number (RLL94CE) and purchase information ready when contacting support.

Related Documents - L50 Ultra

	<p><u>Dreame L50 Ultra Robot Vacuum and Mop User Manual</u></p> <p>User manual for the Dreame L50 Ultra Robot Vacuum and Mop, detailing setup, operation, maintenance, and troubleshooting for this advanced cleaning device.</p>
--	---

	<p>Dreame L50 Pro Ultra Robot Vacuum and Mop User Manual</p> <p>User manual for the Dreame L50 Pro Ultra Robot Vacuum and Mop, detailing setup, usage, maintenance, and troubleshooting for this advanced cleaning device with auto-empty and mop self-cleaning features.</p>
	<p>Dreame L50 Pro Ultra Robot Vacuum and Mop User Manual</p> <p>User manual for the Dreame L50 Pro Ultra Robot Vacuum and Mop with Auto-Empty and Mop Self-Cleaning features. Provides setup, operation, and maintenance instructions.</p>
	<p>Dreame L50 Ultra Robot Vacuum and Mop Self-Cleaning User Manual</p> <p>User manual for the Dreame L50 Ultra Robot Vacuum and Mop with Auto-Empty and Mop Self-Cleaning. This guide provides detailed instructions and safety information for operating the device.</p>
	<p>Dreame L30s Ultra User Manual: Robot Vacuum & Mop with Auto-Empty and Mop Self-Cleaning</p> <p>This comprehensive user manual for the Dreame L30s Ultra robot vacuum and mop provides detailed instructions on setup, operation, safety, maintenance, and troubleshooting. Learn how to maximize the auto-empty and mop self-cleaning features of your Dreame device.</p>
	<p>Dreame L50 Pro Ultra Robot Vacuum and Mop User Manual</p> <p>Comprehensive user manual for the Dreame L50 Pro Ultra robot vacuum and mop, detailing features like auto water refilling, auto-empty, and self-cleaning. Includes setup, usage, maintenance, and troubleshooting guides.</p>