

[Manuals.plus](#) /

› [BOMOVA](#) /

› BOMOVA Heated Electric Blanket (Model: B0F3JK4TXV) - Instruction Manual

BOMOVA B0F3JK4TXV

BOMOVA Heated Electric Blanket Instruction Manual

MODEL: B0F3JK4TXV (TEAL THROW, 50" x 60")

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your BOMOVA Heated Electric Blanket. Failure to follow these instructions may result in fire, electric shock, or injury.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Never use pins or other metallic objects with this blanket. They may damage the wiring.
- Do not use if the power cord or controller is damaged. Contact customer support for assistance.
- Always disconnect the power cord from the outlet when not in use or before cleaning.
- Do not dry clean this product. Dry cleaning solvents may damage the insulation of the heating element.
- Do not iron the blanket.
- Keep the controller away from open windows or direct sunlight to prevent damage.
- Ensure the blanket is spread flat and not bunched or folded when in use to prevent overheating.

PRODUCT OVERVIEW

The BOMOVA Heated Electric Blanket provides customizable warmth and comfort. Made from soft flannel and sherpa materials, it features multiple heat settings and an automatic shut-off timer for safety and convenience.



Image: A woman sleeping peacefully under the soft teal heated blanket.

Key Features:

- **10 Heating Levels:** Adjust warmth from 83°F to 113°F.
- **LED Controller:** Intuitive display for temperature and time settings.
- **Automatic Shut-Off:** Timer options for 1, 2, 4, 6, or 8 hours, with an automatic 8-hour default shut-off.
- **Soft Material:** Constructed from warm flannel and sherpa for ultimate comfort.
- **Long Power Cord:** 7.87ft cord for flexible placement.
- **Machine Washable:** Detachable controller allows for easy cleaning.

SETUP INSTRUCTIONS

Follow these steps to prepare your heated blanket for use:

1. **Unpack:** Carefully remove the blanket and controller from its packaging.
2. **Inspect:** Check the blanket and power cord for any signs of damage. Do not use if damaged.
3. **Position:** Lay the blanket flat on your bed, couch, or desired surface, ensuring there are no folds or creases.
4. **Connect Controller:** Locate the connector port on the blanket. Align the controller's plug with the port and push firmly until it clicks into place.



Image: Detailed view of the blanket's controller and connection point.

5. **Plug In:** Insert the power plug into a standard 120V AC electrical outlet.

OPERATING INSTRUCTIONS

Your BOMOVA Heated Electric Blanket is designed for easy operation.

1. **Power On/Off:** Press the power button on the controller to turn the blanket ON or OFF. The LED display will illuminate when powered on.
2. **Adjust Heating Level:** Use the temperature adjustment button (often marked with a thermometer icon or '+' / '-' symbols) to cycle through the 10 available heating levels (83°F-113°F). The current level will be shown on the LED display.
3. **Set Auto Shut-Off Timer:** Press the timer button (often marked with a clock icon) to select your desired auto shut-off time: 1, 2, 4, 6, or 8 hours. The blanket will automatically turn off after the selected duration. If no timer is set, it will default to an 8-hour auto shut-off for safety.
4. **Enjoy:** Once your desired settings are selected, relax and enjoy the warmth.

CARE AND MAINTENANCE

Proper care will extend the life of your heated blanket.

- **Disconnect Power:** Always unplug the blanket from the wall outlet and detach the controller before cleaning.
- **Hand Wash Only:** The manufacturer recommends hand washing for this product. Use mild detergent and lukewarm water. Gently squeeze out excess water.
- **Drying:** Do not wring or twist the blanket. Hang to air dry completely. Ensure the blanket and all connectors are thoroughly dry before reconnecting the controller or plugging it back into an outlet.
- **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal wiring.

Troubleshooting

If you encounter issues with your heated blanket, refer to the following common solutions:

Problem	Possible Cause	Solution
Blanket not heating	Not plugged in; Controller not connected; Power outage; Auto shut-off activated.	Ensure power cord is securely plugged into outlet and controller is firmly attached to blanket. Check power supply. Reset by unplugging for 5 minutes and replugging.
Controller display not working	Power issue; Controller malfunction.	Check power connection. Try unplugging and replugging. If issue persists, contact customer support.
Blanket overheating or uneven heating	Blanket bunched or folded; Internal wiring damage.	Ensure blanket is spread flat. Discontinue use immediately if overheating occurs and contact customer support.

Product Specifications

Feature	Detail
Brand	BOMOVA
Model Number	B0F3JK4TXV
Size	Throw (50"L x 60"W)
Color	Teal
Material	Flannel, Fleece (100% Polyester)
Heating Levels	10 (83°F-113°F)
Auto Shut-Off Timer	1, 2, 4, 6, 8 hours (default 8 hours)
Power Cord Length	7.87 ft

Feature	Detail
Product Care	Hand Wash Only
Item Weight	3.19 pounds



Image: Available sizes for BOMOVA Heated Electric Blankets.



Image: Color options for BOMOVA Heated Electric Blankets.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact BOMOVA customer service directly. Keep your purchase receipt for warranty claims.