

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Colaxi](#) /
- › [Colaxi Womens Crossbody Bag Instruction Manual](#)

Colaxi B0F3JLB7KD

Colaxi Womens Crossbody Bag Instruction Manual

Model: B0F3JLB7KD

1. PRODUCT OVERVIEW

The Colaxi Womens Crossbody Bag is a versatile and portable accessory designed for daily use, commuting, and travel. Crafted from durable canvas material, it offers convenient storage for essential items such as phones, wallets, cosmetics, glasses, and headphones. Its compact design ensures ease of carrying while providing ample space for your belongings.



Image 1: Front view of the Colaxi Womens Crossbody Bag, showcasing its design and braided top handle.

2. SETUP

Your Colaxi Crossbody Bag arrives ready for use. No assembly is required. Before first use, inspect the bag for any shipping damage. If a chain strap is included, it may be attached or found inside the main compartment. Simply clip the chain strap to the rings located on the sides of the bag for crossbody or shoulder wear.

- **Unpacking:** Remove the bag from its packaging.
- **Strap Attachment:** If using the chain strap, locate the two metal rings on the upper sides of the bag and securely attach the strap's clasps to these rings.
- **Initial Inspection:** Check all zippers, seams, and hardware to ensure they are in good condition.

3. OPERATING INSTRUCTIONS

The Colaxi Crossbody Bag offers multiple carrying options and efficient storage for your daily essentials.

3.1 Carrying Options

- **Top Handle:** Use the braided top handle for hand carrying. This provides a classic and convenient way to transport the bag.
- **Chain Strap:** Attach the chain strap for shoulder or crossbody wear. Adjust the position of the bag for comfort and security.



Image 2: Close-up view of the bag's braided top handle, highlighting its texture and attachment points.

3.2 Storage

The main compartment is designed to hold various personal items. Organize your belongings efficiently to maximize space and accessibility.

- Place larger items like a wallet or phone at the bottom.
- Smaller items such as keys, lip balm, or headphones can be placed on top for easy retrieval.

4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Colaxi Crossbody Bag.

4.1 Cleaning Instructions

- **Spot Cleaning:** For minor stains, gently wipe the affected area with a damp cloth and mild soap. Avoid harsh detergents or abrasive cleaners.
- **Drying:** Allow the bag to air dry completely in a well-ventilated area, away from direct sunlight or heat sources. Do not machine wash or tumble dry.
- **Hardware:** Periodically wipe metal hardware with a soft, dry cloth to maintain its shine.

4.2 Storage

When not in use, store the bag in a cool, dry place. To help maintain its shape, you may lightly stuff the bag with tissue paper.

5. TROUBLESHOOTING

This section addresses common concerns you might encounter with your bag.

- **Strap Tangling:** If the chain strap becomes tangled, gently untangle it by hand. Avoid pulling forcefully to prevent damage.
- **Minor Stains:** Refer to the 'Cleaning Instructions' in Section 4.1 for guidance on spot cleaning.
- **Loss of Shape:** If the bag loses some of its shape, lightly stuff it with soft material (e.g., tissue paper) when storing it.

6. SPECIFICATIONS

Detailed specifications for the Colaxi Womens Crossbody Bag.

Feature	Detail
Material	Canvas
Base Length	17 cm / 6.69 inches
Width	11 cm / 4.33 inches
Height	14 cm / 5.51 inches
Item Weight	0.26 Kilograms / 9.17 ounces

Feature	Detail
Color	Blue



Image 3: The Colaxi Crossbody Bag with its base length, width, and height dimensions clearly indicated.

7. WARRANTY AND SUPPORT

For warranty information or product support, please contact the manufacturer, Colaxi, directly through their official customer service channels. Keep your purchase receipt as proof of purchase.

For further assistance, you may refer to the seller's information on the platform where the product was purchased.

