

Xiaomi L32MB-FIN

User Manual: Xiaomi 80 cm (32 inch) F Series HD Ready Smart LED Fire TV

Brand: Xiaomi

Model: L32MB-FIN

1. INTRODUCTION

This user manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your new Xiaomi 80 cm (32 inch) F Series HD Ready Smart LED Fire TV. Please read this manual thoroughly before using the product to ensure proper functionality and safety.

Key Features

- **Resolution:** HD Ready (1366 x 768) with a 60 Hertz Refresh Rate for clear visuals.
- **Connectivity:** Equipped with 2 HDMI ports, 2 USB ports, Bluetooth, and Built-in Wi-Fi for versatile connections.
- **Audio:** 20 Watts Output with Dolby Audio, DTS-HD, and DTS Virtual : X for immersive sound.
- **Smart TV Features:** Integrated Fire TV with access to Prime Video, Netflix, Disney+ Hotstar, YouTube, and over 12000+ apps. Includes Voice Remote with Alexa and DTH Set-Top Box Integration.
- **Display:** Features HDR, HLG, and Vivid Picture Engine for enhanced visual quality.
- **Design:** Premium Bezel-less Design for a sleek and elegant appearance.



Figure 1.1: Front view of the Xiaomi 32-inch F Series Smart LED Fire TV.

NEW LAUNCH

xiaomi
Smart TV F 32 2025

Fantastic
Entertainment



High-definition
Display

Vivid Picture
Engine 2



Picture-in-
Picture Mode



20W
Speakers



Premium
Bezel-less
Design



Figure 1.2: Overview of key features including High-definition Display, Vivid Picture Engine 2, Alexa, Picture-in-Picture Mode, Dolby Audio, 20W Speakers, DTS-HD, DTS Virtual:X, Premium Bezel-less Design, and Apple AirPlay 2.

2. WHAT'S IN THE BOX

Before proceeding with the setup, please verify that all the following components are included in your package:

- 1 x Xiaomi 80 cm (32 inch) F Series Smart LED Fire TV Unit
- 1 x Remote Control
- 2 x AAA Batteries (for remote control)
- 1 x Power Cable
- 2 x TV Stands
- 4 x Screws (for attaching stands)

What's in the box



1 TV Unit




Figure 2.1: Illustration of the items included in the product packaging.

3. SETUP GUIDE

3.1 Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or service needs.

3.2 Mounting Options

Your Xiaomi Fire TV supports both **Table Mount** and **Wall Mount** installations. Choose the option that best suits your viewing environment.

- **Table Mount:** Attach the provided TV stands to the bottom of the TV using the included screws. Ensure the stands are securely fastened.
- **Wall Mount:** If you prefer wall mounting, you will need a compatible VESA wall mount kit (sold separately). Follow the instructions provided with your wall mount kit for safe and secure installation.

3.3 Connecting Peripherals

Connect your external devices to the appropriate ports on the back or side of your TV.

- **HDMI Ports (2):** Connect set-top boxes, Blu-ray players, gaming consoles, or other HDMI-enabled devices.
- **USB Ports (2):** Connect USB drives for media playback or other USB devices.
- **Ethernet Port:** For a wired internet connection.
- **3.5mm Earphone Jack:** For connecting headphones or external audio systems.
- **AV Input:** For connecting older devices with composite video and stereo audio outputs.
- **Antenna Input (2):** For connecting a terrestrial or cable antenna.



Figure 3.1: Detailed view of the TV's connectivity options including HDMI, USB, Ethernet, and audio ports.

3.4 Power Connection

Once all devices are connected, plug the power cable into the TV's power input and then into a wall outlet. The TV will enter standby mode.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

Press the power button on the remote control or on the TV itself to turn the TV on or off. The TV will boot up to the Fire TV home screen.

4.2 Remote Control Functions

The included remote control is designed for intuitive navigation of the Fire TV interface.

- **Voice Remote with Alexa:** Press and hold the microphone button to activate Alexa and use voice commands to search for content, launch apps, or control smart home devices.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services like Prime Video, Netflix, and YouTube provide instant access.
- **Navigation Pad:** Use the circular pad to navigate menus and select items.
- **Dedicated Mute Button:** Quickly mute or unmute the TV audio.



Weight not Including Base	3.1KG	Weight Including Packing	7.1KG
---------------------------	-------	--------------------------	-------

Figure 4.1: The all-new remote control with Alexa voice assistant and quick access buttons.

4.3 Smart TV Features (Fire TV OS)

Your Xiaomi Fire TV offers a rich smart TV experience:


- **App Store:** Access over 12,000 apps from the Fire TV Appstore, including popular streaming services and games.
- **Voice Control with Alexa:** Use your voice to find movies, TV shows, launch apps, play music, check weather, and control compatible smart home devices.
- **DTH Set-Top Box Integration:** Seamlessly switch between DTH TV channels and OTT apps directly from the home screen (requires compatible DTH provider).
- **Picture-in-Picture Mode:** Monitor an Alexa-compatible camera feed from your home without interrupting your current viewing.



Figure 4.2: The Fire TV home screen displaying a wide range of accessible applications.



Access over 12,000 apps on the Fire TV Appstore



*some apps may require subscription

Figure 4.3: Example of using Alexa voice commands to search for content.

4.4 Display and Audio Settings

Customize your viewing and listening experience through the TV's settings menu.

- **Vivid Picture Engine:** Enhances colors and depth with deeper contrasts for an exceptional visual experience.
- **Dolby Audio, DTS-HD, DTS Virtual : X:** Provides rich, clear, and immersive sound. Adjust audio settings to optimize for different content types.

Vivid Picture Engine 2

Exceptional colours & depth with deeper contrasts



Figure 4.4: Visual demonstration of improved picture quality with Vivid Picture Engine 2.

20W Speakers



Figure 4.5: Illustration emphasizing the 20W speakers and support for Dolby Audio, DTS-HD, and DTS Virtual:X.

5. CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your TV and ensure optimal performance.

5.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasive cleaners, or direct spraying of liquids onto the screen.

5.2 Cleaning the Frame and Stand

Use a soft, dry cloth to clean the TV frame and stand. If necessary, a slightly damp cloth can be used, followed by a dry cloth to remove any moisture.

5.3 Storage

If storing the TV for an extended period, disconnect it from power, cover it to protect from dust, and store in a cool, dry place. Ideally, use the original packaging for protection.

6. TROUBLESHOOTING COMMON ISSUES

This section addresses common issues you might encounter and provides simple solutions.

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet issue; TV in standby mode.	Ensure power cable is securely plugged into TV and wall outlet. Test the outlet with another device. Press the power button on the remote or TV.
No Picture, but Sound is Present	Incorrect input source selected; Loose HDMI/AV cable.	Press the 'Input' or 'Source' button on the remote to select the correct input. Check and re-secure all video cables.
No Sound, but Picture is Present	Volume muted or too low; External audio system not configured correctly; Incorrect audio output setting.	Unmute the TV or increase volume. Check connections to external audio devices. Adjust audio output settings in the TV menu.
Remote Control Not Responding	Batteries are low or incorrectly inserted; Obstruction between remote and TV; Remote needs re-pairing.	Replace batteries, ensuring correct polarity. Remove any obstructions. For Bluetooth remote, try re-pairing according to Fire TV instructions (usually holding Home button for 10 seconds).
Wi-Fi Connection Issues	Incorrect Wi-Fi password; Router issues; TV too far from router.	Double-check Wi-Fi password. Restart your Wi-Fi router. Move the TV closer to the router or consider a Wi-Fi extender.
Apps Crashing or Slow Performance	Too many apps running in background; Insufficient storage; App specific issue.	Close unused apps. Clear cache for problematic apps in settings. Restart the TV. Ensure sufficient storage space.

7. TECHNICAL SPECIFICATIONS

Detailed specifications for the Xiaomi 80 cm (32 inch) F Series HD Ready Smart LED Fire TV L32MB-FIN.

Feature	Specification
Brand	Xiaomi
Model	L32MB-FIN
Screen Size	32 Inches (80 cm)
Display Technology	LED
Resolution	HD Ready (1366 x 768 Pixels)
Refresh Rate	60 Hz

Feature	Specification
Operating System	Fire OS 8
RAM Memory Installed Size	1.5 GB
Memory Storage Capacity	8 GB
Graphics Coprocessor	Mali G31 MP2
Audio Output Power	20 Watts
Speaker Configuration	Dolby Audio, DTS-HD, DTS Virtual : X
Connectivity	Wi-Fi, USB (2 ports), Ethernet, HDMI (2 ports), Bluetooth
Viewing Angle	178 Degrees
Product Dimensions (LxWxH)	6.1 x 71.6 x 42.4 cm
Item Weight	3.1 kg
Power Source	AC
Model Year	2025

8. WARRANTY AND SUPPORT

Your Xiaomi 80 cm (32 inch) F Series HD Ready Smart LED Fire TV comes with a comprehensive warranty and dedicated support.

8.1 Warranty Information





This product is covered by a **1-year comprehensive warranty**. To avail of the brand warranty, please retain your Amazon invoice as proof of purchase.



8.2 Customer Support

For technical assistance, service requests, or any queries regarding your product, please contact Xiaomi customer support. You can typically find contact details on the official Xiaomi India website or through the support section of your Fire TV device.

User manuals and additional support resources can also be accessed from the official brand website.



	<p>Xiaomi L32MB-FPEU Television: User Guide and Safety Precautions</p> <p>This comprehensive guide provides essential safety precautions, installation instructions, usage guidelines, and disposal information for the Xiaomi L32MB-FPEU television. Learn how to safely set up and maintain your device.</p>
	<p>Xiaomi L32MB-FAEU Television User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the Xiaomi L32MB-FAEU television, covering installation, operation, maintenance, and regulatory information.</p>
 <p>To view the user guide, scan the QR code.</p>  <p>Xiaomi Pad 7 Quick Start Guide</p>	<p>Xiaomi Pad 7 Quick Start Guide - Setup and Safety Information</p> <p>Get started with your Xiaomi Pad 7. This quick start guide provides essential setup instructions, safety precautions, and regulatory information for the Xiaomi Pad 7 tablet.</p>

<div></div> <div><p>Xiaomi Focus Pen Uputstvo za brzo pokretanje Korisnički priručnik</p><p>Zvanično uputstvo za brzo pokretanje i bezbednosne informacije za Xiaomi Focus Pen, kompatibilan sa Xiaomi Pad 6S Pro 12.4. Saznajte o uparivanju, punjenju i pravilnoj upotrebi.</p></div> <div><p>Xiaomi Focus Pen</p><p>Uputstvo za brzo pokretanje i bezbednosne informacije</p></div>																																			
<div></div> <div><p>Xiaomi 12 Quick Start Guide: Setup, Features, and Safety Information</p><p>Get started with your Xiaomi 12 smartphone. This quick start guide provides essential information on setup, MIUI features, dual SIM usage, safety precautions, and legal compliance for the Xiaomi 12.</p></div> <div><p>Xiaomi 12</p><p>Quick Start Guide</p></div>																																			
<div><p>Cameras Connectées Xiaomi : Réglementation des Données et Informations Produit</p><p>Informations sur les caméras connectées Xiaomi, leur traitement des données selon la réglementation européenne, les détails des produits et les services connectés.</p></div> <div><p>Cameras Connectées Xiaomi : Réglementation des Données et Informations Produit</p><table><thead><tr><th>Modèle</th><th>Produit</th></tr></thead><tbody><tr><td>1</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>2</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>3</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>4</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>5</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>6</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>7</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>8</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>9</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>10</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>11</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>12</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>13</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>14</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>15</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr><tr><td>16</td><td>Xiaomi 12 Pro 5G (6.73")</td></tr></tbody></table></div>	Modèle	Produit	1	Xiaomi 12 Pro 5G (6.73")	2	Xiaomi 12 Pro 5G (6.73")	3	Xiaomi 12 Pro 5G (6.73")	4	Xiaomi 12 Pro 5G (6.73")	5	Xiaomi 12 Pro 5G (6.73")	6	Xiaomi 12 Pro 5G (6.73")	7	Xiaomi 12 Pro 5G (6.73")	8	Xiaomi 12 Pro 5G (6.73")	9	Xiaomi 12 Pro 5G (6.73")	10	Xiaomi 12 Pro 5G (6.73")	11	Xiaomi 12 Pro 5G (6.73")	12	Xiaomi 12 Pro 5G (6.73")	13	Xiaomi 12 Pro 5G (6.73")	14	Xiaomi 12 Pro 5G (6.73")	15	Xiaomi 12 Pro 5G (6.73")	16	Xiaomi 12 Pro 5G (6.73")	
Modèle	Produit																																		
1	Xiaomi 12 Pro 5G (6.73")																																		
2	Xiaomi 12 Pro 5G (6.73")																																		
3	Xiaomi 12 Pro 5G (6.73")																																		
4	Xiaomi 12 Pro 5G (6.73")																																		
5	Xiaomi 12 Pro 5G (6.73")																																		
6	Xiaomi 12 Pro 5G (6.73")																																		
7	Xiaomi 12 Pro 5G (6.73")																																		
8	Xiaomi 12 Pro 5G (6.73")																																		
9	Xiaomi 12 Pro 5G (6.73")																																		
10	Xiaomi 12 Pro 5G (6.73")																																		
11	Xiaomi 12 Pro 5G (6.73")																																		
12	Xiaomi 12 Pro 5G (6.73")																																		
13	Xiaomi 12 Pro 5G (6.73")																																		
14	Xiaomi 12 Pro 5G (6.73")																																		
15	Xiaomi 12 Pro 5G (6.73")																																		
16	Xiaomi 12 Pro 5G (6.73")																																		