

- Manuals.plus /
- > LUXOAK /
 - > LUXOAK 60" Farmhouse Coffee Bar Cabinet with Beverage Fridge (CBS107) User Manual

LUXOAK CBS107

LUXOAK 60" Farmhouse Coffee Bar Cabinet with Beverage Fridge (CBS107) User Manual

Model: CBS107 | Brand: LUXOAK

Introduction	Safety Information	Setup & Assembly	Operation	Maintenance	Troubleshooting
		Specifications	Warranty & Support		

1. INTRODUCTION

Thank you for choosing the LUXOAK 60" Farmhouse Coffee Bar Cabinet with Beverage Fridge. This manual provides essential instructions for the safe assembly, operation, and maintenance of your new cabinet. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image 1.1: The LUXOAK 60" Farmhouse Coffee Bar Cabinet with Beverage Fridge.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury and damage to the product:

- Always assemble the cabinet with **two people** to ensure stability and safety.
- Keep the area around the cabinet clear of obstructions to prevent tipping.
- Be cautious when opening and closing the doors to avoid injury from sudden movement.
- Always follow the assembly instructions carefully to avoid potential hazards.
- An anti-tip kit is included for enhanced stability. Ensure it is properly installed, especially in homes with pets or children.
- Do not overload shelves or drawers. Refer to specifications for weight limits.

3. SETUP & ASSEMBLY

The LUXOAK cabinet requires assembly. It is recommended that two people perform the assembly. The product will be delivered in multiple packages, which may arrive on different dates.

3.1 Unpacking and Inspection

- Carefully unpack all components and hardware.
- Verify that all parts listed in the instruction manual are present and undamaged. Contact customer support immediately if any parts are missing or damaged.
- Keep packaging materials until assembly is complete in case of returns or exchanges.

3.2 Assembly Instructions

Follow the detailed, easy-to-understand instructions provided in the separate assembly guide included with your product. Take your time and ensure each step is completed correctly.

Product Dimensions



≈ 24 cans



60"

34.9"

15.8"

5.7"

18"

37"

13.5"


22.9"

50 LBS

Wine Bar & Beverage Cooler, will be delivered in **2 Packages** and may **NOT** arrived on same date



Image 3.1: Product dimensions for assembly planning. The cabinet measures 60 inches in width, 34.9 inches in height, and 15.8 inches in depth. The internal shelf is 37 inches wide and 13.5 inches deep, supporting up to 50 lbs. The beverage fridge compartment is 22.9 inches high.



Magnetic Door Latch

The magnetic latch keeps the door securely closed, ensuring a tight seal and easy



Sturdy and Robust Legs

Built with thick, durable legs, this cabinet offers exceptional stability and support.

Image 3.2: Detail of the magnetic door latch for secure closure and the sturdy, robust legs providing exceptional stability and support for the cabinet.

3.3 Placement

- Choose a level, stable surface for the cabinet.
- Ensure adequate ventilation around the beverage fridge, especially at the back and sides.
- Avoid direct sunlight or heat sources, which can affect the fridge's performance.

4. OPERATION

4.1 Beverage Fridge Operation

The integrated beverage fridge features touch controls for temperature adjustment and quiet, energy-efficient cooling.

- **Temperature Control:** The fridge offers an adjustable temperature range from 41°F to 68°F (5°C to 20°C). Use the touch controls on the front panel to set your desired temperature. Long press to switch between Celsius and Fahrenheit.
- **Capacity:** The fridge has a 24-can capacity, suitable for various beverages, wine, or even small food items.
- **Adjustable Shelving:** The interior shelves are adjustable to accommodate different bottle and can sizes.
- **Synchronized Door Link:** The fridge door and the cabinet door open as one for a seamless, integrated feel.



Image 4.1: Close-up of the beverage fridge showing touch-to-set cooling controls, synchronized door link mechanism, and adjustable shelves for flexible storage.



Image 4.2: The smart control panel for the beverage fridge, allowing precise temperature adjustments and display.



Image 4.3: Illustration of the 41°F-68°F temperature range and examples of items that can be stored, including milk, cola, juice, champagne, wine, and beer.

4.2 Cabinet Storage

The cabinet offers flexible and ample storage solutions for various items.

- **Three Spacious Drawers:** Ideal for organizing tableware, snacks, coffee essentials, or barware. The drawers feature smooth metal rails for effortless movement.
- **Adjustable Shelving:** The main cabinet sections include adjustable shelves, allowing you to customize storage space to fit taller items or create multiple levels.
- **Magnetic Doors:** All cabinet doors are equipped with magnetic latches to ensure they stay securely closed, keeping dust out and contents protected.



Image 4.4: View of the 60-inch large countertop and the three spacious drawers, demonstrating their capacity for organizing various items like plates, cutlery, and small appliances.



Spacious Drawers

Three large drawers offer ample storage, keeping everything organized and within easy reach.



Smooth Metal Rails

Metal rails ensure smooth, effortless drawer movement every time.

Image 4.5: Detail showing the spacious drawers and the smooth metal rails that ensure easy and quiet operation.

4.3 Versatile Usage

This cabinet is designed for versatile use in various settings:

- **Coffee Bar:** Organize coffee makers, mugs, and supplies.
- **Wine Bar:** Store wine bottles, glasses, and accessories.
- **Buffet Sideboard:** Use in dining rooms for serving or extra storage.

Versatile Farmhouse Cabinet




Image 4.6: Examples of the cabinet's versatile use as a wine bar, coffee bar, or buffet sideboard in different home environments.

5. MAINTENANCE

5.1 Cabinet Care

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- For spills, wipe immediately to prevent staining.

- Periodically check and tighten any loose hardware.

5.2 Beverage Fridge Care

- Unplug the fridge before cleaning.
- Clean the interior with a mild detergent and warm water. Rinse thoroughly and dry.
- Clean the exterior with a soft, damp cloth.
- Ensure the ventilation grilles are free from dust and debris to maintain efficient cooling.

6. TROUBLESHOOTING

If you encounter issues with your LUXOAK cabinet or beverage fridge, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fridge not cooling	Power outage; Plug not fully inserted; Temperature setting too high; Blocked ventilation.	Check power supply; Ensure plug is secure; Adjust temperature setting; Clear any obstructions from vents.
Fridge is noisy	Normal compressor operation; Unit not level; Items inside vibrating.	Some noise is normal; Ensure the unit is level using adjustable feet; Rearrange items inside to prevent rattling.
Cabinet doors or drawers stick	Loose hardware; Misalignment during assembly; Obstruction.	Check and tighten all screws; Review assembly steps for proper alignment; Remove any obstructing items.
Cabinet feels unstable	Not on a level surface; Anti-tip kit not installed or improperly installed.	Move to a level surface or use shims; Ensure anti-tip kit is securely fastened to the wall and cabinet.

If the problem persists after attempting these solutions, please contact LUXOAK customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	LUXOAK
Model Name	bar cabinet-CBS107
Product Dimensions	15"D x 60"W x 35"H
Item Weight	151 Pounds
Color	Brown
Material	Wood
Mounting Type	Free Standing
Number of Shelves	3 (adjustable)

Feature	Detail
Beverage Fridge Temperature Range	41°F to 68°F (5°C to 20°C)
Beverage Fridge Capacity	24 cans
Assembly Required	Yes

8. WARRANTY & SUPPORT

8.1 Warranty Information

LUXOAK products are manufactured with quality and care. For specific warranty details regarding your 60" Farmhouse Coffee Bar Cabinet with Beverage Fridge, please refer to the warranty card included in your packaging or visit the official LUXOAK website. Warranty coverage typically includes defects in materials and workmanship under normal use.

8.2 Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact LUXOAK customer support. Have your model number (CBS107) and purchase information ready when contacting support.

- **Online Support:** Visit the LUXOAK official website for FAQs and contact forms.
- **Email Support:** Refer to your product packaging or the LUXOAK website for the customer service email address.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F3JP928X>

More documents and user manuals: <https://manuals.plus/>