

Qw5000-12d4

Quantum Audio 12-inch Car Subwoofer User Manual

Model: Qw5000-12d4 | Brand: Generic

INTRODUCTION

Thank you for choosing the Quantum Audio 12-inch Car Subwoofer. This manual provides essential information for the proper installation, operation, and maintenance of your new subwoofer. To ensure optimal performance and longevity, please read this manual thoroughly before installation and keep it for future reference.

This subwoofer is designed to deliver powerful and accurate bass response, enhancing your vehicle's audio system. It features a robust construction with a 5000W max power output and a dual 4-ohm voice coil design for versatile wiring options.

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product and your vehicle:

- **Professional Installation Recommended:** Due to the complexity of car audio systems and high power requirements, professional installation by a qualified technician is highly recommended.
- **Power Disconnection:** Always disconnect the vehicle's battery negative terminal before beginning any installation work to prevent electrical shorts.
- **Proper Wiring:** Ensure all wiring is correctly routed and secured to prevent pinching, chafing, or short circuits. Use appropriate gauge wiring for power, ground, and speaker connections.
- **Ventilation:** Ensure the subwoofer is installed in an enclosure that allows for adequate ventilation to prevent overheating, especially during prolonged high-power operation.
- **Volume Levels:** Prolonged exposure to high volume levels can cause hearing damage. Adjust volume to a comfortable level.
- **Secure Mounting:** Securely mount the subwoofer within its enclosure and the enclosure within the vehicle to prevent movement during driving, which could cause injury or damage.
- **Avoid Moisture:** This product is not water resistant. Avoid exposure to water or excessive moisture.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Quantum Audio 12-inch Car Subwoofer

- Mounting Hardware (screws, clips, etc., as applicable)

PRODUCT OVERVIEW

The Quantum Audio 12-inch Car Subwoofer is engineered for high-performance bass reproduction. Key features include a robust motor structure, dual voice coils, and durable cone materials.



Figure 1: Front view of the Quantum Audio 12-inch Car Subwoofer. This image highlights the compressed paper cone, high-excursion foam surround, and the injection-molded PP dust cap featuring the Quantum Audio logo and "5000 WATTS" power rating.



Figure 2: Rear view of the Quantum Audio 12-inch Car Subwoofer. This view displays the heavy-gauge stamped steel basket, the protective magnet cover, and the heavy-gauge spring terminals for secure wiring connections. The dual voice coil design is evident from the two sets of terminals.

The subwoofer features a 3-inch (76.2mm) 4-layer aluminum voice coil on a QEMT aluminum former for superior heat dissipation. The high-excursion foam surround and compressed paper cone ensure deep and accurate bass reproduction.

SETUP AND INSTALLATION

Proper installation is crucial for the performance and safety of your subwoofer. It is highly recommended to have this unit installed by a certified car audio professional.

Enclosure Requirements

This subwoofer requires a properly designed and constructed enclosure for optimal performance. Consult with a car audio specialist or refer to online resources for recommended sealed or ported enclosure volumes and tuning frequencies for a 12-inch subwoofer with its specific parameters (F_s , Q_{ts} , V_{as}).

Wiring Connections

The Quantum Audio subwoofer features a dual 4-ohm voice coil (DVC) design, offering flexibility in wiring configurations to match your amplifier's impedance requirements. Common wiring options include:

- **1-ohm Load (Parallel Wiring):** Connect both voice coils in parallel. This configuration results in a 1-ohm total impedance, suitable for amplifiers stable at 1-ohm.
- **8-ohm Load (Series Wiring):** Connect both voice coils in series. This configuration results in an 8-ohm total impedance, suitable for amplifiers that require a higher impedance load.

Always ensure correct polarity (+ to + and - to -) for all connections. Incorrect wiring can lead to poor performance or damage to the subwoofer and amplifier. Use high-quality, appropriately gauged speaker wire for all connections.

Power and Ground Connections

- **Power Wire:** Connect the amplifier's positive (+) terminal to the vehicle's battery positive (+) terminal using a heavy-gauge power wire (e.g., 4-gauge or 0-gauge depending on amplifier power) with an inline fuse located within 18 inches of the battery.
- **Ground Wire:** Connect the amplifier's negative (-) terminal to a clean, unpainted metal surface on the vehicle's chassis, ensuring a solid ground connection. Use a ground wire of the same gauge as the power wire and keep it as short as possible.

Signal Connections

Connect the amplifier's input to your head unit's RCA pre-outs. Ensure the remote turn-on wire is connected from the head unit to the amplifier to allow the amplifier to power on and off with the vehicle's audio system.

OPERATING INSTRUCTIONS

Once installed, follow these steps to operate your subwoofer system:

1. **Initial Power-Up:** After all connections are made and verified, reconnect the vehicle's battery. Turn on your head unit.
2. **Amplifier Settings:** Adjust your amplifier's gain (input sensitivity) setting carefully. Start with the gain at minimum and slowly increase it until the desired volume is achieved without distortion. Avoid setting the gain too high, as this can lead to clipping and damage to the subwoofer.
3. **Crossover Settings:** Set the low-pass filter (LPF) on your amplifier or head unit to filter out frequencies above the subwoofer's optimal range (typically 80Hz-120Hz). This ensures the subwoofer only reproduces bass frequencies.
4. **Bass Boost/EQ:** Use bass boost and equalization settings sparingly. Excessive boosting can cause distortion and potential damage.
5. **Break-in Period:** Allow a break-in period of approximately 20-30 hours of moderate listening before operating the subwoofer at its maximum potential. This allows the suspension components to loosen up and perform optimally.

MAINTENANCE

The Quantum Audio subwoofer requires minimal maintenance to ensure long-term performance:

- **Cleaning:** Periodically wipe the subwoofer's cone and surround with a soft, dry cloth to remove dust and debris. Do not use harsh chemicals or solvents.
- **Inspection:** Regularly inspect all wiring connections to ensure they are secure and free from corrosion. Check the subwoofer's surround for any signs of cracking or damage.
- **Environmental Factors:** Avoid exposing the subwoofer to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.

TROUBLESHOOTING

If you experience issues with your subwoofer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Sound from Subwoofer	No power to amplifier Loose or incorrect wiring Amplifier in protect mode Head unit settings	Check power, ground, and remote turn-on connections to amplifier. Verify all speaker and RCA connections are secure and correct. Check amplifier's fuse. Disconnect power, wait, and reconnect. Ensure subwoofer output is enabled and volume is up on head unit.
Distorted Sound	Amplifier gain set too high (clipping) Incorrect crossover settings Damaged subwoofer or voice coil Poor enclosure design	Reduce amplifier gain until distortion disappears. Adjust LPF to appropriate frequency (e.g., 80-120Hz). Inspect subwoofer for physical damage. If damaged, replacement may be necessary. Ensure enclosure meets recommended specifications.
Subwoofer Overheating	Amplifier gain too high Improper impedance match Inadequate ventilation Prolonged high-power operation	Reduce amplifier gain. Verify voice coil wiring matches amplifier's stable impedance. Ensure enclosure and installation location allow for airflow. Reduce listening volume or take breaks during extended use.

If the problem persists after attempting these solutions, contact a qualified car audio technician or the product's support for further assistance.

SPECIFICATIONS

Feature	Specification
Model Name	Qw5000-12d4
Speaker Type	Subwoofer
Subwoofer Diameter	12 Inches
Max Power Output	5000 Watts
RMS Power	1500 Watts
Impedance	Dual 4 Ohm (DVC)
Voice Coil	3-inch (76.2mm) 4-layer Aluminum Voice Coil Former
Cone Material	Compressed Paper
Surround Material	High-excursion Foam
Basket Material	Heavy Gauge Stamped Steel

Feature	Specification
Dust Cap	Injection Molded PP
Gasket	Proprietary Full Round PVC
Terminals	Heavy Gauge Spring Terminals
Product Dimensions (D x W x H)	12"D x 12"W x 12"H
Item Weight	25 Pounds
Signal-to-Noise Ratio	90 dB
Frequency Response	20 Hz
Connectivity Technology	Wired
Recommended Uses	Bass Enhancement, Car Audio, Sound Systems

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

This Quantum Audio product is covered by a limited warranty. Please refer to the warranty card included with your purchase or visit the manufacturer's official website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact the retailer where you purchased the product or the manufacturer's customer service department. Have your model number (Qw5000-12d4) and proof of purchase ready when contacting support.

Contact Information:

- Refer to your purchase documentation for retailer contact details.
- For manufacturer support, search for "Quantum Audio customer service" online.

© 2025 Generic. All rights reserved. Quantum Audio is a brand of Generic.

This manual is for informational purposes only. Generic assumes no responsibility for errors or omissions in this manual or for damages resulting from the use of the information contained herein.