

## BEYNIVAN M986-EEA

# BEYNIVAN 11-inch Tablet User Manual

Model: M986-EEA

This manual provides comprehensive instructions for the setup, operation, and maintenance of your BEYNIVAN 11-inch Android 14 Tablet.

## 1. INTRODUCTION

Thank you for choosing the BEYNIVAN 11-inch Tablet. This device is designed to provide a versatile and powerful computing experience, featuring Android 14, robust connectivity options, and a high-resolution display. To ensure optimal performance and longevity, please read this manual thoroughly before using the tablet.

## 2. WHAT'S INCLUDED

The BEYNIVAN 11-inch Tablet package includes the following items:

- BEYNIVAN 11-inch Tablet
- Protective Case
- Bluetooth Keyboard
- Wireless Mouse
- Stylus Pen
- Charger
- OTG Interface Adapter
- Data Cable (USB-C)
- User Manual (this document)



**11-Inch Tablet**



**11-Inch Case**



**Bluetooth Keyboard**



**Wireless Mouse**



**Stylus Pen**



**charger**



**OTG Interface**



**Data cable**



**Tablet User Manual**

Image: All accessories included with the BEYNIVAN 11-inch Tablet, neatly arranged. This includes the tablet, a protective case, a Bluetooth keyboard, a wireless mouse, a stylus pen, a charger, an OTG adapter, a data cable, and the user manual.

### **3. PRODUCT OVERVIEW**

Familiarize yourself with the physical components of your BEYNIVAN tablet.



Image: The BEYNIVAN 11-inch Tablet displayed with its keyboard case, showcasing the screen and the rear view of the tablet. Key features like 4G LTE, 5G WiFi, 36GB RAM, 256GB ROM, 11-inch 2K HD display, and Android 14 are highlighted on the screen.

## Key Features:

- **Display:** 11-inch Incell FHD screen with 2000 x 1200 resolution, up to 120Hz refresh rate, and TÜV certification for reduced eye strain.
- **Processor:** 2.0 GHz Octa-Core Processor for smooth performance.
- **Memory:** 36GB RAM (12GB physical + 24GB expandable) and 256GB ROM. Expandable up to 1TB via Micro SD card (sold separately).
- **Operating System:** Android 14 OS with intelligent AI functions and enhanced security.
- **Connectivity:** 4G LTE (SIM slot required, SIM card not included) and Dual-band 5G WiFi (802.11ac), Bluetooth 5.0.
- **Cameras:** 8MP Front Camera, 13MP Rear Camera + 2MP Macro Camera.
- **Battery:** 9580 mAh with intelligent AI power management, offering up to 560 hours standby time.
- **Audio:** 4 Stereo Speakers with AI Noise Cancellation.
- **Navigation:** Supports GPS, Beidou, GLONASS, Galileo.
- **Security:** Face ID unlock.

**2000\*1200, Incell original  
colour full screen**



**metal border, Slim and lightweight**



**36(12+24)GB RAM  
256GB ROM**



**9580  
mAh**

Image: A visual representation of the tablet's core specifications, including the 11-inch 2000x1200 Incell screen, metal border design, 36GB RAM (12+24GB), 256GB ROM, Octa-core 2.0 GHz processor, and 9580 mAh battery capacity.

## 11 Inches Made For You



11 inches  
**Maximum Screen Size**



2000\*1200 FHD resolution  
**16:10 Screen Ratio**



Wear-resistant and sweat-resistant  
**Wide Viewing Angle Incell Display**



## Sleek, Elegant And Lightweight Metal Body



Metal body  
**Straight Edge**




Display Bezel  
**7.8 mm**



Slim and portable  
**760g**



## Explore Smoothly, Connect Swiftly



Dual-band  
Wi-Fi



BT 5.0

## Cellular When You Need It



LTE Support  
**4G LTE TDD+FDD**



Call and Browse  
**VoLTE**




Image: Details on the 11-inch FHD screen with 2000x1200 resolution, 16:10 screen ratio, wide viewing angle Incell display, and the sleek, lightweight metal body with a 7.8mm display bezel. Also highlights dual-band Wi-Fi, Bluetooth 5.0, and 4G LTE support for cellular connectivity and VoLTE calls.

## 4. SETUP

### 4.1 Charging the Tablet

Before first use, fully charge your tablet using the provided charger and USB-C data cable. Connect the USB-C cable to the tablet's charging port and the charger to a power outlet. The battery indicator on the screen will show charging progress.

### 4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the BEYNIVAN logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

### 4.3 Inserting SIM Card (Optional)

The tablet supports 4G LTE connectivity. To use cellular data and make calls, you will need a compatible SIM card (not included).

1. Locate the SIM card tray on the side of the tablet.
2. Use the SIM ejector tool (if provided, otherwise a thin pin) to open the tray.
3. Carefully place your SIM card into the designated slot on the tray. Ensure correct orientation.
4. Gently push the tray back into the tablet until it clicks into place.

#### 4.4 Inserting Micro SD Card (Optional)

To expand storage, you can insert a Micro SD card (up to 1TB, not included).

1. Locate the Micro SD card slot, often combined with the SIM tray or a separate slot.
2. Insert the Micro SD card into the slot with the gold contacts facing down, until it clicks into place.
3. To remove, gently push the card in until it springs out.

#### 4.5 Connecting Accessories (Keyboard, Mouse, Stylus)

The tablet comes with a Bluetooth keyboard, a wireless mouse, and a stylus pen.

- **Bluetooth Keyboard:**

- a. Ensure the keyboard is charged and powered on.
- b. On your tablet, go to **Settings > Connected devices > Bluetooth**.
- c. Turn on Bluetooth and scan for devices.
- d. Select the keyboard from the list and follow on-screen pairing instructions.

- **Wireless Mouse:**

- a. Insert the USB receiver of the wireless mouse into the OTG interface adapter.
- b. Connect the OTG interface adapter to the tablet's USB-C port. The tablet should automatically detect the mouse.

- **Stylus Pen:** The stylus pen is generally passive and does not require pairing. Simply use it directly on the screen.

## 5. OPERATING THE TABLET

---

### 5.1 Android 14 Basics


Your tablet runs on Android 14, offering an intuitive and customizable user experience.

- **Home Screen:** Swipe left/right to navigate between home screens. Long-press on an empty area to customize wallpaper, widgets, and settings.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings toggles (Wi-Fi, Bluetooth, brightness, etc.).
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.
- **Multitasking:** Tap the square navigation button (or swipe up and hold from the bottom if using gesture navigation) to see recently opened apps. You can switch between them or close them. Android 14 also supports split-screen sharing for running two apps side-by-side.

## New Android 15 tablet, New upgrade, New experience!

BEYNIVAN Tablet Android 15, leverages the power of artificial intelligence to give you a more personalized

- AI Feature-Quick Smart Reply
- Multitasking Window
- Privacy Protection
- Scale font size up to 200%
- Lock screen customisation elements



## Experience The Speed And Passion

- Octa-Core 2.0 GHz
- Game Performance 68%
- Running Speed 79%



Image: A visual representation of the Android interface on the BEYNIVAN Tablet, highlighting new features such as AI capabilities, quick smart reply, multitasking window, privacy protection, lock screen customization, and scalable font size up to 200%. Note: While the image displays "Android 15", the product specifications confirm Android 14.

### 5.2 Internet Connectivity

- Wi-Fi:** Go to **Settings > Network & internet > Wi-Fi**. Turn on Wi-Fi, select your network, and enter the password if required.
- Mobile Data (4G LTE):** If a SIM card is inserted, go to **Settings > Network & internet > Mobile network** to enable mobile data.

### 5.3 Camera Usage

The tablet features an 8MP front camera and a 13MP + 2MP Macro rear camera.

- Open the "Camera" application.
- Tap the shutter button to take photos.
- Switch between front and rear cameras using the camera toggle icon.
- Explore different modes like video, portrait, or macro (if available in the camera app).

-  Games  
**9.5 hours**
-  Web  
**24 hours**
-  Music  
**19 hours**
-  appel  
**17 hours**
-  Standby  
**560 hours**





# 9580mAh

## Capture More Wonderful Moments

-  Auto Focus  
**Front 8MP**
-  HD Video Call  
**Rear 13MP**
-  Low Light  
**LED Flash**
-  Capture Unlock  
**Face**



## Facial Unlock Convenient and Fast

-  Night-time  
Low Blue
-  Light Mode




Image: This image illustrates the tablet's camera capabilities, including an 8MP auto-focus front camera and a 13MP HD video call rear camera with a 2MP macro lens and LED flash. It also highlights the facial unlock feature for convenient and fast access, showing a user unlocking the tablet with their face.

### 5.4 Facial Unlock

To set up Face ID for convenient unlocking:

1. Go to **Settings > Security & privacy > Face unlock**.
2. Follow the on-screen instructions to register your face.
3. Ensure you are in a well-lit environment during setup.

### 5.5 GPS Navigation

The tablet supports multiple navigation systems (GPS/Beidou/GLONASS/Galileo) for precise positioning. Use mapping applications to utilize this feature.

## 6. MAINTENANCE

## 6.1 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold), as this can degrade battery life.
- Do not let the battery completely drain frequently. Charge it before it reaches 0%.
- Use only the provided charger and cable to prevent damage.
- If storing the tablet for an extended period, charge it to about 50-60% and power it off.

## 6.2 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

## 6.3 Software Updates

Periodically check for system updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings > System > System update**.

## 7. TROUBLESHOOTING

Problem	Possible Solution
Tablet does not power on.	Ensure the tablet is charged. Connect it to the charger for at least 30 minutes, then try powering on again.
Screen is unresponsive.	Restart the tablet by holding the Power button for about 10-15 seconds until it reboots. If the issue persists, perform a factory reset (data will be lost).
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Ensure the password is correct. Restart your router and the tablet. Try connecting to a different Wi-Fi network.
SIM card not detected.	Ensure the SIM card is correctly inserted and activated by your carrier. Restart the tablet. Try the SIM card in another compatible device to check if it's functional.
Bluetooth accessories won't pair.	Ensure the accessory is in pairing mode and fully charged. Turn Bluetooth off and on again on the tablet. Restart both devices.
Tablet is running slow.	Close unnecessary background applications. Clear cache for frequently used apps. Check for system updates. Consider uninstalling unused apps.
Face ID not working.	Ensure you are in a well-lit environment. Re-register your face in the security settings. Clean the front camera lens.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BEYNIVAN
Model Number	M986-EEA

Feature	Detail
Series	P7-EEA
Color	Black
Operating System	Android 14
Processor Brand	Qualcomm
Processor Description	Octa-core processor
Screen Size	11 Inches
Screen Resolution	2000 x 1200 pixels
Graphics Card Description	Integrated
Connectivity Type	Cellular, Wi-Fi
Wireless Technology Type	802.11ac (5G WiFi)
Hardware Interface	USB
RAM Installed Size	36 GB (12GB + 24GB expandable)
Memory Storage Capacity	256 GB
Expandable Storage	Up to 1 TB via Micro SD card (not included)
Battery	9580 mAh (1 x 9V battery included)
Front Camera	8 MP
Rear Camera	13 MP + 2 MP Macro
Dimensions	33.79 x 19.7 x 3.9 cm
Weight	1.37 kilograms

## 9. WARRANTY AND SUPPORT

BEYNIVAN offers 24-hour online support for any issues you may encounter with your tablet. If you experience problems such as lost accessories or tablet malfunctions, please do not hesitate to contact us via Amazon email. We are committed to resolving your concerns promptly.

For specific warranty details, please refer to the warranty card included in your product packaging or contact BEYNIVAN customer service directly.



