Titan W0102PM01

Titan Pendulum Wall Clock W0102PM01 Instruction Manual

Model: W0102PM01

Introduction

This manual provides instructions for the setup, operation, and maintenance of your Titan Pendulum Wall Clock, Model W0102PM01. This clock features a classic design with a wood-finish plastic case, Westminster chime with an automatic night silencer, and a silent sweep movement.

Safety Information

- Ensure the clock is securely mounted to prevent falling. Use appropriate wall anchors for your wall type.
- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Handle batteries according to their instructions. Do not mix old and new batteries, or different types of batteries. Remove depleted batteries promptly to prevent leakage.
- Keep out of reach of children to prevent accidental ingestion of small parts or batteries.

Package Contents

Verify that all items are present in the package:

- Titan Pendulum Wall Clock (Model W0102PM01)
- 1 x AA Battery
- 1 x Wall Plug
- 1 x Mounting Screw



Image: Front view of the Titan Pendulum Wall Clock W0102PM01, showing the classic brown wood-finish case, white dial with Arabic numerals, and the pendulum.

Setup

1. **Battery Installation:**

   Open the battery compartment cover located on the back of the clock. Insert the provided AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Close the cover securely.



Image: Rear view of the clock, highlighting the battery compartment and mounting point.

2. **Setting the Time:**

   Locate the time setting knob on the back of the clock. Gently turn the knob clockwise to set the correct time. Avoid turning counter-clockwise as this may damage the movement.

3. **Pendulum Setup:**

   Carefully remove any protective packaging from the pendulum. Ensure the pendulum is hanging freely and can swing without obstruction. The pendulum is decorative and does not affect timekeeping.

4. **Mounting the Clock:**

   Choose a suitable location on a wall. Drill a hole, insert the wall plug, and then screw in the mounting screw, leaving a small portion exposed. Hang the clock securely onto the screw using the hanging slot on the back. Ensure the clock is level and stable.



Image: The Titan Pendulum Wall Clock W0102PM01 displayed on a wall, illustrating its appearance in a home setting.

Operating Instructions

- **Silent Sweep Movement:**

  Your clock is equipped with a silent sweep second hand, ensuring quiet operation without any ticking sounds. This makes it suitable for bedrooms, offices, and other quiet environments.

- **Westminster Chime:**

  The clock features an hourly Westminster chime. The chime will sound on the hour, playing a traditional melody.

- **Automatic Night Silencer:**

  The Westminster chime includes an automatic night silencer function. The chime will automatically cease sounding during nighttime hours (typically between 10:00 PM and 5:00 AM) to ensure undisturbed sleep. It will resume automatically in the morning.

- **Adjustable Volume:**

  A volume control knob for the chime is located on the back of the clock. Turn the knob to adjust the chime volume to your preference.

Maintenance

- **Cleaning:**

  Wipe the clock's surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish.

- **Battery Replacement:**

  Replace the battery annually or when the clock starts losing time or the chime weakens. Always use a fresh AA battery. Dispose of old batteries responsibly.

Troubleshooting

Problem	Possible Cause	Solution
Clock not running	Depleted or incorrectly installed battery.	Check battery polarity. Replace with a fresh AA battery.
Chime not sounding	Volume too low, night silencer active, or battery low.	Increase chime volume. Wait until morning if night silencer is active. Replace battery.
Clock losing or gaining time	Low battery power.	Replace with a fresh AA battery.

Specifications

Model Number	W0102PM01
Brand	Titan
Dimensions (W x H)	31 cm x 52 cm
Weight	1300 Grams
Material	Plastic (Wood-finish)
Display Type	Analog, Arabic Numerals
Movement	Silent Sweep
Power Source	1 x AA Battery (included)
Special Features	Westminster Chime, Auto Night Silencer, Adjustable Volume, Pendulum
Mounting Type	Wall Mount




Image: Diagram showing the dimensions of the clock: 52 cm height and 31 cm width.

Warranty and Support

This Titan Pendulum Wall Clock (Model W0102PM01) comes with a**1-year manufacturer warranty** against manufacturing defects from the date of purchase.
For warranty claims or technical support, please contact Titan customer service. Keep your purchase receipt as proof of purchase.
Manufacturer Contact Information:
Titan Company Limited, #3, SIPCOT Industrial Complex, Hosur - 635126, Tamil Nadu, India
Telephone: +91-(0)4344-664199

© 2026 Titan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question