

[Manuals.plus](#) /

› [Tombow](#) /

› Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set Instruction Manual

Tombow 913S2

Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set Instruction Manual

Model: 913S2

INTRODUCTION

Thank you for purchasing the Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set. This manual provides essential information for the proper use, care, and maintenance of your new stationery set. Please read this manual thoroughly before use to ensure optimal performance and longevity of the products.

PRODUCT OVERVIEW

The 913S2 Shell Beige Set includes a selection of Tombow writing and erasing tools designed for daily use. The set typically contains:

- **Tombow MONO graph Mechanical Pencil:** A high-quality mechanical pencil with a shake-mechanism and rotating eraser.
- **Tombow MONO graph Pen:** A smooth-writing pen, often a ballpoint or gel pen, designed to complement the mechanical pencil.
- **Tombow MONO one Eraser:** A compact, stick-type eraser for precise corrections.
- **Tombow MONO Plastic Eraser:** A classic block eraser for general erasing needs.
- **Tombow MONO Holder Eraser:** A pen-style eraser for detailed work.



Image: The Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set, showcasing the mechanical pencil, pen, stick eraser, block eraser, and holder eraser, all packaged together. The items feature a consistent shell beige color scheme.

Mechanical Pencil (MONO graph)

1. **Loading Lead:** Remove the eraser cap at the top. Insert lead refills into the lead reservoir. Do not overfill.
2. **Advancing Lead:** Shake the pencil up and down to advance the lead, or press the clip down.
3. **Eraser Replacement:** Pull out the existing eraser. Insert a new Tombow MONO graph replacement eraser.

Pen (MONO graph Pen)

The pen is ready for immediate use. If it is a retractable pen, click the top button to extend/retract the tip. If it is a cap-type pen, remove the cap before use.

Erasers (MONO one, MONO Plastic, MONO Holder)

These erasers are ready for use out of the packaging. For the MONO one and MONO Holder erasers, twist or click to extend the eraser stick as needed.

OPERATING INSTRUCTIONS

Writing with MONO graph Mechanical Pencil

- Hold the pencil comfortably.
- Advance lead by shaking or pressing the clip.
- Apply light to moderate pressure for writing.

Writing with MONO graph Pen

- Ensure the pen tip is extended (if retractable) or cap is removed.
- Write smoothly on paper.

Erasing with MONO Erasers

- **MONO graph Eraser (built-in):** Twist the top to extend the eraser. Use for small corrections.
- **MONO one / MONO Holder Eraser:** Extend the eraser by twisting or clicking. Ideal for precise erasing.
- **MONO Plastic Eraser:** Use the block eraser for larger areas or general erasing.
- Always erase gently to avoid damaging paper.

MAINTENANCE AND CARE

- Store all items in a cool, dry place away from direct sunlight to prevent material degradation.
- Avoid dropping the mechanical pencil or pen, as this can damage the internal mechanisms or lead.
- Keep erasers clean by rubbing them on a scrap piece of paper to remove graphite residue.
- Use only genuine Tombow replacement leads and erasers for optimal performance.
- Do not attempt to disassemble the products beyond normal lead/eraser replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mechanical pencil lead does not advance.	No lead inside; lead jammed; incorrect lead size.	Insert new lead. Gently tap the pencil to dislodge jam. Ensure correct lead diameter is used.
Pen ink is faint or skips.	Ink cartridge is empty; tip is dry or clogged.	Replace ink cartridge (if applicable). Try writing on a scrap piece of paper to prime the tip.

Problem	Possible Cause	Solution
Eraser leaves smudges.	Eraser is dirty; paper quality; excessive pressure.	Clean eraser by rubbing on scrap paper. Use lighter pressure.

SPECIFICATIONS

Product Name: Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set

Model Number: 913S2

Brand: Tombow

Components: MONO graph Mechanical Pencil, MONO graph Pen, MONO one Eraser, MONO Plastic Eraser, MONO Holder Eraser

Color: Shell Beige (Mineral Color Series)

ASIN: B0F3NR7P7T

First Available Date: April 4, 2025

WARRANTY AND SUPPORT

Tombow products are manufactured to high-quality standards. For specific warranty information or support regarding your Tombow Pencil Mineral Color Product Group MIX Original 913S2 Shell Beige Set, please refer to the official Tombow website or contact their customer service directly. Keep your purchase receipt as proof of purchase. For further assistance, you may visit the official Tombow website:www.tombow.com

