

Lamshaw B0F3NZK8J4

Lamshaw Magnetic Charger for Voistek Bone Conduction Headphones - User Manual

Model: B0F3NZK8J4

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Lamshaw Magnetic Charging Cable, designed specifically for Voistek Bone Conduction Headphones. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

PACKAGE CONTENTS

- 1 x Lamshaw Magnetic Charging Cable (White)

SETUP

1. **Connect to Power Source:** Insert the USB-A end of the charging cable into a compatible USB power adapter (not included), a computer's USB port, or a power bank. Ensure the power source provides stable power.
2. **Connect to Headphones:** Align the magnetic charging pins of the cable with the charging contacts on your Voistek Bone Conduction Headphones. The magnetic connection will automatically snap into place.

Magnetic Charging




Image: Illustration of the magnetic charging connection between the cable and the headphones. The cable's pins align with the headphone's contacts, showing the magnetic attraction.

Once connected, your headphones should indicate that they are charging (e.g., via an LED indicator on the headphones, if applicable).

OPERATING INSTRUCTIONS

- **Charging Process:** After establishing the magnetic connection, the headphones will begin to charge. The charging status is typically indicated by an LED on the headphones themselves.
- **Charging Time:** Charging time may vary depending on the battery level of your headphones and the power output of your USB adapter. Refer to your headphone's manual for specific charging duration.
- **Disconnection:** To disconnect, gently pull the magnetic connector away from the headphones.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the charging cable and its magnetic contacts. Avoid using liquids or abrasive cleaners.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Do not bend or twist the cable excessively. Avoid placing heavy objects on the cable. Ensure the magnetic contacts are kept clean and free from debris to maintain a reliable connection.

TROUBLESHOOTING

Issue: Headphones are not charging.

- Ensure the USB-A end is securely connected to a working power source.
- Verify that the magnetic contacts on both the cable and headphones are clean and properly aligned.
- Try using a different USB power adapter or port.
- Check if the headphones themselves are functioning correctly with their original charger (if available).

Issue: Charging is slow or intermittent.

- Ensure the power source provides sufficient output (e.g., a standard 5V/1A USB adapter).
- Clean the magnetic contacts on both the cable and headphones.
- Avoid using the headphones while charging, as this can slow down the process.

Issue: Magnetic connection is weak or unstable.

- Ensure there is no debris or foreign material on the magnetic contacts.
- Verify that the cable is designed for your specific Voistek Bone Conduction Headphones model.

SPECIFICATIONS

- **Brand:** Lamshaw
- **Model:** B0F3NZK8J4
- **Connector Type:** 4-Pin Magnetic
- **Compatible Devices:** Voistek Bone Conduction Headphones
- **Included Components:** Charging Cable
- **Special Feature:** Lightweight
- **Color:** White
- **Cable Length:** 1 Meter

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase platform or contact the seller directly. Keep your purchase receipt for warranty claims.

© 2025 Lamshaw. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F3NZK8J4>

More documents and user manuals: **<https://manuals.plus/>**