Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECCO 538824-01001

ECCO Mens Leisure 538824 Leather Black Shoes User Manual

Model: 538824-01001

1. Product Overview

The ECCO Mens Leisure 538824 Leather Black Shoes are designed for comfort and style, featuring a slip-on design for ease of wear. These shoes are crafted with high-quality materials to provide durability and support for everyday use.



Image: Side view of the ECCO Mens Leisure 538824 Leather Black Shoes, showcasing the black leather upper and white sole.

2. Key Features

- **Premium Leather Upper:** Provides a stylish, durable, and comfortable fit.
- **Soft Textile Lining:** Enhances comfort and breathability for prolonged wear.
- **Breathable Footbed:** Offers all-day cushioning and support.
- **Effortless Slip-On Closure:** Designed for easy wear and convenience.
- **Durable Rubber Sole:** Ensures superior traction and long-lasting wear.

3. Setup and First Use

These ECCO Leisure shoes are designed for immediate wear. Follow these simple steps for optimal comfort:

1. **Unboxing:** Carefully remove the shoes from their packaging.
2. **Inspection:** Before wearing, inspect both shoes for any visible defects or damage.
3. **Wearing:** Due to their slip-on design, simply slide your feet into the shoes. Ensure your heel is comfortably seated at the back of the shoe.
4. **Fit Check:** Walk a few steps to ensure a comfortable and secure fit. There should be adequate space for your toes, and your heel should not slip excessively.



Image: Front view of the ECCO Mens Leisure 538824 Leather Black Shoes, showing the slip-on opening.

4. Operating and Daily Use

The ECCO Mens Leisure shoes are intended for casual and everyday wear. Their design prioritizes comfort and ease of use.

- **Comfort:** The breathable footbed and soft textile lining are designed to provide comfort throughout the day.
- **Traction:** The durable rubber sole offers reliable traction on various surfaces, suitable for urban environments.
- **Versatility:** These shoes are suitable for a range of casual activities, from walking to daily errands.



Image: Rear view of the ECCO Mens Leisure 538824 Leather Black Shoes, highlighting the heel construction.

5. Care and Maintenance

Proper care will extend the life and appearance of your ECCO Mens Leisure Leather Shoes. As they feature a leather upper and fabric lining, specific care is recommended:

- **Cleaning Leather:**
  - Wipe off dirt and dust with a soft, damp cloth.
  - For deeper cleaning, use a specialized leather cleaner according to its instructions.
  - Allow leather to air dry naturally, away from direct heat or sunlight.
  - Apply a leather conditioner periodically to keep the leather supple and prevent cracking.
- **Cleaning Soles:**
  - Clean the rubber soles with a brush or damp cloth to remove dirt and debris.
- **Storage:** Store shoes in a cool, dry place, preferably with shoe trees to maintain their shape. Avoid storing in direct sunlight or extreme temperatures.
- **Avoid Water Immersion:** While the shoes are durable, prolonged exposure to water should be avoided to protect the leather.



Image: View of the sole of the ECCO Mens Leisure 538824 Leather Black Shoes, showing the tread pattern and ECCO branding.

6. Troubleshooting

This section addresses common questions and minor issues you might encounter with your ECCO Mens Leisure shoes.

Problem	Possible Cause	Solution
Shoes feel too tight/loose.	Incorrect size or initial break-in period.	Ensure you have selected the correct size. Leather shoes may require a short break-in period to conform to your foot. If discomfort persists, consider consulting a shoe specialist.
Squeaking noise when walking.	Moisture trapped between sole layers or new sole material.	Ensure shoes are completely dry. A light application of talcum powder under the insole can sometimes help. New soles may squeak initially until worn in.
Leather appears dull or dry.	Lack of conditioning or exposure to harsh elements.	Clean the leather and apply a quality leather conditioner or cream. Regular conditioning is key to maintaining leather health.

7. Specifications

Attribute	Detail
Model Number	538824-01001
Brand	ECCO
Upper Material	Leather
Inner Material	Fabric
Sole Material	Rubber

Attribute	Detail
Closure Type	Pull-On (Slip-On)
Product Dimensions	13.39 x 7.09 x 4.92 inches
Item Weight	3.31 Pounds
Department	Mens
Date First Available	April 4, 2025

8. Warranty and Support

For specific warranty information regarding your ECCO Mens Leisure 538824 Leather Black Shoes, please refer to the documentation provided with your purchase or visit the official ECCO website. ECCO typically offers a limited warranty against manufacturing defects.

If you require technical support, have questions about product care, or need assistance with a warranty claim, please contact ECCO customer service directly. You can often find contact details on the ECCO official website or through the retailer where the product was purchased.

ECCO Official Website: https://us.ecco.com/

For purchases made on Amazon, you may also contact the seller,SHOES Outlet, for order-specific inquiries.

© 2025 ECCO. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3P5NNH6

More documents and user manuals: **https://manuals.plus/**