

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Doro](#) /

› [Doro Aurora A10 Mobile Phone User Manual](#)

Doro 8881

Doro Aurora A10 Mobile Phone User Manual

Model: 8881

INTRODUCTION

This manual provides comprehensive instructions for the Doro Aurora A10 Mobile Phone. It covers setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device. The Doro Aurora A10 is designed for ease of use, featuring a large screen, practical buttons, clear sound, and an SOS button for enhanced security.

WHAT'S INCLUDED

Upon unboxing your Doro Aurora A10, please ensure all components are present:

- Doro Aurora A10 Mobile Phone
- USB Cable
- *(Other accessories may vary by package)*





Image: The Doro Aurora A10 mobile phone, showing its front and back, alongside the included USB cable.

SETUP

1. Inserting the SIM Card and Battery

Before first use, you will need to insert your SIM card.

1. Locate the SIM card slot, typically on the side or under the back cover.
2. Carefully insert your SIM card into the designated slot, ensuring correct orientation.
3. The Doro Aurora A10 comes with an included 9V battery. Ensure it is properly seated in its compartment.
4. Replace the back cover securely.

2. Initial Power On and Setup Wizard

To power on your phone for the first time:

1. Press and hold the power button until the screen illuminates.

2. Follow the on-screen setup wizard to select your language, connect to Wi-Fi, and set up your Google account.
3. The Doro Easy Interface will guide you through the initial settings, simplifying the process.



Image: A visual representation of the Doro Aurora A10 highlighting its key features such as the Easy Interface, Doro Secure Button, ClearSound technology, and physical tactile buttons.

OPERATING YOUR DORO AURORA A10

Basic Navigation

The Doro Aurora A10 features a user-friendly interface with intuitive navigation.

- **Touchscreen:** Navigate by tapping, swiping, and pinching on the screen.
- **Physical Buttons:** Utilize the tactile call buttons for easy answering and ending calls.
- **Doro Easy Call & Home Keys:** Dedicated keys simplify common actions.

Making and Receiving Calls

To make a call, tap the "Phone" icon and dial the number, or select a contact. To receive a call, press the green call button. The Doro ClearSound technology ensures clear audio during conversations, and the phone is compatible with hearing aids (HAC).

Using the Camera

The phone is equipped with a 13MP camera. Open the "Camera" application to capture photos and videos.



Image: A detailed view of the Doro Aurora A10's user-friendly interface, highlighting features like hearing aid compatibility, Doro Easy Call & Home keys, the 13MP main camera, and remote support capabilities.

Doro Secure Button

The Doro Secure Button is a key safety feature. In an emergency, simply press the dedicated button on the back of the phone. This will alert your connected responders and send them your GPS location, providing peace of mind.

Doro Aurora A10

Stay connected, feel secure

With optimised sound and three physical buttons, the Doro Aurora A10 provides a genuine ease of use for daily activities. You'll stay easily connected with your loved ones using the Doro Easy Interface, and at ease thanks to the Doro Secure Button. It activates the Response by Doro app to alert your loved ones quickly, should you need help at any time.



Image: An illustration showing the Doro Secure Button on the back of the Doro Aurora A10, emphasizing its GPS location feature and how it connects to a network of responders.

MAINTENANCE

Cleaning Your Device

To clean your Doro Aurora A10, use a soft, lint-free cloth. Avoid using abrasive cleaners or solvents, as these can damage the phone's surface.

Battery Care

The phone uses a 9V battery. For optimal battery life, avoid exposing the phone to extreme temperatures. Charge the phone using the provided USB cable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not turn on	Low battery; Battery not inserted correctly	Charge the phone; Ensure battery is properly seated
Cannot make/receive calls	No SIM card; Poor network signal	Insert SIM card; Move to an area with better signal
Sound issues during calls	Volume too low; Speaker/microphone obstruction	Adjust volume; Clear any obstructions from speaker/microphone
Screen unresponsive	Temporary software glitch	Restart the phone by holding the power button

If you encounter issues not listed here, please refer to the Doro support website or contact customer service.

SPECIFICATIONS

Model Name: Doro Aurora A10 Bone

Item Model Number: 8881

Operating System: Android 14

RAM Memory Installed Size: 3.99 GB

Memory Storage Capacity: 4 GB

CPU Speed: 2 GHz

Cellular Technology: 4G

Wireless Carrier: Unlocked

Colour: Bone

Connector Type: USB Type C

Batteries: 1 x 9V batteries (included)

Package Dimensions: 19 x 8.8 x 3.9 cm

Weight: 300 g

Manufacturer: Doro

Date First Available: 4 April 2025

WARRANTY AND SUPPORT

The Doro Aurora A10 Mobile Phone comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the documentation included with your purchase or visit the official Doro website.

For technical support, frequently asked questions, or to download the full user manual, please visit the Doro support page: www.doro.com/support.

Note: The provided information indicates "Guaranteed software updates until: unknown". Please check the official Doro website for the latest software update policy.

ADDITIONAL INFORMATION

Doro is committed to helping seniors live a better life by providing technology that promotes independence, security, and enjoyment. The Aurora A10 is part of a family of Doro devices designed with simplicity in mind.



The Aurora family for simplicity

Image: A collection of Doro Aurora series phones, showcasing the range of devices designed for simplicity and ease of use.



Image: A woman smiling while holding and using the Doro Aurora A10 mobile phone, demonstrating its comfortable grip and user-friendly design.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data. Please check the official Doro website or product page for any available video resources.