

## QDCFDXCXB-BROWN1

# Generic 8-Tier Bamboo Shoe Cabinet with Doors (Model QDCFDXCXB-BROWN1) Instruction Manual

Model: QDCFDXCXB-BROWN1 | Brand: Generic

## INTRODUCTION

Thank you for choosing the Generic 8-Tier Bamboo Shoe Cabinet. This manual provides essential information for the proper use, maintenance, and care of your new shoe cabinet. Please read it thoroughly before use and retain it for future reference.

## SAFETY INSTRUCTIONS

- Ensure the cabinet is placed on a flat, stable surface to prevent tipping.
- Utilize the anti-dumping device provided to secure the cabinet to a wall, especially in households with children or pets.
- Do not overload shelves beyond their capacity.
- Keep fingers clear of door hinges when opening and closing.
- Avoid exposing the cabinet to excessive moisture or direct sunlight for prolonged periods to prevent material damage.

## PACKAGE CONTENTS

The package includes one (1) Generic 8-Tier Bamboo Shoe Cabinet. Please inspect all components upon receipt to ensure no parts are missing or damaged.

**Note:** This product is shipped fully assembled. No assembly is required.

## SETUP

This shoe cabinet arrives pre-assembled, simplifying the setup process.

- Unpacking:** Carefully remove the cabinet from its packaging. Retain packaging materials until you are satisfied with the product.
- Placement:** Choose a suitable location in your entryway, hallway, closet, or living room. Ensure the surface is level and stable.
- Anti-Dumping Device Installation:** For enhanced safety, especially in homes with children or pets, it is highly

recommended to install the included anti-dumping device. Secure the cabinet to a wall following the instructions provided with the device.



Figure 1: Overall dimensions of the 8-Tier Bamboo Shoe Cabinet. The cabinet measures 121cm in width, 32cm in depth, and 108cm in height. Internal shelf spacing is approximately 14cm for upper shelves and 13cm for the bottom open shelf.



Figure 2: Detail showing the 32cm deepened width of the cabinet, providing ample space for various shoe sizes and top-surface items.

## OPERATING INSTRUCTIONS

---

The shoe cabinet is designed for straightforward use.

- **Storing Shoes:** Open the cabinet doors using the handles. Place shoes on the internal shelves. The cabinet can accommodate approximately 36-40 pairs of shoes, depending on their size and style.
- **Bottom Open Shelf:** The lower open compartment is ideal for slippers, frequently used shoes, or for accommodating a sweeping robot.
- **Top Surface:** The top surface features a protective fence, making it suitable for placing potted plants, decorative ornaments, keys, or other small items without concern of them falling off.
- **Door Mechanism:** The cabinet features double doors with magnetic locks for secure closure and easy access. The doors are made of Changhong acrylic material, providing a transparent yet textured appearance.



Figure 3: Detail of the exquisite handle design, facilitating easy opening and closing of the cabinet doors.

## Strong door stopper



Figure 4: The strong magnetic door stopper ensures the cabinet doors remain securely closed, protecting shoes from dust.

# Bottom heightened design



Figure 5: The bottom heightened design provides additional space for slippers or allows for easy cleaning underneath the cabinet, including access for sweeping robots.



Figure 6: The cabinet features Changhong acrylic transparent doors, offering a stylish look while allowing visibility of stored items and protecting them from dust.

## MAINTENANCE AND CARE

---

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the bamboo finish or acrylic doors.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Spills:** In case of spills, wipe immediately with a dry cloth to prevent water damage.
- **Door Hinges and Magnetic Catches:** Periodically check hinges and magnetic catches for proper function. Tighten screws if necessary.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Cabinet feels unstable or wobbly.	Uneven floor surface; anti-dumping device not installed or improperly secured.	Ensure the cabinet is on a level surface. Install or re-secure the anti-dumping device to a wall.
Doors do not close properly.	Misaligned hinges; obstruction; weak magnetic catch.	Check for any obstructions. Inspect hinges for alignment and tighten screws if loose. Ensure the magnetic catch is clean and functional.
Scratches or marks on bamboo surface.	Impact from sharp objects; abrasive cleaning.	Use a soft cloth for cleaning. For minor scratches, consult a furniture care specialist or use a bamboo-specific repair kit.

## SPECIFICATIONS

---

**Brand:** Generic

**Model Name:** QDCFDXCXB-BROWN1

**ASIN:** B0F3SLJFPN

**Material:** Bamboo, Changhong Acrylic (doors)

**Color:** Brown 1

**Mounting Type:** Floor Mount

**Door Style:** Double Doors with Magnetic Lock, Transparent (Changhong Acrylic)

**Product Dimensions (L x W x H):** Approximately 121 cm x 32 cm x 108 cm (47.6 x 12.6 x 42.5 inches)

**Item Weight:** Approximately 13000 Grams (28.7 pounds)

**Capacity:** 36-40 pairs of shoes

**Assembly Required:** No

**Manufacturer:** MYKJYXGS

## WARRANTY AND SUPPORT

---

For any issues, missing parts, or concerns regarding your Generic 8-Tier Bamboo Shoe Cabinet, please contact our professional after-sales customer service team. We are committed to resolving any problems within 24 hours.

Please refer to your purchase documentation or the retailer's website for specific warranty details and contact information.

**Manufacturer:** MYKJYXGS

