

[Manuals.plus](#) /

› [Portronics](#) /

› Portronics Nova 40W Portable Bluetooth Speaker User Manual - Model POR-2981

Portronics POR-2981

Portronics Nova 40W Portable Bluetooth Speaker User Manual

Model: POR-2981

1. INTRODUCTION

Thank you for choosing the Portronics Nova 40W Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully to ensure optimal performance and longevity of your device.



Image 1.1: The Portronics Nova 40W Portable Bluetooth Speaker, showcasing its sleek black design and integrated RGB LED strip.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x Portronics Nova Portable Speaker
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.

3.1. Controls and Ports



Image 3.1: An overview of the Portronics Nova speaker, highlighting its integrated button controls, Type-C charging port, USB-A port, and AUX-in port.

The speaker features integrated button controls on the top surface and various connectivity ports on the rear, typically protected by a rubber flap.

- **Power Button:** Press and hold to power on/off.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Play/Pause/Call:** Press to play/pause music, answer/end calls.
- **Mode Button:** Press to switch between Bluetooth, AUX, and USB modes.
- **RGB Light Button:** Press to change RGB light modes or turn them off.
- **Type-C Charging Port:** For charging the speaker.
- **USB-A Port:** For USB playback.
- **AUX-in Port:** For wired audio connection.

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's Type-C port and the other end to a compatible USB power adapter (not included).

- The LED indicator will show charging status.
- A full charge typically takes approximately 3-4 hours.
- Once fully charged, the LED indicator will change or turn off.

40W

HD SOUND



 **TYPE C**
Fast Charging

Image 4.1: The Portronics Nova speaker highlighting its 40W HD sound capability and Type-C fast charging port.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power button for 2-3 seconds. You will hear an audible prompt, and the LED lights will activate.
- **To Power Off:** Press and hold the Power button for 2-3 seconds. You will hear an audible prompt, and the LED lights will turn off.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Pairing

The speaker uses Bluetooth 5.3 for stable wireless connectivity.

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, press the Mode button to switch.

2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Portronics Nova" from the list of devices.
4. Once paired, the LED indicator will turn solid blue, and you will hear a confirmation sound.



Image 5.1: The Portronics Nova speaker demonstrating its Bluetooth 5.3 connectivity with a smartphone.

5.2. True Wireless Stereo (TWS) Mode

Pair two Portronics Nova speakers for a true stereo sound experience.

1. Ensure both speakers are powered on and in Bluetooth pairing mode (flashing blue LED).
2. On one of the speakers (this will be the primary speaker), double-press the Power button or a dedicated TWS button (if available). The speaker will search for another Nova speaker.
3. Once connected, you will hear a confirmation sound, and the LED indicators on both speakers will change to a solid blue.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 5.1.

TWS CONNECTIVITY

Pair Two Speaker together

$40W + 40W = 80W$



Image 5.2: Two Portronics Nova speakers connected via TWS mode, providing a combined 80W output for an enhanced audio experience.

5.3. Hands-Free Calling

The built-in microphone allows for hands-free calls when connected via Bluetooth.

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.

Hands Free Calling



In Built Microphone



Image 5.3: A user engaging in a hands-free call using the Portronics Nova speaker's built-in microphone.

5.4. RGB LED Lights

The speaker features dynamic RGB LED lights that enhance the listening experience.

- Press the dedicated RGB Light button to cycle through different light modes.
- Continue pressing to turn the lights off.

Colourful **RGB** Lights Strip Lights



Image 5.4: The Portronics Nova speaker displaying its vibrant, colorful RGB LED strip lights.

5.5. USB and AUX Playback

The speaker supports audio playback via USB drive and AUX cable.

- **USB Playback:** Insert a USB flash drive containing audio files into the USB-A port. The speaker will automatically switch to USB mode and begin playback. If not, press the Mode button.
- **AUX Playback:** Connect one end of a 3.5mm audio cable (not included) to the speaker's AUX-in port and the other end to your audio device's headphone jack. Press the Mode button to switch to AUX mode.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Water Resistance:** This speaker is **not waterproof**. Avoid exposing it to water, rain, or excessive moisture.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in

use for extended periods.

- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use.

7. TROUBLESHOOTING

If you encounter issues with your Portronics Nova speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed long enough.	Charge the speaker fully. Press and hold the Power button for 2-3 seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Bluetooth disabled on device; Speaker too far from device.	Ensure speaker is in Bluetooth mode (flashing LED). Enable Bluetooth on your device. Move speaker closer to device (within 10 meters).
No sound.	Volume too low; Incorrect mode selected; Device not playing audio.	Increase speaker and device volume. Press Mode button to select correct input (Bluetooth, AUX, USB). Ensure audio is playing on your device.
TWS pairing fails.	Speakers too far apart; One speaker already paired to a device.	Ensure both speakers are in Bluetooth pairing mode and close to each other. Disconnect any existing Bluetooth connections before TWS pairing.

8. SPECIFICATIONS

Key technical specifications for the Portronics Nova 40W Portable Bluetooth Speaker:

- **Model Name:** Nova
- **Model Number:** POR-2981
- **Output Power:** 40W
- **Bluetooth Version:** 5.3V
- **Wireless Communication Technology:** Bluetooth
- **Audio Output Mode:** Stereo
- **Power Source:** Battery Powered
- **Battery Type:** Lithium Polymer
- **Battery Capacity:** 2000 mAh (estimated from '2000' in JSON)
- **Playtime:** Up to 5 Hours (at moderate volume)
- **Charging Port:** Type-C
- **Connectivity Options:** Bluetooth, USB-A, AUX-in
- **Special Features:** Dual Passive Radiator, RGB LED Strip Lights, TWS Mode, Handsfree Calling
- **Control Method:** Touch Buttons
- **Material:** ABS Plastic
- **Product Dimensions:** 22.5D x 11.5W x 11.5H Centimeters
- **Item Weight:** 930 Grams
- **Water Resistance:** No (Not Waterproof)



UPTO
05 Hours
Playtime

Image 8.1: The Portronics Nova speaker, illustrating its capability for up to 5 hours of continuous playtime.

9. WARRANTY AND SUPPORT

Portronics products are designed for reliability and performance. For warranty information, please refer to the warranty card included with your product or visit the official Portronics website.

For technical support, product inquiries, or assistance, please contact Portronics customer service:

- **Email:** help@portronics.com
- **Phone:** +91 9555-245-245
- **Manufacturer:** Portronics Digital Pvt. Ltd.
- **Address:** First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301, India

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F3T4NZ1T>

More documents and user manuals: <https://manuals.plus/>