

[Manuals.plus](#) /

› [Notmise](#) /

› Notmise Heavy Duty 5-Tier Wire Shelving Unit Instruction Manual

Notmise Heavy Duty 5-Tier Wire Shelving Unit

Notmise Heavy Duty 5-Tier Wire Shelving Unit

Model: Heavy Duty 5-Tier Wire Shelving Unit (72"H x 48"W x 24"D)

Brand: Notmise

INTRODUCTION

This instruction manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Notmise Heavy Duty 5-Tier Wire Shelving Unit. Designed for maximum storage capacity, this unit is suitable for various environments including garages, kitchens, basements, workshops, and pantries. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The Notmise Heavy Duty 5-Tier Wire Shelving Unit, showcasing its robust design and ample storage space in a garage environment.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.


- Always ensure the shelving unit is fully assembled and stable before use.
- Do not exceed the weight limit of **500 lbs (227 kg) per shelf** or **2500 lbs (1134 kg) in total**. Distribute weight evenly across shelves.
- Always follow the assembly instructions carefully to prevent accidents.
- Keep children and pets away from the assembly area.
- Do not climb on the shelving unit.
- Ensure the unit is placed on a flat, stable surface.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package typically includes:

- Vertical support posts (multiple sections)
- Horizontal beams (for shelf support)
- 5 Wire shelves
- Rubber mallet (for assembly)
- Gloves (for assembly)
- Plastic feet/caps for posts
- Assembly instructions

• MORE ATTENTION TO DETAIL •



Double thick column

Hoist buckle design

Rubber floor mat

**High quality steel
wire layer board**

Image: Detailed view of key components, highlighting the double thick column, hoist buckle design, rubber floor mat, and high-quality steel wire layer board.

SETUP AND ASSEMBLY INSTRUCTIONS

The Notmise shelving unit features a user-friendly, boltless design for quick and simple assembly. No complex tools are required, only the included rubber mallet and gloves.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Assemble Vertical Posts:** Connect the vertical post sections by aligning the slots and gently tapping them together with the rubber mallet. Ensure they are securely fitted.
3. **Attach Horizontal Beams:** Begin by attaching the bottom horizontal beams to the vertical posts. Insert the beam tabs into the desired slots on the posts and tap with the rubber mallet until secure. Repeat for all four sides of the bottom shelf.
4. **Install First Shelf:** Place the wire shelf onto the installed horizontal beams.
5. **Continue with Remaining Shelves:** Determine the desired height for each subsequent shelf. Attach the horizontal beams at the chosen height, then place the wire shelves. The adjustable height settings allow customization for various items.
6. **Secure Top Beams:** Install the top horizontal beams and place the final wire shelf.
7. **Add Plastic Feet:** Place the plastic feet/caps onto the bottom of the vertical posts to protect your floor.
8. **Final Check:** Ensure all connections are tight and the unit is stable.

Your browser does not support the video tag.

Video: Detailed assembly guide for the Metal Garage Shelving, demonstrating each step of the setup process.

OPERATING INSTRUCTIONS

The Notmise shelving unit is designed for versatile storage. Its primary operation involves adjusting shelf heights to suit your specific needs.

- **Adjusting Shelf Height:** The horizontal beams can be repositioned to different slots on the vertical posts. To adjust, carefully remove the items from the shelf, then gently tap the beams upwards with the rubber mallet to disengage them from the slots. Reinsert the beams into the desired slots and tap down firmly to secure.
- **Loading Items:** Distribute weight evenly across each shelf. Place heavier items on lower shelves for increased stability.
- **Versatile Configuration:** The unit can be configured as a single tall unit or potentially split into two shorter workbench-style units (refer to assembly instructions for specific model capabilities).

WHY CHOOSE OUR PRODUCT

OURS



**Very stable
Very sturdy
Does not tip over easily**



OTHERS



**Precarious
Easily tilted
Falls apart easily**

**OURS
IS BETTER**

Image: Illustration of the adjustable shelving feature, demonstrating how shelf heights can be customized to accommodate various items like large tires.

Your browser does not support the video tag.

Video: Demonstration of the garage metal shelving unit in use, showing its capacity and how various items can be stored efficiently.

MAINTENANCE

To ensure the longevity and optimal performance of your shelving unit, follow these simple maintenance guidelines:

- **Cleaning:** The durable, powder-coated finish is scratch-resistant and easy to clean. Wipe down the shelves and frame with a damp cloth and mild detergent as needed. Avoid abrasive cleaners that could damage the finish.
- **Regular Inspection:** Periodically check all connections to ensure they remain secure. If any beams feel loose, gently tap them back into place with the rubber mallet.
- **Weight Distribution:** Always ensure weight is distributed evenly and does not exceed the maximum capacity per shelf or the total unit capacity.

TROUBLESHOOTING

If you encounter any issues with your shelving unit, please refer to the following common solutions:

- **Unit feels wobbly:** Ensure all horizontal beams are fully seated in their respective slots. Use the rubber mallet to firmly tap down any loose connections. Verify the unit is on a level surface.
- **Difficulty assembling beams:** Ensure the tabs on the beams are correctly aligned with the slots on the vertical posts. Apply firm, even pressure and use the rubber mallet as instructed. Sometimes a slight wiggle can help align the components.
- **Missing parts:** If any parts are missing or damaged upon arrival, please contact customer support immediately with your order details.

SPECIFICATIONS

Feature	Detail
Product Dimensions	72" H x 48" W x 24" D (182.88 cm H x 121.92 cm W x 60.96 cm D)
Number of Shelves	5
Material	Alloy Steel
Finish Type	Powder Coated (Black)
Load Capacity (Per Shelf)	500 lbs (227 kg)
Total Load Capacity	2500 lbs (1134 kg)
Special Feature	Adjustable Shelf Height
Mounting Type	Floor Mount (Freestanding)
Assembly Required	Yes (Boltless design)
Item Weight	80 Pounds (36.29 kg)



Image: Visual representation of the shelving unit's dimensions (72"H x 48"W x 24"D).



Image: Graphic detailing the impressive load capacity of 500 lbs per shelf and 2500 lbs total for the heavy-duty unit.

WARRANTY AND CUSTOMER SUPPORT

Notmise is committed to your satisfaction. This product is designed for long-term use and comes with dedicated customer support. If you have any inquiries, require assistance with assembly, or need to report missing/damaged parts, please contact our customer service team. Refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question