

[Manuals.plus](#) /

> [LIFKOME](#) /

> LIFKOME Blind Cord Safety Part Tensioner for Rolladen Gurtwickler Unterputz Window Shade Cord Winder Blind Tidy

## LIFKOME DDX33V19EJDNKHVZP23J9Y5R

# LIFKOME Blind Cord Winder Instruction Manual

Model: DDX33V19EJDNKHVZP23J9Y5R

## INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your LIFKOME Blind Cord Winder. Please read this manual thoroughly before using the product to ensure proper function and safety.

## SAFETY INFORMATION

---

- Always ensure the product is securely mounted to prevent accidental detachment.
- Keep blind cords out of reach of small children and pets to prevent entanglement hazards.
- Do not attempt to modify the product. Any modifications may void the warranty and pose safety risks.
- Use only for its intended purpose as a blind cord winder.

## PRODUCT OVERVIEW AND COMPONENTS

---

The LIFKOME Blind Cord Winder is designed to manage blind cords efficiently, enhancing both safety and aesthetics. It is constructed from durable ABS, Nylon, and Stainless steel materials.




**Figure 1:** Front view of the LIFKOME Blind Cord Winder. This image shows the compact, white housing of the winder with the cord neatly integrated.

### Package Contents:

- 1 x Blind Cord Winder

### SPECIFICATIONS

| Attribute                  | Detail                             |
|----------------------------|------------------------------------|
| Material                   | ABS, Nylon, Stainless steel        |
| Color                      | White                              |
| Product Dimensions (L x W) | 8.46"L x 6.3"W (21.50cm x 16.00cm) |
| Item Weight                | 13.1 ounces (371.38 grams)         |
| Model Number               | DDX33V19EJDNKHVZP23J9Y5R           |
| Country of Origin          | China                              |



**Figure 2:** Dimensions of the Blind Cord Winder. This image illustrates the length (21.5cm / 8.45in), height (16cm / 6.29in), and depth (3.3cm / 1.30in) of the product.

## SETUP AND INSTALLATION

---

The installation process for the LIFKOME Blind Cord Winder is designed to be straightforward and user-friendly, requiring no specialized tools.

1. **Identify Mounting Location:** Choose a suitable location near your window blind where the cord winder can be securely attached. Ensure it is positioned to effectively manage the blind cord.

# APPLICATION SCENARIOS



**Figure 3:** Application scenarios. This image displays various window types and blind setups where the cord winder can be effectively used, including standard window blinds and plantation shutters.

2. **Prepare the Blind Cord:** Ensure the blind cord is free of tangles and is accessible for winding.



**Figure 4:** Preparing the blind cord. This image shows hands holding the blind cord and the winder, demonstrating the initial step of feeding the cord into the device.

- 3. Mount the Winder:** Secure the blind cord winder to the wall or window frame using appropriate fasteners (not included, as specific fasteners depend on mounting surface). The winder features mounting points on its base for stability.



**Figure 5:** Mounting the winder. This image depicts a person using a drill to secure the winder to a surface, highlighting the mounting points.

4. **Feed and Secure Cord:** Carefully feed the blind cord into the winder's mechanism. Ensure the cord is properly seated and tensioned to prevent slippage.



**Figure 6:** Cord insertion detail. A close-up view showing the patterned blind cord entering the winder's slot, indicating how the cord is managed.

## OPERATING INSTRUCTIONS

---

Once installed, the LIFKOME Blind Cord Winder helps maintain a tidy and safe environment by managing excess blind cord length.

- To shorten the visible cord length, gently pull the cord through the winder until the desired length is achieved. The internal mechanism will store the excess cord.
- To lengthen the cord, carefully pull the cord from the winder. The winder is designed to release cord smoothly.
- Always ensure the cord moves freely within the winder and is not snagged or twisted.



**Figure 7:** Winder in operation with plantation shutters. This image shows the winder mounted and managing the cord for a set of white plantation shutters, demonstrating its discreet integration.

## MAINTENANCE

---

The LIFKOME Blind Cord Winder requires minimal maintenance to ensure long-lasting performance.

- **Cleaning:** Wipe the exterior of the winder with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Inspection:** Periodically check the winder for any signs of wear or damage, especially around the cord entry and exit points. Ensure the mounting is secure.
- **Cord Condition:** Inspect the blind cord itself for fraying or damage. A damaged cord should be replaced by a qualified professional.

## TROUBLESHOOTING

---

If you encounter issues with your Blind Cord Winder, refer to the following common problems and solutions:

| Problem                                | Possible Cause   | Solution  |
|--|--|---|
| Cord does not retract smoothly.        | Cord is twisted or snagged inside the winder.                  | Gently pull the cord out and re-feed it, ensuring it is straight. Check for any obstructions.                           |
| Winder feels loose after installation. | Mounting screws are not tight or mounting surface is unstable. | Tighten mounting screws. If the surface is unstable, consider reinforcing it or choosing a different mounting location. |
| Cord does not stay at desired length.  | Internal mechanism issue or cord material incompatibility.     | Ensure the cord is correctly inserted and is of a compatible type. If the issue persists, contact customer support.     |

## WARRANTY AND SUPPORT

---

For any questions, technical assistance, or warranty inquiries regarding your LIFKOME Blind Cord Winder, please contact the manufacturer directly. Refer to the product packaging or the retailer's website for specific contact information. Please have your model number (DDX33V19EJDNKHVZP23J9Y5R) and purchase date available when contacting support.