

FeeKaa FK-HD-U8

FeeKaa Foldable High Speed Kids Hair Dryer FK-HD-U8 Instruction Manual

Model: FK-HD-U8

1. INTRODUCTION

Thank you for choosing the FeeKaa Foldable High Speed Kids Hair Dryer. This compact and lightweight hair dryer is designed with children's delicate hair and scalp in mind, featuring 100 million negative ions to reduce frizz and enhance shine. It offers multiple heat and speed settings for gentle and efficient drying. Please read this manual thoroughly before use to ensure safe and optimal operation.

Included Components:

- FeeKaa Foldable High Speed Kids Hair Dryer
- Diffuser attachment
- Concentrator attachment
- Detangler brush
- Hair ties
- Decorative stickers

All-in-One Kit for Little Stylists



Diffuser

For curly, wavy hair or adding volume



Detangling Brush

Detangle without pulling, pain, or tears



Hair Ties

Soft on delicate hair, strong on style



Concentrator

For straight style or precision styling



Cute Stickers

Let child decorate their styling buddy

Image: FeeKaa Kids Hair Dryer with all included accessories, demonstrating the complete kit.

2. SAFETY PRECAUTIONS

To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- **Keep out of reach of children:** This appliance is not a toy. Adult supervision is required when used by or near children.
- **Do not use while bathing:** Never use this appliance near water, in a bathtub, shower, or sink.
- **Keep away from water:** If the appliance falls into water, unplug it immediately. Do not reach into the water.
- **Handle with care:** Do not drop, throw, or disassemble the appliance.
- **Power Cord:** Do not wrap the cord around the appliance. Keep the cord away from heated

surfaces.

- **US ALCI Safety Plug:** This hair dryer is equipped with an Appliance Leakage Current Interrupter (ALCI) safety plug. Press the 'TEST' button before each use. If the 'RESET' button pops up, press 'RESET' to continue. If it fails to reset, discontinue use.



Image: Detail of the US ALCI Safety Plug, highlighting the 'TEST' and 'RESET' buttons for electrical safety.

3. SETUP

Unfolding the Hair Dryer:

1. Gently hold the main body of the hair dryer.
2. Unfold the handle until it clicks securely into place.

Attaching Accessories:

The hair dryer comes with a concentrator and a diffuser. These attachments can be easily connected to the nozzle of the hair dryer.

- **Concentrator:** For focused airflow, ideal for straight styling or precision drying. Align the concentrator with the dryer nozzle and push firmly until it snaps into place.
- **Diffuser:** For enhancing natural curls and waves, or adding volume. Align the diffuser with the dryer nozzle and push firmly until it snaps into place.

Concentrator

For straight style or precision styling



Image: Demonstrating the attachment of the concentrator nozzle to the hair dryer.

Diffuser

For curly, wavy hair or adding volume



Image: Demonstrating the attachment of the diffuser to the hair dryer.

4. OPERATING INSTRUCTIONS

Powering On/Off:

Plug the hair dryer into a standard electrical outlet. Use the power switch located on the handle to turn the appliance on or off.

Heat and Speed Settings:

The FeeKaa Kids Hair Dryer offers customizable settings to suit different hair types and drying needs:

- **Temperature Modes:** Choose from 4 temperature settings: 100°F (Low Heat), 120°F (Medium Heat), 150°F (High Heat), and a Cool Shot button for setting styles.
- **Speed Settings:** Select between 2 airflow speeds.

Adjust the settings using the dedicated buttons on the handle. The low-temperature settings are ideal for gentle drying, while higher speeds provide faster drying for thicker hair.

Image: Controls for tailored temperatures and speeds on the hair dryer.

Ionic Technology:

This hair dryer releases over 100 million negative ions during operation. This technology helps to reduce frizz, enhance hair shine, and minimize knots and static, resulting in softer, healthier, and smoother hair.

Tailored Temps for Tiny Scalps

4 heat settings and 2 wind speeds, fit growing kids and evolving routines



Image: Visual representation of hair before and after using the ionic hair dryer, showing improved shine and smoothness.

Fast Drying:

The high-speed motor is designed to significantly reduce drying time. For short hair, expect 1-2 minutes; medium length hair, 2-3 minutes; and long hair, 4-5 minutes.



Image: Estimated drying times for various hair lengths using the high-speed motor.

Your browser does not support the video tag.

Video: An official product video demonstrating the FeeKaa Foldable High Speed Kids Hair Dryer in use, highlighting its features and compact design.

5. MAINTENANCE

Cleaning:

Ensure the hair dryer is unplugged and completely cool before cleaning. Wipe the exterior with a soft, damp cloth. Periodically check the air inlet filter at the back of the dryer for lint or dust buildup and clean it to maintain optimal airflow and performance.

Storage:

The hair dryer features a foldable design for convenient storage and travel. After use, allow the appliance to cool down completely. Fold the handle for a compact form factor. Store it in a dry place, away from moisture and direct sunlight. The included Velcro strap can be used to secure the cord for tidy storage.

Silky-Smooth Strand Magic

100 million negative ions reduce frizz, seal moisture, add shine, and protect delicate hair

Before

After

↑ **+50%**
Shine

↑ **+50%**
Smooth

↓ **-40%**
Frizz

Image: The hair dryer's foldable design for easy storage and portability.

6. TROUBLESHOOTING

• Appliance does not turn on:

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check the ALCI safety plug. Press the 'RESET' button. If it does not reset, the plug may be faulty or there might be an electrical issue.

- **Low airflow or overheating:**

- Unplug the appliance and allow it to cool down.
- Check the air inlet filter at the back of the dryer for any obstructions (e.g., lint, dust, hair) and clean it thoroughly.

- **Attachments do not attach securely:**

- Ensure the attachments are correctly aligned with the dryer nozzle.
- Apply firm, even pressure until the attachment clicks into place. If the attachment still does not secure, inspect both the attachment and the dryer nozzle for any damage or debris.

7. SPECIFICATIONS

Feature	Detail
Model Number	FK-HD-U8
Product Dimensions	9 x 9 x 3 inches
Item Weight	2.12 Pounds (0.88 lbs for the dryer itself)
Wattage	800 watts
Power Source	Corded Electric
Voltage	120 Volts
Maximum Temperature	150 Degrees Fahrenheit
Number of Speeds	2
Number of Settings	9 (combinations of heat and speed)
Special Features	Compact, Cool Shot Button, Foldable, Ionic Technology, Lightweight
Hair Type	All
Material Type	Plastic

8. WARRANTY AND SUPPORT

Warranty Information:

The FeeKaa Foldable High Speed Kids Hair Dryer comes with a standard warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. An extended warranty application may be available; check the product documentation for details on how to apply.

Customer Support:

For any questions, concerns, or support needs regarding your FeeKaa product, please contact customer service. Contact information can typically be found on the product packaging or the official FeeKaa website.