Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic F10 Pro

Proscenic F10 Pro Cordless Wet and Dry Vacuum Cleaner

Model: F10 Pro

INTRODUCTION

The Proscenic F10 Pro is a versatile 3-in-1 cordless wet and dry vacuum cleaner, combining sweeping, mopping, and vacuuming functions. It is designed for efficient cleaning of sealed hard floors, including wood, tile, marble, and laminate, effectively tackling wet, dry, and sticky messes. Its intelligent features and user-friendly design make daily cleaning tasks simpler and more effective.



Image: The Proscenic F10 Pro vacuum cleaner shown with its charging base and cleaning solution bottle.

Setup

Before first use, ensure the Proscenic F10 Pro is fully charged. Simply place the vacuum on its charging base. The LED display will indicate charging status. It is recommended to fully charge the device before its initial operation to ensure optimal performance.

- **Unpacking:** Carefully remove all components from the packaging.
- **Assembly:** Attach the handle to the main body of the vacuum until it clicks into place.
- **Charging:** Place the vacuum on the charging base. The device will begin charging automatically.

- **Filling Water Tank:** Fill the clean water tank with clean water and, if desired, a suitable cleaning solution.

Operating Instructions

3-in-1 Cleaning Function

The F10 Pro combines sweeping, mopping, and vacuuming into one efficient machine. With a high-speed rotation of 550 RPM and powerful suction, it effectively removes wet, dry, and sticky messes like pet hair, ketchup, large debris, and eggs. It is suitable for all sealed hard floors, including wood, tile, marble, and laminate.



Image: The vacuum cleaning different types of spills and debris, illustrating its 3-in-1 capability.

Self-Propelled and Lightweight Design

This all-in-one vacuum and mop machine features a self-propelled system, allowing it to move forward easily and reducing strain on your arms and back. Weighing only 4.4 kg, it is light and easy to maneuver, even for elderly users or those with less physical

strength.



Image: A user operating the self-propelled vacuum cleaner, showing its ease of movement.

Extreme Edge Cleaning

Designed with a narrow roller brush, the F10 Pro can clean close to baseboards and deep into edges and corners, reaching difficult-to-access areas. Its precise edge handling, up to 7mm wide, ensures excellent cleaning performance near walls and baseboards, eliminating the need for additional edge cleaning.



Image: The vacuum cleaning along a wall, highlighting its ability to clean close to edges.

Three Modes and Smart LED Screen

The smart cordless vacuum offers three adjustable power levels: Smart Mode (for daily cleaning), Max Mode (for stubborn stains), and Water Absorption Mode (for absorbing liquids). Equipped with an LED screen and voice prompts, you can quickly monitor the cleaning mode, battery life, and maintenance alerts in real-time.



Image: Close-up of the vacuum's LED display showing various modes and indicators, with examples of cleaning scenarios for each mode.

Long Battery Life and Dual Tank System

With a 30-minute battery life, this cordless stick vacuum can clean up to 970 square feet without interruption. It features a 650ml clean water tank and a 500ml dirty water tank, allowing for extensive cleaning without frequent water changes. The dual-tank technology ensures you always clean with fresh water, while dirty water is collected in a separate tank to prevent cross-contamination, ideal for homes with children or pets.



Image: Two individuals cleaning with the vacuum, illustrating its long battery life and the separate clean and dirty water tanks.

Maintenance

Self-Cleaning Function

The F10 Pro features an automatic self-cleaning cycle for the roller brush. Simply press a button, and the vacuum will clean the roller brush with clean water, immediately sucking the dirty water into the dirty water tank. This process ensures that dirty water, stubborn dirt, and debris are removed from the roller brush, leaving the brush, internal tube, and suction port clean to prevent odors.



Image: Diagram showing the self-cleaning water flow from the clean water tank, through the brush, and into the dirty water tank.

Easy Tank Cleaning

The solid-liquid separator in the dirty water tank allows for quick and easy disposal of dirt, enabling you to clean the dirty water tank in just 1 minute. Regular cleaning of both the clean and dirty water tanks is essential for maintaining hygiene and optimal performance.

- **After Each Use:** Empty and rinse the dirty water tank.
- **Regularly:** Check and clean the roller brush and filter to prevent blockages and odors.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Power / Not Turning On	Battery is low or depleted.	Place the vacuum on the charging base and ensure it is fully charged.
Poor Suction / Cleaning Performance	Dirty water tank is full; Roller brush is clogged; Filter is dirty.	Empty the dirty water tank. Clean the roller brush. Clean or replace the HEPA filter.
Unpleasant Odor	Dirty water tank or roller brush not cleaned properly.	Perform the self-cleaning cycle. Thoroughly clean the dirty water tank and roller brush.
Water Leaking	Water tanks not properly installed or damaged.	Ensure both clean and dirty water tanks are securely in place. Check for any cracks or damage.

Specifications

Brand	Proscenic
Model Number	F10 Pro
Color	F10 Pro White
Product Dimensions (L x W x H)	109.22 x 20.32 x 25.4 cm
Item Weight	3 Kilograms
Capacity (Clean Water Tank)	0.65 Liters
Capacity (Dirty Water Tank)	0.5 Liters
Power	230 Watts
Voltage	28.8 Volts
Noise Level	62 dB
Battery Life	Up to 30 minutes
Filter Type	HEPA Filter
Surface Recommendation	All sealed hard floors (wood, tile, marble, laminate)
Power Source	Battery Powered
Wireless	Yes
Special Features	Waterproof, Light, High-precision sensors, Wet/dry, Self-cleaning base stations, Smart detection (auto-adjusts suction power and water volume), 3-in-1 sweeping/vacuuming/cleaning, Lightweight, Automatic brush, LED touch screen and voice notifications, Solid and liquid waste separation, Storage stand, Rechargeable, Portable, Compact, Self-standing stability, Washable filter, Hypoallergenic, Impeccable cleaning, Self-propelled

Warranty and Support

Proscenic is committed to providing high-quality products and excellent customer service. Your F10 Pro vacuum cleaner comes with comprehensive support and warranty coverage.

- **Warranty Period:** Enjoy up to 24 months of warranty coverage from the date of purchase.
- **Money-Back Guarantee:** A 30-day money-back guarantee is offered for your peace of mind.
- **Customer Support:** A dedicated 24/7 quick assistance team is available to help with any queries or issues you may encounter.
- **Returns:** For return or replacement inquiries, please refer to the seller's return policy.



Image: Icons representing 24/7 support, 30-day money-back guarantee, and up to 24-month warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3X1CQ8P

More documents and user manuals: **https://manuals.plus/**