

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Audizio](#) /
- › [Audizio Boston All-in-One Retro Style Music Centre User Manual](#)

## Audizio 102.195

# Audizio Boston All-in-One Retro Style Music Centre

User Manual - Model: 102.195

## INTRODUCTION

---

Thank you for purchasing the Audizio Boston All-in-One Retro Style Music Centre. This versatile system combines a turntable, CD player, DAB+/FM radio, USB playback, and Bluetooth connectivity, all with integrated stereo speakers. This manual provides essential information for safe and optimal use of your device. Please read it thoroughly before operation and retain it for future reference.

## SAFETY INSTRUCTIONS

---

- **Power Source:** Ensure the power supply matches the voltage specified on the unit.
- **Ventilation:** Do not block any ventilation openings. Maintain adequate space around the unit for proper airflow.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids on the unit.
- **Heat Sources:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth. Do not use liquid or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the unit on a stable, flat surface. Avoid placing it in direct sunlight or near strong magnetic fields.

## PACKAGE CONTENTS

---

Upon opening the package, ensure all items are present and in good condition:

- Audizio Boston Music Centre Unit
- External Stereo Speakers (2 units)
- Remote Control
- User Manual (this document)
- Power Adapter

## SETUP

### Unpacking and Placement

Carefully remove the unit and its components from the packaging. Place the main unit and the two external speakers on a stable, flat surface. Ensure there is enough space for ventilation around the unit.



Image: The Audizio Boston Music Centre with its main unit and two detached stereo speakers, ready for setup.

### Connecting the Speakers

Connect the included stereo speakers to the "SPEAKERS" output terminals on the rear of the main unit. Ensure the left speaker is connected to the "L" terminal and the right speaker to the "R" terminal.



Image: Detailed view of the rear panel of the Audizio Boston, highlighting the AUX IN and speaker output connections (RCA type) for connecting the external speakers.

## Power Connection

Connect the power adapter to the DC 12V 2.5A input on the rear of the unit, then plug the adapter into a suitable wall outlet.

## OPERATING INSTRUCTIONS

### Front Panel Overview



Image: Close-up of the Audizio Boston's front panel, showing the LCD display, illuminated VU meters, control buttons, and volume knob.

The front panel features an LCD display, illuminated VU meters, control buttons for various functions (Play/Pause, Skip, Mode, Scan/Select, Menu), and a large volume knob.

### Remote Control Functions



Image: The remote control for the Audizio Boston Music Centre, displaying buttons for power, mode, scan, mute, playback controls, volume, EQ, and repeat/preset functions.

The included remote control provides convenient access to all major functions, including power, mode selection, playback controls, volume adjustment, and EQ settings.

### Turntable Operation

The turntable supports 3 speeds: 33 1/3, 45, and 78 RPM. Ensure the correct speed is selected for your vinyl record. Place the record on the platter, lift the tone arm using the cueing lever, position it over the record, and gently lower it. The auto-stop feature will stop the platter when the record finishes.



Image: The Audizio Boston Music Centre with a vinyl record playing on its turntable, demonstrating its primary function.

### CD Player Operation

Insert a CD into the disc tray located on the front panel. The unit will automatically detect the CD and begin playback. Use the playback controls on the unit or remote to play, pause, skip tracks, or stop.



Image: The Audizio Boston Music Centre with its CD tray extended, showing a CD being inserted or removed.

## USB Playback

Insert a USB flash drive into the USB port on the front panel. The unit supports MP3 playback. Use the controls to navigate through folders and tracks.



Image: A close-up of the Audizio Boston's front panel, showing a USB flash drive inserted into the USB port, with the display indicating USB playback mode.

### **Bluetooth Connectivity**

Switch the unit to Bluetooth mode. On your mobile device, search for "Audizio Boston" in the Bluetooth settings and pair. Once connected, you can stream audio wirelessly to the music centre.



Image: A person holding a smartphone, wirelessly streaming music to the Audizio Boston Music Centre, demonstrating Bluetooth connectivity.

## DAB+/FM Radio

Switch to DAB+ or FM radio mode. Use the scan function to automatically search for available stations. You can save your favorite stations as presets for quick access.

## AUX Input

Connect external audio devices (e.g., smartphone, MP3 player) to the AUX IN port on the rear of the unit using a 3.5mm audio cable. Select AUX mode on the unit to play audio from the connected device.

## MAINTENANCE

### Cleaning the Unit

Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. For the turntable stylus, use a specialized stylus cleaning brush.

### Record Care

Keep your vinyl records clean and free of dust. Store them vertically in their sleeves to prevent warping. Avoid touching the record grooves directly.

### CD Care

Handle CDs by their edges. Clean them with a soft, lint-free cloth, wiping from the center outwards. Avoid scratching the disc surface.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty	Ensure power cable is securely plugged in; Try a different power outlet.
No sound from speakers	Speakers not connected; Volume too low; Incorrect input mode selected	Check speaker connections; Increase volume; Select the correct input mode (e.g., Phono, CD, Bluetooth).

Problem	Possible Cause	Solution
Turntable not spinning or playing	Speed setting incorrect; Tone arm not lowered; Auto-stop engaged prematurely	Select correct speed (33/45/78 RPM); Ensure tone arm is fully lowered onto the record.
Bluetooth pairing issues	Device too far; Bluetooth not enabled on source device; Unit not in pairing mode	Move device closer; Enable Bluetooth on your device; Ensure the unit is in Bluetooth pairing mode.
CD skipping or not playing	CD is dirty or scratched; CD inserted incorrectly	Clean the CD with a soft cloth; Ensure the CD is inserted correctly with the label side up.

## SPECIFICATIONS

Feature	Detail
Model Name	102.195
Product Dimensions	57.5 x 29.6 x 43.2 cm
Weight	8 kg
Power Source	Electric with cable (220 Volts)
Turntable Speeds	33 1/3, 45, 78 RPM
Connectivity	Bluetooth, USB, AUX In, RCA Out (for speakers)
Radio	DAB+, FM
Signal-to-Noise Ratio	60 dB
Material	Wood
Included Components	Main unit, external speakers, remote control, user manual

## WARRANTY AND SUPPORT

### Warranty Information

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

### Customer Support

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Audizio customer support. Contact details can typically be found on the manufacturer's website or on the product packaging.

*Note: Specifications are subject to change without notice.*

