Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave GZZ000078NQK3

Bellemave Queen Over King Bunk Bed Instruction Manual

Model: GZZ000078NQK3 | Brand: Bellemave

1. Introduction

Thank you for purchasing the Bellemave Queen Over King Bunk Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before assembly and retain this manual for future reference.

This heavy-duty metal bunk bed is designed for durability and space-saving, featuring a Queen-sized upper bed and a King-sized lower bed. It includes two integrated ladders and full-length guardrails for safety.



Image 1.1: Front view of the Bellemave Queen Over King Bunk Bed.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the recommended mattress size for each bed.
- Ensure all connections are tight before use. Periodically check and tighten all bolts.
- The upper bunk is not suitable for children under six years of age.
- **Upper Bed Weight Capacity:** 400 LBS.
- **Bottom Bed Weight Capacity:** 600 LBS.
- Do not allow more than one person on the upper bunk.
- Always use the ladder for entering and leaving the upper bunk. Do not use substitute parts. Contact the manufacturer for replacement parts.

- This bunk bed is certified by the Children's Product Certificate (CPC).
- This bunk bed cannot be converted into two single beds.

3. Parts List

Your Bellemave Queen Over King Bunk Bed will arrive in two separate boxes. Please ensure you have received both packages and all components are present before beginning assembly. Refer to the detailed parts list included in your packaging for specific component identification.

Key components include:

- Metal Frame Sections (Headboards, Footboards, Side Rails)
- Metal Slats for both Queen and King beds
- Integrated Ladders (2)
- Full-Length Guardrails for the upper bunk
- Noise-Reducing Rubber Stoppers
- Assembly Hardware (bolts, nuts, washers, Allen wrench)



Image 3.1: Detail showing heavy-duty slats, rubber stopper, and built-in ladder.

4. Setup and Assembly

Assembly is required for this bunk bed. Detailed instructions and numbered parts are included in the packaging to guide you step-by-step. It is recommended to have two adults for assembly.

1. **Unpack and Identify:** Carefully unpack all components from both boxes. Lay out all parts and hardware on a clean, soft surface (like a carpet) to prevent scratches. Compare with the included parts list to ensure everything is present.
2. **Initial Frame Assembly:** Begin by assembling the main frame sections according to the numbered steps in your instruction manual. Do not fully tighten bolts until the entire frame is loosely assembled.
3. **Attach Ladders and Guardrails:** Securely attach the two side ladders and the full-length guardrails to the upper bunk frame as instructed. Ensure all connections are firm.
4. **Install Slats:** Place the metal slats onto both the upper (Queen) and lower (King) bed frames. Ensure the noise-reducing rubber stoppers are correctly positioned to fix the slats firmly.

5. **Final Tightening:** Once the entire bunk bed structure is assembled, go back and securely tighten all bolts and screws. Do not overtighten.
6. **Placement:** Position the bunk bed in its desired location, ensuring it is stable and level.

Note: This Queen Over King bunk bed is designed as a single unit and cannot be separated into two individual beds.



Image 4.1: Side view of the bunk bed, highlighting the integrated ladder.

5. Usage and Operation

This bunk bed is designed for efficient space utilization and comfortable sleeping arrangements.

- **Space Saving Design:** The Queen over King configuration maximizes sleeping capacity in a compact footprint. The design also provides approximately 9.4 inches of clearance under the lower bed for convenient storage of items like trunks, toys, shoes, or books.
- **Noise-Free Operation:** Equipped with noise-reducing rubber stoppers, the bed frame is designed to prevent slats from moving and minimize noise, ensuring a quiet sleep environment.
- **Access:** The two integrated side ladders provide safe and easy access to the upper Queen bunk.
- **Headroom:** There is approximately 40 inches of height between the upper and lower beds, providing ample activity space and reducing the risk of bumping heads.



Image 5.1: Under-bed storage clearance.

Image 5.2: Height between beds and guardrail detail.

Watch the video below for a visual overview of the Bellemave Queen Over King Bunk Bed.

Your browser does not support the video tag.

Video 5.1: Overview of the Bellemave Queen Over King Bunk Bed in black.

6. Maintenance

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any that have become loose to maintain the bed's stability and prevent wobbling.
- **Slat Inspection:** Ensure all metal slats are securely in place and the rubber stoppers are functioning correctly to prevent noise.

7. Troubleshooting

- **Wobbling or Instability:**

  This is often caused by loose connections. Re-check and tighten all bolts and screws throughout the entire frame. Ensure the bed is placed on a level surface. If the issue persists after tightening, disassemble and reassemble carefully, ensuring all parts are correctly aligned according to the instructions.
- **Noise from Slats:**

Verify that all noise-reducing rubber stoppers are properly installed and securing the slats. Ensure slats are correctly seated in their designated positions.

- **Missing or Damaged Parts:**

  If you find any parts missing or damaged upon delivery, please do not proceed with assembly. Contact customer support immediately for assistance.

- **Difficulty Assembling:**

  Refer to the detailed assembly instructions provided with your product. Ensure you are following each step in order and using the correct hardware for each connection. If you continue to experience difficulties, contact customer support.

8. Specifications

Feature	Detail
Brand	Bellemave
Model Number	GZZ000078NQK3
Configuration	Queen Over King Bunk Bed
Material	Heavy Duty Metal
Color	Black
Product Dimensions (L x W x H)	82.7" x 78.7" x 64"
Upper Bed Weight Capacity	400 LBS
Bottom Bed Weight Capacity	600 LBS
Under-bed Storage Clearance	9.4 inches
Height Between Beds	40 inches
Included Components	Guardrails, Slats, 2 Ladders
Assembly Required	Yes (Instructions Included)

Image 8.1: Detailed dimensions of the bunk bed.

9. Warranty and Support

For any issues, missing parts, or questions regarding your Bellemave Queen Over King Bunk Bed, please contact our customer support team.

- **Customer Support Email:** service@bellemave.com
- **Return Policy:** This product typically comes with a 30-day return policy. Please refer to your purchase documentation for specific return details.

We are committed to providing high-quality products and support to ensure your satisfaction.

© 2026 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3X31RFR

More documents and user manuals: **https://manuals.plus/**