

[Manuals.plus](#) /

› [Dnniakm](#) /

› Dnniakm M108 Open Ear Earbuds User Manual

Dnniakm M108

Dnniakm M108 Open Ear Earbuds User Manual

Model: M108 | Brand: Dnniakm

INTRODUCTION

Welcome to the user manual for your Dnniakm M108 Open Ear Earbuds. These earbuds are designed to provide a comfortable and safe listening experience by allowing you to remain aware of your surroundings while enjoying high-quality audio. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device.



Image: Dnniakm M108 Open Ear Earbuds shown inside their charging case, ready for use.

PACKAGE CONTENTS

Upon unboxing, please ensure all items are present:

- Dnniakm M108 Open Ear Earbuds (Left and Right)
- Charging Case
- USB Charging Cable (Type-C)
- User Manual (this document)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The indicator light on the charging case will show charging status. A full charge provides up to 42 hours of total playtime with the case. A 10-minute charge can provide up to 2 hours of playback.



Image: Illustration of the Dnniakm M108 earbuds and charging case, highlighting battery life and quick charge capabilities.

2. Pairing with a Bluetooth Device

The M108 earbuds use Bluetooth 5.4 for stable and fast connections.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.

4. Select "M108" from the list of devices.
5. Once connected, a voice prompt will confirm successful pairing.

Note: Please avoid using in environments with strong magnetic interference or when there are walls/obstacles between the phone and the earbuds for optimal connection.

Bluetooth 5.4 Technology Quick One-Touch Connection

Once paired, just open the charging case to instantly connect to your <M108> Bluetooth device. Supports easy switching between mobile and PC



Image: The M108 earbuds and charging case displayed alongside a smartphone and laptop, illustrating multi-device Bluetooth 5.4 connectivity.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The M108 earbuds feature an open-ear, clip-on design for comfort and situational awareness.

1. Gently clip each earbud onto your ear, ensuring the speaker portion is positioned near your ear canal without blocking it.
2. Adjust the flexible U-shaped bridge for a secure and comfortable fit.

3. The lightweight design (4g per earbud) ensures comfort during extended wear, even for glasses wearers.

Open-Ear Design with Ear Clip


Enjoy Ultimate Comfort Without Any Distractions



Image: A person wearing the Dnniakm M108 open-ear earbuds, demonstrating the comfortable and secure clip-on design.

Hi-Fi Stereo Sound Quality

Rich, Detailed Sound



Directional Acoustics

Sound is precisely delivered to minimize leakage and enhance audio quality



0.88mm Large Amplitude

Wide dynamic range with adaptive bass enhancement and a balanced sound profile




Image: Two individuals demonstrating the open-ear clip-on comfort of the M108 earbuds, including compatibility with glasses.

2. Touch Controls

The M108 earbuds feature intuitive touch controls on each earbud.

Function	Action (L/R Earbud)
Power On	Long Press 3s (L and R)
Power Off	Long Press 5s (L/R)
Previous Song	Click*3 (L)
Next Song	Click*3 (R)
Play/Pause	Click*2 (L/R)
Increase Volume	Click*1 (R)
Decrease Volume	Click*1 (L)
Answer/Hang up Call	Click*2 (L/R)
Refuse to Answer Call	Long Press 2s (L/R)
Music Mode/Game Mode	Click*4 (L/R)
Activate Voice Assistant (Siri)	Long Press 2s (L/R)
Restore Factory Settings	Click*5 (L/R)



Image: A visual guide to the smart touch controls on the M108 earbuds, detailing various functions and corresponding tap/press actions.

3. Call Functions

The M108 earbuds are equipped with ENC noise reduction technology for clear calls.

- **Answer/Hang up:** Double-tap either earbud.
- **Refuse Call:** Long press either earbud for 2 seconds.

MAINTENANCE

1. Cleaning

To maintain optimal performance and hygiene:

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture in any openings.

2. Water Resistance

The M108 earbuds have an IP56 waterproof rating, making them resistant to sweat, rain, and splashes.

- Do not submerge the earbuds in water.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

TROUBLESHOOTING

If you encounter issues with your M108 earbuds, please refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are charged.
- Place earbuds back in the case, close, then open again to re-enter pairing mode.
- Turn off and on your device's Bluetooth.
- If issues persist, perform a factory reset (Click*5 on either earbud).

• **No sound or low volume:**

- Check the volume level on both your device and the earbuds.
- Ensure earbuds are properly connected to your device.
- Clean any debris from the speaker grilles.

• **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different charging cable or power adapter.
- Verify that the charging contacts on the earbuds and in the case are clean and free of obstruction.

• **Sound leakage:**

- While the M108 is designed for open-ear listening with reduced leakage, ensure the earbuds are positioned correctly on your ears.
- Lowering the volume can also help minimize sound leakage.

SPECIFICATIONS

Feature	Detail
Model Name	M108
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.4
Bluetooth Range	10 Meters
Earpiece Shape	Clip-on, Open Ear
Audio Driver Type	Bone Conduction Driver
Frequency Response	20Hz - 20,000Hz
Sensitivity	104 dB
Battery Life (Single Charge)	Up to 6 hours
Total Playtime (with case)	Up to 42 hours
Quick Charge	10 minutes charge for 2 hours playback
Control Type	Touch Control
Water Resistance Level	IP56 Waterproof
Noise Control	Adaptive Noise Cancellation (for calls)
Material	Acrylonitrile Butadiene Styrene (ABS)

Feature	Detail
Item Weight (Earbuds)	Approx. 4g per earbud
Compatible Devices	Bluetooth-enabled devices (Smartphones, Tablets, Laptops)

WARRANTY AND SUPPORT

Warranty Information

Dnniakm offers a **2-year after-sales service** for the M108 Open Ear Earbuds. This warranty covers manufacturing defects and ensures product quality. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or assistance with your Dnniakm M108 earbuds, please do not hesitate to contact our customer service team.

- **Contact Method:** Refer to the contact information provided with your product packaging or on the official Dnniakm website.
- When contacting support, please provide your product model (M108) and a detailed description of the issue.

