

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ULANZI](#) /

› **ULANZI MT88 ClipMate 3-in-1 Camera Tripod Instruction Manual**

ULANZI MT88

ULANZI MT88 ClipMate 3-in-1 Camera Tripod Instruction Manual

Model: MT88

PRODUCT OVERVIEW

The Ulanzi MT88 ClipMate is a versatile 3-in-1 accessory designed for action cameras, DJI Pocket3, Xtra Muse, and Insta 360 X5. It functions as a backpack clip, selfie stick, and tabletop tripod, offering flexibility for various shooting scenarios. Its compact and portable design makes it ideal for on-the-go use.




Image: Ulanzi MT88 ClipMate Tripod in use, demonstrating its backpack clip functionality with a camera attached.

PACKAGE CONTENTS

Verify that all items are present in the package:

- ClipMate Tripod x1
- Velcro Strap x1

Included:

ClipMate Tripod*1

Velcro Strap*1



Image: The ULANZI MT88 ClipMate Tripod and its accompanying Velcro strap, displayed next to its packaging.

SETUP AND ASSEMBLY

1. Attaching Your Device

The MT88 features a universal 1/4" screw mount for broad compatibility with various cameras and accessories. Simply screw your action camera, DJI Pocket3, Xtra Muse, Insta 360 X5, or phone holder (not included) onto the top of the ball head until secure.

Wide Compatibility

The 1/4" screw works with action cameras, phone holders, and other accessories—ready for any creative setup.



Max load
1kg



*Only the tripod and Velcro strap included.

Image: Illustration demonstrating the wide compatibility of the 1/4" screw mount with different devices.

2. Adjusting the Ball Head

The 360° rotating ball head allows for flexible angle adjustments. Loosen the side knob to freely rotate your device to any desired angle, including switching between portrait and landscape orientations. Tighten the knob to lock the position.

360° Ball Head

Rotate freely for any angle with the ball head and switch between portrait & landscape in seconds.



Image: Illustration demonstrating the 360° rotation and 90° tilt capabilities of the ball head.

3. Using the Backpack Clip

Attach the tripod to a backpack strap using the integrated clip design. Simply pull down to lock it securely onto the strap, and lift to release. The Velcro strap with non-slip silicone grips ensures a firm hold on most bags (compatible with 6-8cm wide and 1cm+ thick straps, Velcro width >3cm).

Strap & Go

The Velcro strap securely fits most bags, with non-slip silicone grips that keep your gear firmly in place.



compatible with 6–8cm wide and 1cm+ thick straps

*Velcro width ≥3cm



Image: Detailed view of the Velcro strap and the clip mechanism, showing how to attach the tripod to a backpack strap.




Video: Demonstration of attaching the ULANZI MT88 ClipMate Tripod to a camera backpack strap using its quick-release system.

OPERATING MODES

The ULANZI MT88 offers three distinct modes for versatile use:


3 Modes, Endless Creativity

Switch modes in seconds to match your scene—backpack clip, selfie stick, or stable tripod.




Backpack Clip Mode

Hands-free POV shots on the move



Selfie Stick Mode

Get the perfect group shot or solo angle



Tripod Mode

Steady shots

Image: Visual representation of the three operating modes: Backpack Clip, Selfie Stick, and Tripod.

1. Backpack Clip Mode

Securely attach the tripod to your backpack strap for hands-free point-of-view (POV) shots while on the move. This mode is ideal for capturing dynamic footage during activities like hiking or cycling.

MT88 ClipMate Mini Tripod

Endless possibilities



Image: A person demonstrating the Backpack Clip Mode with an action camera mounted on the tripod attached to their backpack strap.

2. Selfie Stick Mode

Extend the tripod's central column to transform it into a selfie stick. This allows you to capture wider angles for group photos or achieve unique perspectives for solo shots. The 3-section adjustable design provides flexibility in length.

Three-section Adjustable Mini Tripod



Image: A diagram illustrating the three adjustable sections of the mini tripod, showing its extension capabilities.

Video: Demonstration of the ULANZI MT88 ClipMate Tripod functioning as a selfie stick, highlighting its extendable feature.

3. Tripod Mode

Fold out the legs at the base to use the MT88 as a stable tabletop tripod. This mode is perfect for steady shots, time-lapses, or hands-free video calls.

Video: Overview of the ULANZI MT88 ClipMate Tripod, showcasing its various features including the tripod mode.

MAINTENANCE

- Keep the tripod clean by wiping it with a soft, dry cloth.
- Avoid exposing the tripod to extreme temperatures or harsh chemicals.

- Ensure all screws and connections are tightened before use to prevent accidental damage to your device.
- Store in a dry place when not in use.

TROUBLESHOOTING

- **Device feels unstable:** Ensure the 1/4" screw is fully tightened to your device and the ball head knob is securely fastened.
- **Tripod legs not extending/retracting smoothly:** Check for any obstructions and ensure the sections are clean. Apply a small amount of silicone lubricant if necessary.
- **Backpack clip not holding securely:** Verify that the strap width and thickness are within the compatible range (6-8cm wide, 1cm+ thick, Velcro width >3cm) and that the clip is fully engaged.

SPECIFICATIONS

Feature	Detail
Brand	ULANZI
Model	MT88
Material	Plastic + Aluminum Alloy
Max Load Capacity	1kg
Folded Size	15*4.3cm
Selfie Stick Height	15-26.5cm
Tripod Height	12.5-24.5cm
Weight	138.5g
Compatible Devices	Camera, DJI Pocket3, Insta 360 X5
Special Feature	Foldable, Lightweight

*Manually measured weight and size may not be accurate.

WARRANTY INFORMATION

ULANZI products typically come with a limited manufacturer's warranty. Please refer to the product packaging or the official Ulanzi website for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Ulanzi MT88 ClipMate Tripod, please visit the official Ulanzi website or contact their customer service department. Contact information can usually be found on the product packaging or the brand's online store.

Official Ulanzi Store: [Visit Ulanzi Store on Amazon](#)