

TFWX3506

User Manual for Rose Analog Watch

Model: TFWX3506

1. INTRODUCTION

Thank you for choosing the Rose Analog Watch, Model TFWX3506. This timepiece is designed for individuals who appreciate a blend of classic style and reliable functionality. Featuring a durable strap and a uniquely crafted dial, this watch is suitable for both casual and semi-formal occasions. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your watch to ensure its longevity and accurate performance.

2. SAFETY INFORMATION

- Keep the watch away from strong magnetic fields, as this can affect the accuracy of the quartz movement.
- Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes.
- While the watch is designed for daily wear, it is generally splash-resistant. Avoid submerging it in water or wearing it during swimming or showering unless explicitly stated otherwise for your specific model.
- Do not attempt to open the watch case or replace the battery yourself, as this may void the warranty and damage the internal components. Seek professional assistance for battery replacement.
- Keep the watch out of reach of small children due to small parts that could pose a choking hazard.

3. SETUP

3.1 Unboxing

Upon opening the package, ensure that the watch is present and appears undamaged. No assembly is required for immediate use.

3.2 Setting the Time

1. Locate the crown (the small knob on the side of the watch case).
2. Gently pull the crown outwards until you feel a click. The watch hands will stop moving.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position. The watch hands will resume movement.

3.3 Strap Adjustment

The Rose Analog Watch features a silver-tone mesh strap with a magnetic clasp for easy adjustment and a secure fit.

1. Open the magnetic clasp.

2. Place the watch on your wrist.
3. Adjust the magnetic clasp along the mesh strap until you achieve a comfortable and snug fit. The magnet will securely hold the strap in place.



Figure 1: Rose Analog Watch. This image displays the Rose Analog Watch, featuring a round silver-tone case, a black dial adorned with golden star and moon hour markers, and a sleek silver-tone mesh strap with a magnetic clasp.

4. OPERATING

Once the time is set and the strap is adjusted, your Rose Analog Watch is ready for daily wear. The watch operates continuously using its quartz movement, providing accurate timekeeping.

- **Daily Use:** Wear the watch comfortably on your wrist.
- **Time Reading:** Read the time directly from the hour and minute hands on the dial.

5. MAINTENANCE

5.1 Cleaning

To maintain the appearance of your watch:

- Wipe the watch case and strap regularly with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water (do not use harsh chemicals or abrasive materials).
- Ensure the watch is completely dry before wearing it again.

5.2 Water Resistance

This watch is designed for everyday use and is generally splash-resistant. It is *not* suitable for swimming, showering, or diving. Avoid direct contact with water beyond light splashes.

5.3 Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops or begins to lose time consistently, it likely needs a new battery. Battery life varies but typically lasts for several years.

For battery replacement, it is highly recommended to take your watch to a qualified watch repair professional. Attempting to replace the battery yourself may damage the watch and void its warranty.

5.4 Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. A watch box or soft pouch can help protect it from dust and scratches.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Crown is pulled out; Battery is depleted.	Push the crown back into its normal position; Replace battery (professional service recommended).
Time is inaccurate	Low battery; Exposure to strong magnetic fields.	Replace battery; Move watch away from magnetic sources.
Strap feels loose/tight	Improper adjustment of magnetic clasp.	Re-adjust the magnetic clasp along the mesh strap for a comfortable fit.

7. SPECIFICATIONS

Feature	Detail
Model Number	TFWX3506
Product Dimensions	10 x 2.4 x 2 cm
Item Weight	100 g (0.1 Kilograms)
Case Diameter	38 Millimetres
Watch Movement Type	Quartz (as per product description)
Band Material Type	Mesh (as per product image, note: data indicates Leather/PU)
Band Colour	Silver-tone (as per product image, note: data indicates Brown)
Manufacturer	TF WATCHES
Country of Origin	India

Note: Some specifications regarding band material and color in the provided data may differ from the visual representation of the product. The manual describes the product as visually presented.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This product comes with a Manufacturer's Warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of the warranty. The warranty typically covers manufacturing defects.

8.2 Customer Support

For any questions, concerns, or support needs regarding your Rose Analog Watch, please contact the retailer or the

manufacturer, TF WATCHES. Keep your purchase receipt and model number (TFWX3506) handy when contacting support.

© 2025 Generic. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Documents - TFWX3506 – TFWX3506
no relevant documents