Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool AFI2539ERM00

Whirlpool Refrigerator Door Shelf Bin Instruction Manual

Model: AFI2539ERM00 | Part Number: WPW10224961

1. Introduction

Product Overview

This document provides essential instructions for the installation, proper use, and maintenance of the Genuine OEM Whirlpool Refrigerator Door Shelf Bin, part number WPW10224961. This shelf bin is an authentic replacement part designed to restore the organization and functionality of your refrigerator door.

Compatibility

This door shelf bin is specifically designed for Whirlpool refrigerator model AFI2539ERM00. To ensure correct fitment, always verify your refrigerator's model number. The model number is typically located inside the fresh food compartment or on the side wall of the appliance. Using an incorrect part may lead to improper fit or damage.



Image: A Whirlpool refrigerator with the door shelf bin location highlighted. This image illustrates where the door shelf bin is typically installed within the refrigerator door.

2. Installation (Setup)

Before beginning, ensure the refrigerator door is open and stable. No tools are typically required for this installation.

1. **Remove the Old Bin (if applicable):** Gently lift the existing door shelf bin upwards and then pull it outwards to detach it from the door liner. Dispose of the old bin responsibly.
2. **Align the New Bin:** Position the new door shelf bin so that its mounting tabs align with the corresponding slots on the refrigerator door liner.
3. **Insert and Secure:** Press the bin firmly downwards until it clicks securely into place. Ensure both sides are fully seated and the bin is stable.
4. **Test Stability:** Lightly tug on the installed bin to confirm it is securely attached before placing items inside.



Image: Angled view of the door shelf bin, showing its overall shape and clear front panel.




Image: Top-down view of the door shelf bin, illustrating its internal dimensions and mounting points.



Image: Front view of the door shelf bin, highlighting the clear front panel and overall width.



Image: Side view of the door shelf bin, showing its depth and height.

3. Operating (Proper Use)

The door shelf bin is designed to hold various items such as bottles, condiments, and jars. Distribute weight evenly to prevent stress on the bin and ensure longevity. Avoid overloading the bin with excessively heavy items, as this can lead to damage or dislodgement.

4. Care and Maintenance

To clean the door shelf bin, remove it from the refrigerator door. Wash with mild soap and warm water. Rinse thoroughly and dry completely before re-installing. Avoid using abrasive cleaners or harsh chemicals, as these can damage the plastic material.

5. Troubleshooting

- **Bin Does Not Fit:** Double-check your refrigerator's model number against the compatible model

AFI2539ERM00. If the model numbers do not match, the bin may be incorrect for your appliance. Refer to the compatibility section.

- **Bin Feels Loose After Installation:** Ensure the bin's mounting tabs are fully engaged and clicked into the door liner slots. Remove and re-install, applying firm downward pressure until it is secure.
- **Bin Appears Damaged Upon Arrival:** Inspect the bin immediately upon receipt. If any damage is observed, contact the seller or manufacturer for assistance.

6. Specifications

Manufacturer	Whirlpool
Part Number	WPW10224961
Item Weight	1.1 pounds
Product Dimensions	14.25 x 7.25 x 4.5 inches
Compatible Model Number	AFI2539ERM00
Included Components	1 x Genuine Whirlpool Door Shelf Bin

7. Warranty Information

This Genuine OEM Whirlpool Door Shelf Bin comes with a 1-year warranty. For specific terms and conditions, or to make a warranty claim, please refer to the documentation provided with your original refrigerator purchase or contact Whirlpool customer service.

8. Customer Support

For further assistance, questions regarding compatibility, or support with installation, please contact the seller or Whirlpool customer service. When contacting support, please have your refrigerator's full model number (AFI2539ERM00) and the part number (WPW10224961) readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3XSV94S

More documents and user manuals: **https://manuals.plus/**